

Integrator's Reference Manual for the VSX Series

Version 8.7

August 2007 Edition
3725-21905-005/A
VSX Version 8.7



Trademark Information

Polycom®, the Polycom logo design, SoundStation®, SoundStation VTX 1000®, and Vortex® are registered trademarks of Polycom, Inc., and Conference Composer™, Global Management System™, ImageShare™, MGC™, People+Content™, Polycom *InstantDesigner*™, Polycom PathNavigator™, PowerCam™, Pro-Motion™, Siren™, StereoSurround™, Visual Concert™, VSX™, and VTX™ are trademarks of Polycom, Inc. in the United States and various other countries. VISCA is a trademark of Sony Corporation. All other trademarks are the property of their respective owners.

Patent Information

The accompanying product is protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

© 2007 Polycom, Inc. All rights reserved.

Polycom Inc.
4750 Willow Road
Pleasanton, CA 94588-2708
USA

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc. Under the law, reproducing includes translating into another language or format.

As between the parties, Polycom, Inc. retains title to, and ownership of, all proprietary rights with respect to the software contained within its products. The software is protected by United States copyright laws and international treaty provision. Therefore, you must treat the software like any other copyrighted material (e.g. a book or sound recording).

Every effort has been made to ensure that the information in this manual is accurate. Polycom, Inc. is not responsible for printing or clerical errors. Information in this document is subject to change without notice.

Contents

1 Room Integration	1-1
Setting Up a Room for Video Conferencing	1-1
Room Layout Examples	1-1
Integrating Video	1-5
Connecting Polycom Cameras	1-5
Connecting Other Video Cameras	1-15
Integrating Audio and Content	1-18
Connecting a VSX 8000 to a Vortex Mixer and SoundStation VTX 1000	1-19
Connecting a VSX 7000e to a Vortex Mixer and SoundStation VTX 1000	1-19
Configuring the Vortex, SoundStation VTX 1000, and VSX System to Work Together	1-20
2 Cables	2-1
Network Cables	2-1
LAN Cable	2-1
ISDN Cable	2-2
Analog Telephone (POTS) Cable	2-3
V.35/RS-449/RS-530 Serial Adapter	2-4
V.35 NIC Cable	2-5
V.35 and RS-366 Serial Cable	2-6
RS-449 and RS-366 Serial Cable	2-7
RS-530 with RS-366 Serial Cable	2-8
Video and Camera Cables	2-9
S-Video Cable	2-9
BNC to S-Video Cable	2-10
BNC to S-Video Adapter	2-11
VCR/DVD Composite Cable	2-12
VGA Cable	2-13
Composite Video Cable	2-14
PowerCam Plus Primary Cable	2-15
PowerCam Primary Camera Cable	2-16
PowerCam Break-Out Cable	2-17
PowerCam/VISCA Control Cable (VSX 7000e or VSX 8000)	2-18
RS-232 Adapter	2-20

PowerCam/VISCA Control Cable (VSX 7000 or VSX 7000s)	2-21
S-Video to RCA Adapter	2-22
Audio Cables	2-23
Audio Cable	2-23
Vortex Cable (VSX 8000)	2-24
Balanced Audio Connector	2-25
Vortex Cable (VSX 6000, VSX 6000A, VSX 7000, VSX 7000s, or VSX 7000e)	2-26
VSX to VTX Cable	2-27
Visual Concert to VTX Cable	2-28
Subwoofer Volume Attenuator	2-29
Serial Cables	2-30
RS-232 Cable (VSX 5000, VSX 6000, VSX 6000A, VSX 7000, or VSX 7000s)	2-30
Straight-Through Serial Cable (VSX 7000e or VSX 8000)	2-32
Null Modem Cable	2-34
Null Modem Adapter	2-35
Content Sharing Cables	2-36
Visual Concert VSX Cable	2-36
ImageShare II to Computer Cable	2-37
IR Connector	2-38

3 Using the API 3-1

Using the API with an RS-232 Interface	3-1
Configuring the RS-232 Interface	3-1
Starting an API Session via an RS-232 Interface	3-2
Using the API with a LAN Connection	3-3
Using the API Controller Code	3-3

4 System Commands 4-1

About the API Commands	4-2
Syntax Conventions	4-2
Availability of Commands	4-2
!	4-3
abk	4-5
addressdisplayedingab	4-7
adminpassword	4-8
advnetstats	4-9
alertusertone	4-11
alertvideotone	4-12
all register	4-13
all unregister	4-14
allowabkchanges	4-15
allowcamerapresetssetup	4-16
alldialing	4-17
allowmixedcalls	4-18

allowstreaming	4-19
allowusersetup	4-20
answer	4-21
areacode	4-22
audiometer	4-23
audiotransmitlevel	4-24
autoanswer	4-25
autoshowcontent	4-26
backlightcompensation	4-27
basicmode	4-28
bri1enable, bri2enable, bri3enable, bri4enable	4-29
briallenable	4-30
button	4-31
calldetail	4-34
calldetailreport	4-35
callencryption (deprecated)	4-36
callinfo	4-37
callpreference	4-38
callstate	4-39
callstats	4-40
camera	4-41
cameradirection	4-44
camerainput	4-45
chaircontrol	4-46
colorbar	4-48
colorscheme	4-49
configchange (deprecated)	4-50
configdisplay	4-51
configparam	4-52
configpresentation	4-56
confirmdiradd	4-58
confirmdirdel	4-59
contentauto	4-60
country	4-61
cts	4-62
daylightsavings	4-63
dcd	4-64
dcdfilter	4-65
defaultgateway	4-66
dhcp	4-67
dial	4-68
dialchannels	4-70
dialingdisplay	4-71
dialingentryfield	4-72
diffservaudio, diffservfecc, diffservvideo	4-73
dir	4-74

directory	4-75
display (deprecated)	4-76
displayglobaladdresses	4-77
displaygraphics	4-78
displayipext	4-79
displayipisdninfo (deprecated)	4-80
displayparams	4-81
dns	4-82
dsr	4-83
dsranswer	4-84
dtr	4-85
dualmonitor	4-86
dynamicbandwidth	4-87
e164ext	4-88
echo	4-89
echocanceller	4-90
echocancellerred	4-92
echocancellerwhite	4-93
enablefirewalltraversal	4-94
enablepvec	4-95
enablersvp	4-96
enablesnmp	4-97
encryption	4-98
exit	4-99
farcontrolnearcamera	4-100
farnametimedisplay	4-101
flash	4-102
gabk	4-103
gabpassword	4-104
gabserverip	4-105
gatekeeperip	4-106
gatekeeperpin	4-107
gatewayareacode	4-108
gatewaycountrycode	4-109
gatewayext	4-110
gatewaynumber	4-111
gatewaynumbertype	4-112
gatewayprefix	4-113
gatewayssetup	4-114
gatewaysuffix	4-115
gendial	4-116
gendialtonepots (deprecated)	4-117
generatetone	4-118
get screen	4-119
getcallstate	4-120
gmscopy	4-121

gmscontactemail	4-122
gmscontactfax	4-123
gmscontactnumber	4-124
gmscontactperson	4-125
gmscountry	4-126
gmsstate	4-127
gmstechsupport	4-128
gmsurl	4-129
graphicsmonitor	4-130
h239enable	4-131
h323name	4-132
h331audiomode	4-133
h331dualstream	4-134
h331framerate	4-135
h331videofORMAT	4-136
h331videoprotocol	4-137
hangup	4-138
help	4-139
history	4-140
homecallquality	4-141
homemultipoint	4-142
homerecentcalls	4-143
homesystem	4-144
homesystemname	4-145
hostname	4-146
ipaddress	4-147
ipdialspeed	4-148
ipisdninfo	4-149
ipprecaudio, ipprecfecc, ipprecvideo	4-150
ipstat	4-151
isdnareacode	4-152
isdncountrycode	4-153
isdndialingprefix	4-154
isdndialspeed	4-155
isdnum	4-156
isdnswitch	4-157
keypadaudioconf	4-158
language	4-159
lanport	4-160
linestate	4-161
listen	4-162
localdatetime	4-163
marqueedisplaytext	4-164
maxgabinternationalcallspeed	4-165
maxgabinternetcallspeed	4-166
maxgabisdncallspeed	4-167

maxtimeincall	4-168
mcupassword	4-169
meetingpassword	4-170
midrangespeaker	4-171
monitor1 (deprecated)	4-172
monitor1screensaveroutput	4-173
monitor2 (deprecated)	4-174
monitor2screensaveroutput	4-175
mpautoanswer	4-176
mpmode	4-177
mtumode	4-178
mtusize	4-179
mute	4-180
muteautoanswer	4-181
natconfig	4-182
nath323compatible	4-183
nearloop	4-184
netstats	4-185
nonotify	4-186
notify	4-187
ntpmode	4-190
ntpserver	4-191
numberofmonitors (deprecated)	4-192
numberofrouterhops	4-193
numdigitsdid	4-194
numdigitsext	4-195
overlayname	4-196
overlaytheme	4-197
pause	4-198
phone	4-199
ping	4-200
pip	4-201
popupinfo	4-203
preset	4-204
priareacode	4-205
pricallbycall	4-206
prichannel	4-207
pricsu	4-209
pridialchannels	4-210
priintlprefix	4-211
prilinebuildout	4-212
prilinesignal	4-213
primarycallchoice	4-214
primarycamera	4-215
prinumber	4-216
prinumberingplan	4-217

prioutsideline	4-218
priswitch	4-219
reboot	4-220
recentcalls	4-221
registerall	4-222
registerthissystem	4-223
remotecontrol	4-224
remotemonenable	4-226
repeat	4-227
requireacctnumtodial	4-228
roomphonenummer	4-229
rs232 baud, rs232port1 baud	4-230
rs232 mode, rs232port1 mode	4-231
rs232monitor	4-232
rs366dialing	4-233
rt	4-234
rts	4-235
run	4-236
screen	4-237
screencontrol	4-238
secondarycallchoice	4-239
serialnum	4-240
setaccountnumber	4-241
showgatekeeper	4-242
showpopup	4-243
sleep	4-244
sleeptext	4-245
sleeptime	4-246
snapshottimeout	4-247
snmpadmin	4-248
snmpcommunity	4-249
snmpconsoleip	4-250
snmplocation	4-251
snmpsystemdescription	4-252
snmptrapversion	4-253
soundeffectsvolume	4-254
spidnum	4-255
st	4-257
stream	4-258
streamannounce	4-259
streamaudioport	4-260
streamenable	4-261
streammulticastip	4-262
streamrestoredefaults	4-263
streamrouterhops	4-264
streamspped	4-265

streamvideoport	4-266
subnetmask	4-267
subwoofer	4-268
subwooferoffset	4-269
sysinfo	4-270
systemname	4-271
tcpports	4-272
techsupport	4-273
teleareacode	4-274
telenumber	4-275
telnetmonitor	4-276
timediffgmt	4-277
traceroute	4-278
typesofservice	4-279
udpports	4-280
unregisterall	4-281
usefixedports	4-282
usegatekeeper	4-283
usepathnavigator	4-284
useroompassword	4-285
v35broadcastmode	4-286
v35dialingprotocol	4-287
v35num	4-288
v35portsused	4-289
v35prefix	4-290
v35profile	4-291
v35suffix	4-292
validateacctnum	4-293
vcbutton	4-294
vcraudioout	4-295
vcrrecordsource	4-296
vcstream	4-297
version	4-298
vgaqualitypreference	4-299
videocallorder	4-300
voicecallorder	4-301
volume	4-302
vortex	4-303
vtxstate	4-304
waitfor	4-305
wake	4-306
wanipaddress	4-307
webport	4-308
whoami	4-309
winsresolution	4-310
winsserver	4-311

xmladvnetstats	4-312
xmlnetstats	4-313

A Room Design and Layout A-1

Room Requirements	A-1
Walls	A-3
Windows	A-3
Ceiling Tiles	A-4
Air Conditioning	A-4
Interior Design and Finishes	A-5
Furniture	A-5
Acoustics	A-5
Room Lighting	A-6
Light Fixtures	A-7
Room Preparation Conclusion	A-8
Audio Elements	A-8
Audio Input	A-8
Audio Output	A-10
Direction	A-10
Power	A-10
Range/Frequency Response	A-11
Video Elements	A-11
Video Projection for Use in Videoconference	A-12
Cameras	A-12
Room Control Elements	A-13

B Categorical List of API Commands B-1

API Utility Commands	B-2
Audio Commands	B-2
Call Commands	B-3
Cameras, Content, and Monitors Commands	B-3
Diagnostics and Statistics Commands	B-4
Global Services Commands	B-4
Home Screen Setting Commands	B-4
Local Directory Commands	B-5
Network Commands	B-5
IP Commands	B-5
ISDN Commands	B-6
Telephony Commands	B-6
V.35/RS-449/RS-530 Commands	B-6
Notification Commands	B-7
Security and Permissions Commands	B-7
Serial Port Commands	B-7
Streaming Commands	B-7
Systems Settings Commands	B-8

C	Commands that Prompt Restart	C-1
D	API Changes in This Version	D-1
	Commands Introduced in Version 8.7	D-1
	Commands Newly Deprecated in Version 8.7	D-1
E	Status Messages	E-1
	Status Display	E-1
	B Channel Status Message Example	E-1
F	IR Codes for Non-Polycom Remotes	F-1

Room Integration


Setting Up a Room for Video Conferencing

For detailed information about setting up a room for video conferencing, refer to [Room Design and Layout](#) on page A-1.


Room Layout Examples

Use the following diagrams as examples for setting up a conference room with Polycom® VSX™ systems. Polycom recommends that you contract an experienced contractor to assure all the components operate as a single cohesive system.


Small Conference Room




Large Conference Room



Classroom



Auditorium



Integrating Video

The following sections describe how to connect cameras to VSX systems. After you connect a camera to a VSX system, refer to the *Administrator's Guide for the VSX Series* for information about configuring the camera options in the user interface.

Connecting Polycom Cameras

You can connect the VSX 8000 and VSX 7000e systems to either a PowerCam or PowerCam Plus camera from Polycom, or to other supported cameras. You must use a PowerCam Plus as the main camera, not as a secondary camera. Refer to the release notes for a list of supported PTZ cameras.

In addition to their integrated main camera, VSX 7000 and VSX 7000s systems provide an S-Video input for a second camera. You can use the RS-232 serial port on the VSX 7000 or VSX 7000s system for camera control. Refer to the release notes for a list of supported PTZ cameras.

You can connect a camera to the VCR video input on any VSX system (except the VSX 3000 executive desktop systems). On the VSX 6000 and VSX 6000A systems, the video input is for a composite video signal. VSX 5000, VSX 6000, and VSX 6000A systems do not provide pan/tilt/zoom (PTZ) control for a second camera.




Plenum-rated CAT5 cable adapters are available from several manufacturers such as Sound Control Technologies and Vaddio. These cables allow you to connect cameras up to several hundred feet away.

PowerCam as the Main Camera up to 10 ft Away


You can connect a PowerCam (part number 2215-50370-001) to a VSX 8000 as the main camera up to 10 ft away using:

- PowerCam Primary cable shown on page 2-16
- S-Video to BNC adapter shown on page 2-11



You can connect a PowerCam (part number 2215-50370-001) to a VSX 7000e as the main camera up to 10 ft away using:

- PowerCam Primary cable shown on page 2-16




PowerCam as the Main Camera More Than 10 ft Away

The following extension kits are available, which include the power supply, PowerCam Break-Out cable, PowerCam/VISCA Control cable, and S-Video cable:

- 7230-21703-001 (50 ft)
- 7230-21704-001 (100 ft)
- 7230-21705-001 (150 ft)
- 7230-21706-001 (200 ft)


You can connect a PowerCam (part number 2215-50370-001) to a VSX 8000 as the main camera for distances more than 10 ft away using:

- PowerCam Break-Out cable shown on page [2-17](#)
- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)
- S-Video to BNC adapter shown on page [2-11](#)
- Power Supply (part number 1465-52621-036)



You can connect a PowerCam (part number 2215-50370-001) to a VSX 7000e as the main camera for distances more than 10 ft away using:

- PowerCam Break-Out cable shown on page [2-17](#)
- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)
- Power Supply (part number 1465-52621-036)




PowerCam as the Secondary Camera

The following kits are available, which include the power supply, PowerCam Break-Out cable, PowerCam/VISCA Control cable, and S-Video cable:

- 7230-22231-001 (50 ft)
- 7230-22232-001 (100 ft)


You can connect a PowerCam (part number 2215-50370-001) to a VSX 8000 as the secondary camera using:

- PowerCam Break-Out cable shown on page [2-17](#)
- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)
- Power Supply (part number 1465-52621-036)




You can connect a PowerCam (part number 2215-50370-001) to a VSX 7000e as the secondary camera using:

- PowerCam Break-Out cable shown on page [2-17](#)
- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)
- Power Supply (part number 1465-52621-036)




You can connect a PowerCam (part number 2215-50370-001) to a VSX 7000 as the secondary camera using:

- PowerCam Break-Out cable shown on page [2-17](#)
- PowerCam/VISCA Control cable shown on page [2-21](#)
- S-Video cable on page [2-9](#)
- Power Supply (part number 1465-52621-036)



You can connect a PowerCam (part number 2215-50370-001) to a VSX 7000s as the secondary camera using:

- PowerCam Break-Out cable shown on page [2-17](#)
- PowerCam/VISCA Control cable shown on page [2-21](#)
- S-Video cable on page [2-9](#)
- Power Supply (part number 1465-52621-036)




If you connect a PTZ camera to a serial port, set **RS-232 Mode** to **Sony PTZ** on the Serial Ports screen.

PowerCam Plus as the Main Camera up to 10 ft Away


You can connect a PowerCam Plus (part number 2215-50200-001) to a VSX 8000 as the main camera up to 10 ft away using:

- PowerCam Plus Primary cable shown on page [2-15](#)
- S-Video to BNC adapter shown on page [2-11](#)



You can connect a PowerCam Plus (part number 2215-50200-001) to a VSX 7000e as the main camera up to 10 ft away using:


- PowerCam Plus Primary cable shown on page [2-15](#)



PowerCam Plus as the Main Camera More Than 10 ft Away


You can connect a PowerCam Plus (part number 2215-50200-001) to a VSX 8000 as the main camera for distances more than 10 ft away using:

- PowerCam Plus Primary cable shown on page 2-15
- S-Video to BNC adapter shown on page 2-11
- Power Supply (part number 1465-52621-036)



You can connect a PowerCam Plus (part number 2215-50200-001) to a VSX 7000e as the main camera for distances more than 10 ft away using:

- PowerCam Plus Primary cable shown on page 2-15
- Power Supply (part number 1465-52621-036)




Connecting Other Video Cameras

Refer to the release notes for a list of supported Pan/Tilt/Zoom (PTZ) cameras.

To connect a PTZ camera to a VSX 8000 system as the main camera:

You can connect a PTZ camera to a VSX 8000 using:


- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)
- S-Video to BNC adapter shown on page [2-11](#)



To connect a PTZ camera to a VSX 7000e system as the main camera:

You can connect a PTZ camera to a VSX 7000e using:


- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)



To connect a PTZ camera to a VSX 8000 system as the secondary camera:

You can connect a PTZ camera to a VSX 8000 as the secondary camera using:


- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)



To connect a PTZ camera to a VSX 7000e system as the secondary camera:


You can connect a PTZ camera to a VSX 7000e as the secondary camera using:

- PowerCam/VISCA Control cable shown on page [2-18](#)
- S-Video cable on page [2-9](#)

**To connect a PTZ camera to a VSX 7000s system as the secondary camera:**

You can connect a PTZ camera to a VSX 7000s as the secondary camera using:


- PowerCam/VISCA Control cable shown on page [2-21](#)
- S-Video cable on page [2-9](#)



To connect a PTZ camera to a VSX 7000 system as the secondary camera:

You can connect a PTZ camera to a VSX 7000 as the secondary camera using:

- PowerCam/VISCA Control cable shown on page 2-21
- S-Video cable on page 2-9



Integrating Audio and Content

For detailed information about connecting a VSX system to a Vortex mixer and SoundStation VTX 1000® conference phone, refer to the Vortex application notes in the Voice section of the Polycom web site at www.polycom.com.




Polycom strongly recommends using Polycom *InstantDesigner*™ to get started with your Polycom Vortex mixer integration. *InstantDesigner* resolves many common issues with connections and configuration settings.

If you have more line inputs, you may use one of the Mic/Line level inputs instead of a line level input, but you need to disable all processing on that Mic/Line input (AEC, AGC, NC, Automixer), disable Phantom Power, and set the input to line level versus the default of mic level.

Connecting a VSX 8000 to a Vortex Mixer and SoundStation VTX 1000

Connect the VSX 8000 to the Vortex mixer using:


- Vortex cable shown on page [2-24](#)
- VSX to VTX™ cable shown on page [2-27](#)



Connecting a VSX 7000e to a Vortex Mixer and SoundStation VTX 1000

Connect the VSX 7000e to the Vortex mixer using:

- Vortex cables shown on page [2-26](#)
- Serial cable shown on page [2-32](#)
- VSX to VTX cable shown on page [2-27](#)



Configuring the Vortex, SoundStation VTX 1000, and VSX System to Work Together

1. On the SoundStation VTX 1000:
 - a Make sure the phone has software version 1.50.009 or later.
 - b Select **Menu > Admin Setup > Phone System > Vortex Mode** to put the SoundStation VTX 1000 in Vortex mode.
 - c Select **Menu > Admin Setup > Audio Setup > AUX Input** and choose Other Input.
 - d Select **Menu > Admin Setup > Audio Setup > AUX Output** and choose Subwoofer.
2. Configure the Vortex to recognize the SoundStation VTX 1000 input/output, using Conference Composer™. Refer to the *Interfacing to the SoundStation VTX 1000 with Vortex Devices* application note in the Voice section of the Polycom web site at www.polycom.com.
3. Configure the Vortex to work correctly with the VSX system. Refer to the *Vortex/VSX 8000 Integration* application note in the Voice section of the Polycom web site at www.polycom.com.
4. On the VSX system, go to **System > Admin Settings > Audio > Next** and make these selections:
 - a Set the audio input:
 - VSX 8000: Set **Input Type** to **Line Input**.
 - VSX 6000, VSX 7000, and VSX 7000e: Set **Line Input** to **Audio Mixer**.
 - b Disable **Echo Canceller**.
 - c Disable the system microphones by deselecting **Enable Polycom Microphones**.
5. On the VSX system, go to **System > Admin Settings > General Settings > Serial Port** and set the **RS-232 Mode** to **Vortex Mixer**. Verify that the baud rate of the VSX system matches that of the Vortex.
6. Make sure the VSX system input to the Vortex is assigned to the appropriate AEC reference signal if the VSX system will be used in Mono mode (Standard AEC Operation). If using Polycom *InstantDesigner* to create the configuration settings for the Vortex, the reference will be set automatically.

Cables

This chapter includes information about cables that can be used with a VSX system. Please note that drawings and part numbers are provided for reference only. Compliance information is provided for the Restriction of certain Hazardous Substances Directive (RoHS).


Network Cables

LAN Cable



This cable connects a VSX system to the LAN. It has orange RJ-45 connectors on both ends and is used with all systems. The maximum approved length for this cable is 100 ft (30 m).

Length	Part Number	RoHS Compliant
12 ft (3.6 m)	2457-08343-001	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

ISDN Cable



This cable connects a VSX system to a BRI or PRI line. It has clear RJ-45 connectors on both ends and is used with all VSX systems that have ISDN capability. The maximum approved length for this cable is 50 ft (15 m).


Length	Part Number	RoHS Compliant
20 ft (6.6 m)	2457-08548-001	Yes



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

PRI Pin Assignments

The following illustration and table show the pin assignments for the PRI port on the VSX 8000.




Pin	Signal Name
1	Receive Ring
2	Receive Tip
3	No Connection
4	Transmit Ring
5	Transmit Tip
6	No Connection
7	No Connection
8	No Connection

Analog Telephone (POTS) Cable



This cable connects a VSX 7000e or VSX 8000 to an analog telephone line. It has pink RJ-11 connectors on both ends. The maximum approved length for this cable is 100 ft (30 m).

Length	Part Number	RoHS Compliant
12 ft (3.6 m)	2457-20071-001	Yes



WIRING IS "PIN TO PIN" 1-1, 2-2, ETC.




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

V.35/RS-449/RS-530 Serial Adapter



This adapter is used when connecting a VSX system to other third-party network equipment. It adapts the 68-pin interface to an industry standard 44-pin interface used by some network interface equipment. It is used with VSX systems that have a V.35/RS-449/RS-530 serial network interface card (NIC) installed.

Length	Part Number	RoHS Compliant
6 in (15.23 cm)	2457-21264-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

V.35 NIC Cable




This cable connects a VSX system to Ascend network equipment. It is used with the V.35/RS-449/RS-530 serial adapter on page 2-4 to connect to network equipment that has the HD-44 pin interface. It has HD-44 M connectors on both ends and is used with VSX systems that have a serial network interface card (NIC) installed.

Length	Part Number	RoHS Compliant
5 ft (1.65 m)	2457-10608-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

V.35 and RS-366 Serial Cable




This cable connects a VSX system to third-party network equipment. It is used with the V.35/RS-449/RS-530 serial adapter on page 2-4 to connect to network equipment that has a V.35/RS-366 interface. It is HD-44 M to "Y" Winchester 34M/RS-366 DB-25M and is used with VSX systems that have a serial network interface card (NIC) installed.

Length	Part Number	RoHS Compliant
5 ft (1.65 m)	2457-10609-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

RS-449 and RS-366 Serial Cable




This cable connects a VSX system to third-party network equipment. It is used with the V.35/RS-449/RS-530 serial adapter on page 2-4 to connect to network equipment that has an RS-449/RS-366 interface. It is HD-44 M to “Y” RS-449 DB-37M/RS-366 DB-25M and is used with VSX systems that have a serial network interface card (NIC) installed.

Length	Part Number	RoHS Compliant
5 ft (1.65 m)	2457-10610-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

RS-530 with RS-366 Serial Cable



This cable connects a VSX system to third-party network equipment. It is used with the V.35/RS-449/RS-530 serial adapter on page 2-4 to connect to network equipment that has an RS-530/RS-366 interface. It is HD-68M to "Y" DB-25M and is used with VSX systems that have a serial network interface card (NIC) installed.

Length	Part Number	RoHS Compliant
5 ft (1.65 m)	2457-21263-200	Yes



68 pin Signal Name	Signal Type	Notes (direction from V.35 module (DTE))	From card	Function	RS530-DB25	RS366-DB25
Shield			V.35RS449/RSS30			7,18,19#
12 Receive Data A	Differential	in	V.35RS449/RSS30	3		
11 Receive Data B	Differential	in	V.35RS449/RSS30	16		
10 Send Timing A	Differential	in	V.35RS449/RSS30	15		
9 Send Timing B	Differential	in	V.35RS449/RSS30	12		
29 Data Set Ready (DSR)	Single Ended	in	V.35			
28 Request To Send (RTS)	Single Ended	out	V.35			
27 Data Terminal Ready (DTR)	Single Ended	out	V.35			
34 Digit Present (DPR)	Single Ended	out	RS366	2		
24 Abandon Call/Reply (ACR)	Single Ended	in	RS366	3		
32 Call Request (CRQ)	Single Ended	out	RS366	4		
26 Present Next Digit (PND)	Single Ended	in	RS366	5		
21 Data Line Occupied (DLO)	Single Ended	in	RS366	22		
14 Receive Timing A	Differential	in	V.35RS449/RSS30	17		
13 Receive Timing B	Differential	in	V.35RS449/RSS30	9		
8 Terminal Timing A	Differential	out	V.35RS449/RSS30	24		
7 Terminal Timing B	Differential	out	V.35RS449/RSS30	11		
15 Request To Send (RTS) A	Differential	out	RS449/RS530	4		
16 Request To Send (RTS) B	Differential	out	RS449/RS530	19		
35* Receiver Common	Gnd		RS449			
20 BCD Dial Digit Bit 1 (NB1)	Single Ended	out	RS366	14		
19 BCD Dial Digit Bit 2 (NB2)	Single Ended	out	RS366	15		
23 BCD Dial Digit Bit 4 (NB4)	Single Ended	out	RS366	16		
25 BCD Dial Digit Bit 8 (NB8)	Single Ended	out	RS366	17		
2** Signal Ground	Gnd		V.35RS366		7,18,19	
6 Send Data A	Differential	out	V.35RS449/RSS30	2		
5 Send Data B	Differential	out	V.35RS449/RSS30	14		
reserved (Ascend select line)						
63 Clear To Send (CTS) A	Differential	in	RS449/RS530	5		
64 Clear To Send (CTS) B	Differential	in	RS449/RS530	13		
61 Data Mode (DM-DSR) A	Differential	in	RS449/RS530	6		
62 Data Mode (DM-DSR) B	Differential	in	RS449/RS530	22		
65 Receiver Ready (RR-DCCD) A	Differential	in	RS449/RS530	8		
66 Receiver Ready (RR-DCCD) B	Differential	in	RS449/RS530	10		
4** Send Common	Gnd		RS530	7		
33 Data Carrier Detect (DCD)	Single Ended	in	V.35			
18 Terminal Ready (TR-DTR) A	Differential	out	RS449/RS530	20		
17 Terminal Ready (TR-DTR) B	Differential	out	RS449/RS530	23		
3 V.35 Cable Connected		ground to indicate a V.35 cable is attached			7,18,19*	
1 RS449 Cable Connected		ground to indicate a RS449 cable is attached			7,18,19**	
22 Distant Station Connected (DSC)	Single Ended	in	RS366	13		
30 Clear To Send (CTS)	Single Ended	in	V.35			
31 Ring Indicate (RI) (Incoming Call)	Single Ended	in	V.35RS449			
reserved (Ascend select line)						
68 LOS A	Differential	out	RS530 crypto	18		
67 LOS B	Differential	out	RS530 crypto	21		

* For V.35, connect pin 3 of 68 pin connector to ground
 ** For RS449, connect pin 1 of 68 pin connector to ground
 # For RS530, connect pins 1 and 3 of 68 pin connector to ground
 ** Gnd pins are 2,4, 35-60



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.


Video and Camera Cables

S-Video Cable



These cables connect a VSX system to a monitor or camera. They have yellow 4-pin mini-DIN connectors on both ends and are used with all VSX systems except the VSX 3000. The VSX 8000 system may require the BNC to S-Video adapter on page 2-11. The maximum approved length for this cable is 200 ft (60 m).

Length	Part Number	RoHS Compliant
25 ft (7.6 m)	2457-08409-002	Yes
8 ft (2.4 m)	2457-08410-002	Yes
50 ft (15 m)	2457-09204-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

BNC to S-Video Cable



This cable connects S-Video devices to a VSX 8000. It is 4-pin male mini-DIN to dual BNC. The maximum approved length for this cable is 100 ft (30 m).

Length	Part Number	RoHS Compliant
6 ft (1.8 m)	2457-21489-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

BNC to S-Video Adapter



This adapter may be required when connecting standard S-Video cables to a VSX 8000. It is dual BNC to 4-pin female mini-DIN.

Length	Part Number	RoHS Compliant
1 ft (.3 m)	2457-21490-200	Yes




COLOR	P1	P2
WHITE	POS 3	POS 1
SPIRAL SHIELD	POS 1	SHELL
BLACK	POS 4	P3
SPIRAL SHIELD	POS 2	POS 1
		SHELL





Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

VCR/DVD Composite Cable



This cable connects a VSX system to a VCR or DVD player. It has triple RCA connectors on both ends and is used with all VSX systems. The VSX 8000 system requires the S-Video to RCA adapter on page 2-22. The maximum approved length for this cable is 50 ft (15 m).

Length	Part Number	RoHS Compliant
8 ft (2.6 m)	2457-08412-001	—




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

VGA Cable



This cable connects a VSX system to a VGA monitor. It has HD-15 high-density subminiature connectors on both ends and is used with all VSX systems except the VSX 3000. The VSX 6000 and VSX 7000 require a display adapter.

Length	Part Number	RoHS Compliant
30 ft (9 m)	2457-09211-001	—





Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Composite Video Cable




This cable connects a VSX system to a monitor or camera. It has single yellow RCA connectors on both ends and is used with VSX 6000, VSX 7000, and VSX 8000 systems. The VSX 8000 requires the S-Video to RCA adapter on page 2-22. The maximum approved length for this cable is 100 ft (30 m).

Length	Part Number	RoHS Compliant
25 ft (7.6 m)	2457-09207-001	—




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

PowerCam Plus Primary Cable



This cable connects a VSX 7000e or VSX 8000 to a Polycom PowerCam Plus camera. It has 4-pin mini-DIN and DB-15 connectors on both ends. The VSX 8000 system requires the S-Video to BNC adapter on page 2-11.

Length	Part Number	RoHS Compliant
9 ft 10 in (3 m)	1457-50105-002	Yes
30 ft (9 m)	1457-50105-230	Yes
50 ft (15 m)	1457-50105-250	Yes
100 ft (30 m)	1457-50105-300	Yes
150 ft (45 m)	1457-50105-350	Yes



Front View of Connector



P1 Connector		P2 Connector	
Pin #	Signal Name	Pin #	Signal Name
1	Arm Mic	1	Arm Mic
2	Left Mic	2	Left Mic
3	A GND	3	A GND
4	Cam ID Bit	4	Cam ID Bit
5	P GND	5	P GND
6	+12V	6	+12V
7	SW-RX/SN-TX	7	SW-RX/SN-TX
8	IR signal	8	IR signal
9	Center Mic	9	Center Mic
10	Right Mic	10	Right Mic
11	A GND	11	A GND
12	P GND	12	P GND
13	+12V	13	+12V
14	SW-TX/SN-RX	14	SW-TX/SN-RX
15	IR return	15	IR return
P3 4 Pin mini Din		P4 4 Pin mini Din	
1	A GND	1	A GND
2	A GND	2	A GND
3	Luma	3	Luma
4	Chroma	4	Chroma



Front View of Connector



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.


PowerCam Primary Camera Cable



This cable connects the VSX 7000e or VSX 8000 to a Polycom PowerCam camera. It is 8-pin mini-DIN to 4-pin mini-DIN and DB-15. The maximum approved length for this cable is 10 ft (3 m).

Length	Part Number	RoHS Compliant
9 ft 10 in (3 m)	1457-50338-002	Yes

For distances more than 10 ft (3 m) use the PowerCam breakout cable (2457-50526-200) on page 2-17, the PowerCam/VISCA control cable (1457-50527-201) on page 2-18, the S-Video cable on page 2-9, and a power supply (1465-52621-036).



P1 15 Pin D Connector			P2 8 Pin mini Din	
Pin #	Signal Name	Wire Type	Pin #	Signal Name
1-4	N/C			
5	PGND	22AWG wire	3	DGND
6	+12V	22 AWG wire	7	+12V
7	SW-RX/SN-TX	30 AWG wire	2	SW-RX/SN-TX
8	IR-SIGNAL	30 AWG wire	4	IR SIGNAL
9-11	N/C			
12	P GND	22 AWG wire	3	DGND
13	+12V	22 AWG wire	7	+12V
14	SW-TX/SN-RX	30 AWG wire	1	SW-TX/SN-RX
15	IR RETURN	30 AWG wire	3	DGND
SHIELD		DRAIN wire	SHIELD	
P3 4 Pin Mini Din				
1	RTN	Coax Shield	5	GVID
2	RTN	Coax Shield	5	GVID
3	Luma	Micro Coax	6	Luma
4	Chroma	Micro Coax	8	Chroma
SHIELD		DRAIN wire	SHIELD	



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

PowerCam Break-Out Cable




This cable connects S-Video and control cables and a power supply to a Polycom PowerCam camera. This combination is required when using the PowerCam as either the primary or the secondary camera when the camera is more than 10 ft away from the system. It is 8-pin mini-DIN to 3-way breakout block and is used with VSX 7000, VSX 7000s, VSX 7000e, and VSX 8000 systems.

For VSX 7000 or VSX 7000s systems, use this cable with the S-Video cable on page 2-9 and control cable (2457-21713-201 or 2457-21713-202) on page 2-21. For VSX 7000e or VSX 8000 systems, use with the S-Video cable on page 2-9, control cable (1457-50527-201) on page 2-18 for a primary camera, and control cable (1457-50527-201) on page 2-18 for a secondary camera.

A separate power supply is required (part number 1465-52621-036).

Length	Part Number	RoHS Compliant
6 ft (1.8 m)	2457-50526-200	Yes



CONNECTION TABLE				
Signal Name	P1	P2	J1	J2
TXD	---	1	---	5
RXD	---	2	---	3
DGND	1	3	---	6 & 4
IR-SIGNAL	---	4	---	7
CHROMAR	---	5	1	---
LUMAR	---	5	2	---
LUMA (Y)	---	6	3	---
+12V	2	7	---	---
CHROMA (C)	---	8	4	---
SHIELD	---	Shield	---	Shield



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

PowerCam/VISCA Control Cable (VSX 7000e or VSX 8000)


8-pin mini-DIN to DB-15



This cable connects VSX 7000e or VSX 8000 main camera inputs to a non-Polycom camera using a VISCA 8-pin DIN connector, or to a Polycom PowerCam break-out cable with a PowerCam camera.

The 8-pin mini-DIN to DB-15 cable is not qualified and should not be used. As stated below, this information is provided for your reference only and Polycom claims no responsibility or liability for the use of this information. Instead, Polycom recommends the 8-pin mini-DIN to DB-9 and the DB-15 to DB-9 adapter on [2-20](#), which is included with the VSX 8000 system.

Length	Part Number	RoHS Compliant
50 ft (15 m)	1457-50527-201	Yes



P1 15 Pin D Connector		P2 VISCA 8 Pin mini Din	
Pin #	Signal Name	Pin #	Signal Name
1-6, 9-11, 13	NC	1, 2, 8	NC
7	SW-RX/SN-TX	3	SW-RX/SN-TX
8	IR-SIGNAL	7	IR OUT
12	P-GND	4	GND
14	SW-TX/SN-RX	5	SW-TX/SN-RX
15	IR RETURN	6	GND
SHIELD		SHIELD	




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

8-pin mini-DIN to DB-9



This cable connects VSX 7000e or VSX 8000 serial port inputs to a non-Polycom camera using a VISCA 8-pin DIN connector, or to a Polycom PowerCam break-out cable with a PowerCam camera. It is 8-pin mini-DIN to DB-9. RTS/CTS and IR are not supported on this cable.

Length	Part Number	RoHS Compliant
50 ft (15 m)	2457-10029-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

RS-232 Adapter



This adapter is included with the VSX 7000e and VSX 8000 and is used to convert the primary camera control input port for connecting the control port of non-Polycom cameras to the system as the main camera. This does not carry any IR signals to the system. It is DB-15 to DB-9.

Length	Part Number	RoHS Compliant
—	2457-21930-002	Yes



CONNECTION TABLE		
9-PIN	15-PIN	SIGNAL
2	7	RXD/TXD
3	14	TXD/RXD
5	12	GND
ALL OTHERS	N/C	N/A




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

PowerCam/VISCA Control Cable (VSX 7000 or VSX 7000s)



This cable connects a VSX 7000 or VSX 7000s to a camera VISCA port, or to the PowerCam Break-Out Cable on page 2-17. It has 8-pin mini-DIN male connectors on both ends. An S-Video cable is also required. IR from the camera is not supported on this cable.

Length	Part Number	RoHS Compliant
25 ft (7.6 m)	2457-21713-201	Yes
50 ft (15 m)	2457-21713-202	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

S-Video to RCA Adapter



This adapter is used when connecting a standard composite video cable (or the video jack on a VCR cable) into an S-Video connector on a VSX 8000. It is yellow RCA to 4-pin mini-DIN.

Length	Part Number	RoHS Compliant
1.5 in	1517-08822-002	Yes



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.


Audio Cables

Audio Cable




This cable connects a VSX system to an external audio system. It has dual RCA connectors (red/white) on both ends and is used with all systems except the VSX 3000. The maximum approved length for this cable is 100 ft (30 m).

Length	Part Number	RoHS Compliant
25 ft (7.6 m)	2457-09212-002	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Vortex Cable (VSX 8000)



This cable connects a VSX 8000 to a Polycom Vortex mixer. It has four mini-Phoenix connectors and one DB-9 connector on each end.

Length	Part Number	RoHS Compliant
6 ft (1.8 m)	2457-21978-200	Yes




PIN #	Signal
1	Signal +
2	Signal - (return)
3	Shield/drain wire/ground

WIRING CHART			
FROM	TO	WIRE TYPE	WIRE USE
P1-2	J1-2	A	SIGNAL
P1-3	J1-3		SIGNAL
P1-5	J1-5		SIGNAL
P1-7	J1-7		SIGNAL
P1-8	J1-8		SIGNAL
P1-SHELL	J1-SHELL		SHIELD
PINS 1, 4, 6, 9 ARE N/C			N/A
P2-1	P6-1	B	SIGNAL
P2-2	P6-2		SIGNAL
P2-3	P6-3		SHIELD (DRAIN WIRE)
P3-1	P7-1	B	SIGNAL
P3-2	P7-2		SIGNAL
P3-3	P7-3		SHIELD (DRAIN WIRE)
P4-1	P8-1	B	SIGNAL
P4-2	P8-2		SIGNAL
P4-3	P8-3		SHIELD (DRAIN WIRE)
P5-1	P9-1	B	SIGNAL
P5-2	P9-2		SIGNAL
P5-3	P9-3		SHIELD (DRAIN WIRE)



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.


Balanced Audio Connector



This connector connects audio input and output to the VSX 8000. It is a 3-pin Phoenix connector.

Length	Part Number	RoHS Compliant
—	1515-20881-003 Phoenix part number: 1939921	Yes

Top View



PIN #	
1	Signal +
2	Signal - (return)
3	Shield/drain wire/ground




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Vortex Cable (VSX 6000, VSX 6000A, VSX 7000, VSX 7000s, or VSX 7000e)




These cables connect VSX systems with RCA audio outputs to a Polycom Vortex mixer. They are mini-Phoenix to RCA and are used with the VSX 6000, VSX 6000A, VSX 7000, VSX 7000s, and VSX 7000e systems.

Length	Part Number	RoHS Compliant
12 ft (3.6 m)	2457-80100-003 (white RCA)	Yes
12 ft (3.6 m)	2457-80100-004 (black RCA)	Yes



A	B		
PIN #	PIN #	COLOR CODE	AWG SIZE
1	1	RED	20
2	2	BLACK	20
	3	BRAID SHIELD	





Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

VSX to VTX Cable



This cable connects a VSX system to the Polycom SoundStation VTX 1000 conference phone. It is black offset RJ-11 to RJ-45 and is used with all VSX systems except the VSX 3000. The maximum approved length for this cable is 50 ft (15 m).

Length	Part Number	RoHS Compliant
30 ft (9 m)	2457-21626-001	Yes
50 ft (15 m)	2457-21626-050	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Visual Concert to VTX Cable



This cable connects the Polycom SoundStation VTX 1000 conference phone to a Polycom Visual Concert™ that is already connected to a VSX system. It is black offset RJ-11 to RJ-45 and is used with VSX 5000, VSX 6000, VSX 6000A, VSX 7000, and VSX 7000s systems. The maximum approved length for this cable is 30 ft (9 m).

Length	Part Number	RoHS Compliant
10 ft (3 m)	2457-21624-001	Yes
3 ft (0.9 m)	2457-21625-001	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Subwoofer Volume Attenuator



This attenuator plugs into the Volume Control RJ-11 port on the subwoofer that comes with the Polycom stereo speaker kit. The attenuator is required for proper operation of the acoustic echo cancellation. It has an RJ-11 connector.

Length	Part Number	RoHS Compliant
3.5 in (9 cm)	1457-52415-001	—



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Serial Cables


RS-232 Cable (VSX 5000, VSX 6000, VSX 6000A, VSX 7000, or VSX 7000s)



This cable connects a VSX system to an RS-232 device. It is DB-9 to 8-pin mini-DIN and is used with VSX 5000, VSX 6000, VSX 6000A, VSX 7000, and VSX 7000s systems. The maximum approved length for this cable is 100 ft (30 m).

Use 2457-21714-200 on page 2-34 instead, when connecting to a modem.


Length	Part Number	RoHS Compliant
10 ft (3 m)	2457-09156-001	—



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

The 8-pin mini-DIN female connector on the VSX system has the following connections.

Pin	Signal
1	Not used
2	Tx (output)
3	Rx (input)
4	DSR (input)
5	GND
6	DTR (output)
7	RTS (output)
8	CTS (input)
Shield	GND



Straight-Through Serial Cable (VSX 7000e or VSX 8000)




This cable connects a VSX 7000e or VSX 8000 to a serial device. It has a DB-9 connector on each end. The maximum approved length for this cable is 100 ft (30 m).



Polycom does not recommend using this straight-through serial cable for RS-232 communication from a computer, Crestron system, or AMX device. Instead, for RS-232 communication, Polycom recommends using a cross-over cable with pin 2 wired to pin 3, pin 3 wired to pin 2, and pin 5 wired to pin 5. The other pins are not used.

If you choose to use this straight-through serial cable for RS-232 communication from a computer or Crestron system, the null modem adapter 1517-61577-001 on page 2-35 is required. However, the null modem adapter does not work for RS-232 communication from AMX devices and will cause problems if you try to use it.

Length	Part Number	RoHS Compliant
25 ft (7.6 m)	2457-09172-001	—



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

The DB-9 male connector on the VSX system has the following connections.

Pin	Signal
1	Not used
2	Rx
3	Tx
4	DTR (tied to pin 6, DSR)
5	GND
6	DSR (tied to pin 4, DTR)
7	RTS (tied to pin 8, CTS)
8	CTS (tied to pin 7, RTS)
9	Not used


Most devices which connect to the serial port to control the VSX system via the API only require pins 2, 3, and 5. For more information and to verify the proper cabling, refer to the documentation for your control system.

Null Modem Cable



This cable connects a VSX system to a null modem. It is 8-pin mini-DIN to DB-9 and is used with VSX 5000, VSX 6000, VSX 6000A, VSX 7000, and VSX 7000s systems.

Length	Part Number	RoHS Compliant
25 ft (7.6 m)	2457-21714-200	Yes



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Null Modem Adapter




This adapter is used when connecting a VSX 7000e or VSX 8000 to a serial device that transmits on pin 3 such as Crestron Pro2 processor. It is a male to female DB-9 adapter plug. This connection may require the straight-through serial cable (2457-09172-001) on page [2-32](#).



Do not use this adapter with an AMX device. AMX systems support both RS-232 and RS-422. Therefore, for RS-232 support, use a null modem cross-over cable that carries only pins 2, 3, and 5, with pins 2 and 3 crossed.

Length	Part Number	RoHS Compliant
—	1517-61577-001	Yes

DB9F	DB9M
PIN 1&6	PIN 4
PIN 2	PIN 3
PIN 3	PIN 2
PIN 4	PIN 1&6
PIN 5	PIN 5
PIN 7	PIN 8
PIN 8	PIN 7
PIN 9	N/C



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.


Content Sharing Cables

Visual Concert VSX Cable



This cable connects a Polycom Visual Concert VSX to a computer. It has RJ-45, HD-15, and stereo jack connectors on both ends and is used with VSX 5000, VSX 6000, VSX 6000A, VSX 7000, and VSX 7000s systems.

Length	Part Number	RoHS Compliant
6 ft (1.8 m)	2457-10757-200	Yes




Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

ImageShare II to Computer Cable



This cable connects a Polycom ImageShare™ II to a computer. It has HD-15 and stereo jack connectors on both ends and is used with VSX 7000e and VSX 8000 systems.

Length	Part Number	RoHS Compliant
3 ft (0.9 m)	185-0020-02	Yes



WIRE TABLE				
HD15 -M	SIGNAL NAME	HD15 -F	WIRE TYPE	WIRE COLOR
1	RED	1	A	RED CENTER
2	GREEN	2	A	GREEN CENTER
3	BLUE	3	A	BLUE CENTER
4	TOT -DETECT	4	C	ORANGE
5	GROUND	5	C	GREEN
6	RED -SHIELD	6	A	RED -SHIELD
7	GREEN -SHIELD	7	A	GREEN -SHIELD
8	BLUE -SHIELD	8	A	BLUE -SHIELD
9	N/C	9	N/C	N/C
10	SYNC -RETURN	10	B	BLACK -WHITE
11	N/C	11	N/C	N/C
12	SDA	12	C	BROWN
13	H-SYNC	13	B	BLUE
14	V-SYNC	14	B	RED
15	SCL	15	C	YELLOW
3.5mm PLUG				
TIP	LEFT -AUDIO	TIP	A	BLACK
RING	RIGHT -AUDIO	RING	A	WHITE
SLEEVE	OUTER SHIELD	SLEEVE	A	BLACK SHIELD
SLEEVE	OUTER SHIELD	SLEEVE	A	WHITE SHIELD



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.


IR Connector



This connector connects the IR sensor input on a VSX 8000 to an external IR receiver, such as Xantech models 780-80, 780-90, 480-00, and 490-90. It is a 3-pin Phoenix connector.

Length	Part Number	RoHS Compliant
—	1515-21516-003 Phoenix part number: 1952270	Yes

Top View



PIN #	
1	+12 V
2	Ground
3	IR signal



Drawings and part numbers are provided for reference only. Polycom claims no responsibility or liability for the quality, performance, or reliability of cables based on these reference drawings, other than cables provided by Polycom. Contact your Polycom distributor or Polycom Custom/Vertical Products to order cables that meet the appropriate manufacturing tolerances, quality, and performance parameters for your application.

Using the API

The Application Programming Interface (API) is a set of commands for advanced users who want to automate a VSX system. You can use the API by connecting a control system or computer RS-232 serial port to the VSX system. Or, you can use Telnet over the LAN to use the API.

Using the API with an RS-232 Interface

If you use an RS-232 interface to send API commands, you must connect and configure the control system or computer and the VSX system for serial communication.

Configuring the RS-232 Interface

If you use the API with a serial connection, make sure that the RS-232 interfaces of the VSX system and your computer are configured appropriately.

To access the RS-232 settings on your system, select **System > Admin Settings > General Settings > Serial Port**.

Configure the Baud Rate and RS-232 Mode options as follows:

Option	Configure this way on your computer	Configure this way on the VSX system
Baud Rate	Must be the same rate for both devices. Available rates are: 9600 14400 19200 38400 57600 115200	
RS-232 Mode	—	Control

The RS-232 port on the VSX system supports two modes: Control and Pass-Thru.

In Control Mode, a device (for example, a computer) connected to the RS-232 port can control the system using the API.


In Pass-Thru Mode, the operational modes of both devices' RS-232 ports depend on the port configuration of each device.

Starting an API Session via an RS-232 Interface


After you have verified that the VSX system and your computer are both configured appropriately, set up both devices as follows:

1. Power off the computer and the VSX system.
2. Use an RS-232 cable to connect the control system or computer RS-232 port to an RS-232 port on the VSX system as shown in the following illustration. This connection may require the null modem adapter 1517-61577-001 on page 2-35.


VSX 6000 or VSX 7000



VSX 6000A or VSX 7000s



VSX 7000e or VSX 8000



3. Power on the computer and the VSX system.
4. From the computer, start a serial session using HyperTerminal or another appropriate utility.

Using the API with a LAN Connection

If you have a computer connected to the LAN, you can send API commands to the VSX system via Telnet port 24.

1. On the computer, open a command line interface.
2. Start a Telnet session using the VSX system IP address and port number — for example, `telnet 10.11.12.13 24`.

If the VSX system has Security Mode enabled, you must use a utility that supports Transport Layer Security (TLS), and you must provide the remote access password.

Using the API Controller Code

In cooperation with the leading touch panel controller manufacturers, Polycom Video Division is proud to offer its own version of controller code designed to run on Crestron and AMX systems. This independent code base was developed specifically to address issues of code compatibility with video system software releases. It provides a fully executable controller program but also serves as a guideline for ongoing development using Polycom preferred methodology and commands.

Companion documents are also available to further explain how to interface your controller with Polycom video systems and utilize the API efficiently.

System Commands

This chapter describes the API commands for software version 8.7.

For an alphabetical list of all the commands, refer to the table of contents for this document.

For a list of all the commands by category, refer to Appendix B, [Categorical List of API Commands](#).

For a list of commands that are new and newly deprecated in this version, refer to Appendix D, [API Changes in This Version](#).

About the API Commands

Syntax Conventions

The following conventions are used for the API command descriptions in this chapter. All of the commands are case sensitive.

Convention	Meaning
<param1 param2 param3>	Multiple valid parameters are enclosed in angle brackets and separated by the pipe (" ") character. Example: <code>allowdialing <yes no get></code> shows that the <code>allowdialing</code> command must be followed by one of the parameters listed.
[param] ["param"]	Optional parameters are enclosed in square brackets. Quotation marks indicate strings to be supplied by the user. Example: <code>teleareacode set ["telephone_area_code"]</code> shows that you can supply a value for the area code, or omit it and let the default value apply. You do not need to enclose the actual value in quotes unless it contains a space.
{a..z}	A range of possible alphanumeric values is enclosed in braces. Example: <code>abk letter {a..z}</code> shows that the <code>abk</code> command can be used to return address book entries that begin with an alphanumeric character in the range specified. Example: <code>camera near {1..4}</code> shows that the <code>camera</code> command can be used to select camera 1, 2, 3, or 4 at the near site.
"x"	Quotation marks indicate strings to be supplied by the user. You do not need to enclose the value in quotes unless it contains a space.

Although the API command parser may accept the minimum number of characters in a command which makes it unique, you should always use the full command string.

Availability of Commands

The availability of API commands depends on the type of system and optional equipment installed or connected. If a particular command is not supported on the system, the command returns feedback such as "error: this command is not supported on this model" or "command is not available in current system configuration".

Deprecated commands are included for backward compatibility only and are not recommended for use with this version. Suitable replacements are noted for each deprecated command.

!

Executes a previously used command from the history list, starting with a specific number or letter.

Syntax

```
!"string"  
!{1..64}
```

Parameter	Description
"string"	Specifies the most recent command from the history list that begins with this string.
{1..64}	Specifies the Nth command in the history list, where N is 1 through 64.

Feedback Examples

Assume the following command history.

- gatewaynumber set 123456789
returns
gatewaynumber 123456789
- hangup video
returns
hanging up video call
- history
returns
1 gatewaynumber set 123456789
2 hangup video
- h323name get
returns
h323name testip

In this case, each of the following `!<letter or number>` commands executes the command and prints its output from the history list, as follows.

- !1
returns
gatewaynumber set 123456789
gatewaynumber 123456789
- !2
returns
hangup video
hanging up video call

- !h
returns
h323name get
h323name testip
- history
returns
1 gatewaynumber set 123456789
2 hangup video
3 h323name get
4 gatewaynumber set 123456789
5 hangup video
6 h323name get

See Also

For information about the history list, refer to the [history](#) command on page 4-140.

abk

Returns local directory (address book) entries.

Syntax

```
abk all
abk batch {0..59}
abk batch search "pattern" "count"
abk batch define "start_no" "stop_no"
abk letter {a..z}
abk range "start_no" "stop_no"
abk refresh
```

Parameter	Description
all	Returns all the records in the local directory.
batch	Returns a batch of 10 local directory entries. Requires a batch number, which must be an integer in the range {0..59}. Batches should be requested sequentially to ensure receiving a complete list of entries.
search	Specifies a batch search.
"pattern"	Specifies pattern to match for the batch search.
"count"	Specifies the number of entries to list that match the pattern.
define	Returns a batch of entries in the range defined by "start_no" to "stop_no." Deprecated. Polycom recommends using <code>abk range</code> instead of this command.
"start_no"	Specifies the beginning of the range of entries to return.
"stop_no"	Specifies the end of the range of entries to return.
letter	Returns entries beginning with the letter specified from the range {a..z}. Requires one or two alphanumeric characters. Valid characters are: - _ / ; @ , . \ 0 through 9 a through z
range	Returns local directory entries numbered "start_no" through "stop_no". Requires two integers.
refresh	Refreshes the local directory entries cache.

Feedback Examples

- abk range 6 9
returns
abk 6. 192.168.1.107 spd:128 num:192.168.1.107
abk 7. Polycom Austin Stereo spd:384 num:1.512.6977918
abk 7. Polycom Austin Stereo spd:384 num:stereo.polycom.com
abk 8. Polycom HDX Demo spd:384 num:1.700.5551212
abk 9. Polycom VSX Demo spd:2x64 num:1.700.5552323
- abk letter p
returns
abk 0. Polycom HDX Demo spd:384 num:1.700.5551212
abk 1. Polycom VSX Demo spd:2x64 num:1.700.5552323
- abk batch 0
returns
abk 0. 192.168.1.101 spd:128 num:192.168.1.101
abk 1. 192.168.1.102 spd:128 num:192.168.1.102
abk 2. 192.168.1.103 spd:128 num:192.168.1.103
abk 3. 192.168.1.104 spd:128 num:192.168.1.104
abk 4. 192.168.1.105 spd:128 num:192.168.1.105
abk 5. 192.168.1.106 spd:128 num:192.168.1.106
abk 6. 192.168.1.107 spd:128 num:192.168.1.107
abk 7. Polycom Austin Stereo spd:384 num:1.512.6977918
abk 7. Polycom Austin Stereo spd:384 num:stereo.polycom.com
abk 8. Polycom HDX Demo spd:384 num:1.700.5551212
abk 9. Polycom VSX Demo spd:2x64 num:1.700.5552323

Note: Entries with multiple addresses (for example, IP address and ISDN number) return each address type on separate lines with the same record number.

Comments

abk entries are entries stored on the system. gabk entries are entries stored on the GDS. In the user interface, the address book and global address book features are referred to as *directory* and *global directory*.

User interface screen location: **Directory** > **Search** button or alphabet tabs

addressdisplayedingab

Specifies whether to make the system address public or private in the global directory.

Syntax

```
addressdisplayedingab get
addressdisplayedingab private
addressdisplayedingab public
```

Parameter	Description
get	Returns the current setting.
private	Specifies not to display the system address in the global directory.
public	Displays the system address in the global directory.

Feedback Examples

- addressdisplayedingab private
returns
addressdisplayedingab private
- addressdisplayedingab public
returns
addressdisplayedingab public
- addressdisplayedingab get
returns
addressdisplayedingab public

Comments

User interface screen location: **System > Admin Settings > Global Services > Directory Servers: Display Name in Global Directory**

adminpassword

Sets or gets the remote access password. This command is not supported on the serial port.

Syntax

```
adminpassword get
adminpassword set ["password"]
```

Parameter	Description
get	Returns the current remote access password.
set	Sets the password used for remote management of the system if followed by the <code>password</code> parameter. To erase the current setting, omit the <code>password</code> parameter.
"password"	User-defined password. Valid characters are: a through z (lower and uppercase), -, _, @, /, ;, ,, ., \, 0 through 9. The password cannot include spaces.

Feedback Examples

- ```
adminpassword set Mypasswd
returns
adminpassword Mypasswd
```
- ```
adminpassword set "Mypasswd"
returns
adminpassword Mypasswd
```
- ```
adminpassword set "My passwd"
returns
error: command has illegal parameters
```

### Comments

User interface screen location: **System > Admin Settings > General Settings > Security: Remote Access**

## advnetstats

Gets advanced network statistics for a call connection.

### Syntax

```
advnetstats [{0..n}]
```

| Parameter | Description                                                                                                                                                                                                                                                                                                                                                                             |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| {0..n}    | Specifies a connection in a multipoint call, where <i>n</i> is the maximum number of connections supported by the system. 0 is call #1, 1 is call #2, 2 is call #3, and so on. Select a number from this range to specify a remote site call for which you want to obtain advanced network statistics.<br><br>Omit this parameter when retrieving statistics for a point-to-point call. |

### Feedback Examples

- `advnetstats 1`  
returns  

```
call:1 tar:24k rar:24k tvr:64.3k rvr:104k
tvru:63.8k rvru:114.6k tvfr:15.0 rvfr:15.0 vfe ---
tapl:66 rapl:0 taj:46mS raj:40mS tvpl:122 rvpl:0
tvj:21mS rvj:60mS dc:--- rsid:Polycom_4.2
```
- Returned parameters are:  

```
tar=Transmit audio rate
rar=Receive audio rate
tvr=Transmit video rate
rvr=Receive video rate
tvru=Transmit video rate used
rvru=Receive video rate used
tvfr=Transmit video frame rate
rvfr=Receive video frame rate
vfe=Video FEC errors
tapl=Transmit audio packet loss (H.323 calls only)
tlsdp=Transmit LSD protocol (H.320 calls only)
rapl=Receive audio packet loss (H.323 calls only)
rldsdp=Receive LSD protocol (H.320 calls only)
taj=Transmit audio jitter (h.323 calls only)
tlsdr=Transmit LSD rate (H.320 calls only)
raj=Receive audio jitter (H.323 calls only)
rlds=Receive LSD rate (H.320 calls only)
tvpl=Transmit video packet loss (H.323 calls only)
tmlpp=Transmit MLP protocol (H.320 calls only)
rvpl=Receive video packet loss (H.323 calls only)
rmlpp=Receive MLP protocol (H.320 calls only)
tvj=Transmit video jitter (H.323 calls only)
```

tmlpr=Transmit MLP rate (H.320 calls only)  
rvj=Receive video jitter (H.323 calls only)  
rmlpr=Receive MLP rate (H.320 calls only)  
dc=Data conference  
rsid=Remote system id

**Comments**

User interface screen location: **System > Diagnostics > Call Statistics**

# alertusertone

Sets or gets the tone used for user alerts.

## Syntax

```
alertusertone <get|1|2|3|4>
```

| Parameter | Description                                    |
|-----------|------------------------------------------------|
| get       | Returns the current setting.                   |
| 1 2 3 4   | Sets the user alert to the corresponding tone. |

## Feedback Examples

- alertusertone 1  
returns  
alertusertone 1
- alertusertone get  
returns  
alertusertone 1

## Comments

User interface screen location: **System > Admin Settings > Audio: User Alert Tones**

## alertvideotone

Sets the tone used for incoming video calls.

### Syntax

alertvideotone <get|1|2|3|4|5|6|7|8|9|10>

| Parameter            | Description                                              |
|----------------------|----------------------------------------------------------|
| get                  | Returns the current setting.                             |
| 1 2 3 4 5 6 7 8 9 10 | Sets the incoming video alert to the corresponding tone. |

### Feedback Examples

- alertvideotone 1  
returns  
alertvideotone 1
- alertvideotone get  
returns  
alertvideotone 1

### Comments

User interface screen location: **System > Admin Settings > Audio: Incoming Video Call**

# all register

Registers for most commonly-used user registration events.

## Syntax

```
all register
```

## Feedback Examples

- all register  
returns  
callstate registered  
camera registered  
chaircontrol registered  
linestate registered  
mute registered  
pip registered  
popupinfo registered  
preset registered  
screen registered  
vcbUTTON registered  
volume registered  
sleep registered

## Comments

Registers changes to any of the following types of parameters:

- Current near-site or far-site source
- State of privacy
- Current volume level
- Active camera presets
- Status of point-to-point or multipoint calls
- Status of physical ISDN/IP connection to codec
- PIP state
- Visual Concert state
- Chair control
- System information
- Gatekeeper status

This command is particularly useful when two different control systems are being used simultaneously, such as the web and API commands. The system maintains the registration changes through restarts.

To register for events not included in this feedback, refer to the specific registration command.

## See Also

The [registerall](#) command on page 4-222 is an alias for this command.

To unregister user feedback, use the [all unregister](#) command on page 4-14 or the [unregisterall](#) command on page 4-281.

## all unregister

Simultaneously unregisters all registered user feedback so that the API no longer reports changes to the parameters.

### Syntax

```
all unregister
```

### Feedback Examples

- all register  
returns  
callstate unregistered  
camera unregistered  
linestate unregistered  
mute unregistered  
pip unregistered  
popupinfo unregistered  
preset unregistered  
screen unregistered  
vcbUTTON unregistered  
volume unregistered  
sleep unregistered  
configchange unregistered

### Comments

The following types of parameters are unregistered:

- Current near-site or far-site source
- State of privacy
- Current volume level
- Active camera presets
- Status of point-to-point or multipoint calls
- Status of physical ISDN/IP connection to codec
- PIP state
- Visual Concert state
- Chair control
- System information
- Gatekeeper status

### See Also

The [unregisterall](#) command on page 4-281 is an alias for this command. To register for user feedback, use the [all register](#) command on page 4-13 or the [registerall](#) command on page 4-222.



# allowabkchanges

Sets or gets the Allow Directory Changes setting.

## Syntax

```
allowabkchanges <get|yes|no>
```

| Parameter | Description                                   |
|-----------|-----------------------------------------------|
| get       | Returns the current setting.                  |
| yes       | Enables the Allow Directory Changes setting.  |
| no        | Disables the Allow Directory Changes setting. |

## Feedback Examples

- `allowabkchanges no`  
**returns**  
`allowabkchanges no`
- `allowabkchanges yes`  
**returns**  
`allowabkchanges yes`
- `allowabkchanges get`  
**returns**  
`allowabkchanges yes`

## Comments

If this option is enabled, the user has access to the **New**, **Edit**, and **Delete** operations in the directory.

User interface screen location: **System > Admin Settings > General Settings > System Settings > Directory: Allow Directory Changes**

## allowcamerapresetssetup

Sets or gets whether users are allowed to change camera presets.

### Syntax

allowcamerapresetssetup <get|yes|no>

| Parameter | Description                                  |
|-----------|----------------------------------------------|
| get       | Returns the current setting.                 |
| yes       | Allows users to change camera presets.       |
| no        | Prevents users from changing camera presets. |

### Feedback Examples

- allowcamerapresetssetup no  
returns  
allowcamerapresetssetup no
- allowcamerapresetssetup yes  
returns  
allowcamerapresetssetup yes
- allowcamerapresetssetup get  
returns  
allowcamerapresetssetup yes

# allowdialing

Sets or gets the ability to dial out from the system.

## Syntax

```
allowdialing <get|yes|no>
```

| Parameter | Description                                                 |
|-----------|-------------------------------------------------------------|
| get       | Returns the current setting.                                |
| yes       | Allows users to place calls.                                |
| no        | Disables dialing so that the system can only receive calls. |

## Feedback Examples

- ```
allowdialing no
returns
allowdialing no
```
- ```
allowdialing yes
returns
allowdialing yes
```
- ```
allowdialing get
returns
allowdialing yes
```

Comments

`allowdialing no` removes the dialing field and marquee text from the home screen.

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: Dialing Display**

See Also

The ability to place calls is also controlled by the [dialingdisplay](#) command on page 4-71 and [dialingentryfield](#) command on page 4-72.

allowmixedcalls

Sets or gets the ability to place and receive mixed protocol multipoint calls (IP and ISDN). It allows the administrator to disable this ability for security reasons.

Syntax

```
allowmixedcalls <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables mixed IP and ISDN calls.
no	Disables mixed IP and ISDN calls.

Feedback Examples

- `allowmixedcalls no`
returns
`allowmixedcalls no`
- `allowmixedcalls yes`
returns
`allowmixedcalls yes`
- `allowmixedcalls get`
returns
`allowmixedcalls yes`

Comments

This option is only visible on screen if ISDN and IP have both been enabled on the Call Preference screen.

User interface screen location: **System > Admin Settings > General Settings > System Settings > Call Settings: Allow Mixed IP and ISDN Calls**

allowstreaming

Adds or removes **Streaming** on the Utilities screen, which allows users to start streaming calls.

Syntax

```
allowstreaming <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Allows users to stream calls.
no	Does not allow users to stream calls.

Feedback Examples

- allowstreaming no
returns
allowstreaming no
- allowstreaming yes
returns
allowstreaming yes
- allowstreaming get
returns
allowstreaming yes

Comments

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Allow Streaming**

allowusersetup

Adds or removes the **User Settings** icon on the System screen, which allows users to access the User Settings screen.

Syntax

```
allowusersetup <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the User Settings icon.
no	Disables the User Settings icon.

Feedback Examples

- allowusersetup no
returns
allowusersetup no
- allowusersetup yes
returns
allowusersetup yes
- allowusersetup get
returns
allowusersetup yes

Comments

This command is useful to prevent users from changing the user settings.
User interface screen location: **System > Admin Settings > General Settings > Security (page 2): Allow Access to User Settings**

answer

Answers incoming video or analog phone calls.

Syntax

```
answer <video|phone>
```

Parameter	Description
video	Answers incoming video calls when Auto Answer Point to Point or Auto Answer Multipoint is set to No.
phone	Answers incoming analog phone calls.

Feedback Examples

- `answer video`
returns
`answer incoming video call failed`
- `answer video`
returns
`answer incoming video call passed`
- `answer phone`
returns
`answer incoming phone call failed`
- `answer phone`
returns
`answer incoming phone call passed`

areacode

Sets or gets the area code for all ISDN BRI lines. This command is only applicable if you have a BRI network interface connected to your system.

Syntax

```
areacode get
areacode set "areacode"
```

Parameter	Description
get	Returns the area code information.
set	Sets the ISDN BRI area code when followed by the area code parameter. To erase the current setting, omit "areacode".
"areacode"	Area code to use for all BRI lines.

Feedback Examples

- areacode set 212
returns
areacode 212
- areacode get
returns
areacode 212

Comments

This area code is associated with the area where the system is used.

User interface screen location: **System > Admin Settings > Network > ISDN** (page 2): **Area Code** (for Line 1, Line 2, Line 3, and Line 4)

audiometer

Queries and displays levels and peak of audio inputs, 10 times per second.

Syntax

audiometer

```
<micpod|farin|linein|lineinred|lineinwhite|balancedin|visualconcert|
vcr|aux|off>
```

Parameter	Description
micpod	Measures the audio strength from microphone(s).
farin	Measures the strength of far-site audio.
linein	Measures the audio strength of any device connection to the white (left) audio line.
lineinred	Measures the audio strength of any device connection to the red (right) audio line.
lineinwhite	Measures the audio strength of any device connection to the white (left) audio line.
balancedin	Measures the audio strength of any device connection to the balanced in connectors on a VSX 8000.
visualconcert	Measures the strength of Visual Concert VSX audio.
vcr	Measures the strength of VCR audio.
aux	Measures the strength of aux audio.
off	Turns off audiometer output.

Feedback Examples

- audiometer farin
returns
audiometer farin level:-20 peak:-20
audiometer farin level:-19 peak:-19
audiometer farin level:-2 peak:-2
audiometer farin level:-4 peak:-4
audiometer farin level:-6 peak:-6
audiometer farin level:-8 peak:-8
audiometer farin level:1 peak:1
and so on until you enter
audiometer off

Comments

User interface screen location: **System > Diagnostics > Audio > Audio Meter**

audiotransmitlevel

Sets or gets the audio volume transmitted to the far site, or notification of transmit level changes. This command is used when a control system needs to increase the audio gain level of DTMF tones being sent to a gateway.

Syntax

```
audiotransmitlevel <get|up|down|register|unregister>
audiotransmitlevel set {-20..30}
```

Parameter	Description
get	Returns the current setting.
up	Sets the volume 1 decibel higher than the current setting.
down	Sets the volume 1 decibel lower than the current setting.
register	Registers to receive notification when audio transmit level changes.
unregister	Unregisters to receive notification when audio transmit level changes.
set	Sets the volume to the specified dB level. Valid values are: {-20..30}.

Feedback Examples

- audiotransmitlevel set 2
returns
audiotransmitlevel 2
- audiotransmitlevel get
returns
audiotransmitlevel 2
- audiotransmitlevel up
returns
audiotransmitlevel 3
- audiotransmitlevel down
returns
audiotransmitlevel 2
- audiotransmitlevel register
returns
audiotransmitlevel registered
- audiotransmitlevel unregister
returns
audiotransmitlevel unregistered

autoanswer

Sets or gets the Auto Answer Point to Point mode, which determines how the system will handle an incoming call in a point-to-point video conference.

Syntax

```
autoanswer <get|yes|no|donotdisturb>
```

Parameter	Description
yes	Allows any incoming video call to be connected automatically. This is the default setting.
no	Prompts the user to answer incoming video calls.
donotdisturb	Notifies the user of incoming calls, but does not connect the call. The site that placed the call receives a Far Site Busy (H.320) or Call Rejected (H.323) code.
get	Returns the current setting.

Feedback Examples

- autoanswer yes
returns
autoanswer yes
- autoanswer no
returns
autoanswer no
- autoanswer get
returns
autoanswer no
- autoanswer donotdisturb
returns
autoanswer donotdisturb

Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Call Settings: Auto Answer Point to Point**

If autoanswer is set to no or donotdisturb, you must rely on API session notifications to answer inbound calls.

autoshowcontent

Specifies whether to send content automatically when the computer is connected to the Visual Concert VSX or ImageShare II.

Syntax

autoshowcontent <get|on|off|nearfar|nearonly>

Parameter	Description
get	Returns the current setting.
on	Sets the system to send content automatically when a computer is connected to the system.
off	Requires presenters to press the Play button on the Visual Concert VSX or ImageShare II to send content to the far sites.
nearfar	Sets the system to send content automatically when a computer is connected to the system. Returns <code>autoshowcontent on</code> .
nearonly	Sets the system to send content automatically when a computer is connected to the system. Returns <code>autoshowcontent on</code> .

Feedback Examples

- ```
autoshowcontent on
returns
autoshowcontent on
```
- ```
autoshowcontent off
returns
autoshowcontent off
```
- ```
autoshowcontent get
returns
autoshowcontent off
```
- ```
autoshowcontent nearfar
returns
autoshowcontent on
```
- ```
autoshowcontent nearonly
returns
autoshowcontent on
```

### Comments

User interface screen location: **System > Admin Settings > Monitors > Graphics VGA: Send Content When PC Connects**

## backlightcompensation

Sets or gets the Backlight Compensation mode.

### Syntax

```
backlightcompensation <get|yes|no>
```

| Parameter | Description                                                                               |
|-----------|-------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                              |
| yes       | Enables Backlight Compensation. The camera automatically adjusts for a bright background. |
| no        | Disables the option.                                                                      |

### Feedback Examples

- `backlightcompensation yes`  
**returns**  
`backlightcompensation yes`
- `backlightcompensation no`  
**returns**  
`backlightcompensation no`
- `backlightcompensation get`  
**returns**  
`backlightcompensation no`

### Comments

User interface screen location: **System > Admin Settings > Cameras: Backlight Compensation**

## basicmode

Sets or gets the Basic Mode configuration, a limited operating mode that uses H.261 for video and G.711 for audio. Basic mode provides administrators with a workaround for interoperability issues that cannot be solved using other methods.

### Syntax

```
basicmode <get|on|off>
```

| Parameter | Description                  |
|-----------|------------------------------|
| get       | Returns the current setting. |
| on        | Enables basic mode.          |
| off       | Disables basic mode.         |

### Feedback Examples

- ```
basicmode on
returns
basicmode on
```
- ```
basicmode off
returns
basicmode off
```
- ```
basicmode get
returns
basicmode off
```

Comments

User interface screen location: **System > Admin Settings > Network > Call Preference: Enable Basic Mode**

bri1enable, bri2enable, bri3enable, bri4enable

Sets or gets the configuration of the specified ISDN BRI line. This command is only applicable if you have a BRI network interface connected to your system.

Syntax

```
bri1enable <get|yes|no>
bri2enable <get|yes|no>
bri3enable <get|yes|no>
bri4enable <get|yes|no>
```

Parameter	Description
get	Returns the status of the BRI line—yes if enabled, no if disabled.
yes	Enables the BRI line.
no	Disables the BRI line.

Feedback Examples

- `bri1enable yes`
returns
`bri1enable yes`
- `bri1enable no`
returns
`bri1enable no`
- `bri1enable get`
returns
`bri1enable no`

Comments

User interface screen location: **System > Admin Settings > Network > ISDN**
(page 2): **Enable** (for each line)

briallenable

Sets or gets the configuration of all ISDN BRI lines. This command is only applicable if you have a BRI network interface connected to your system.

Syntax

```
briallenable <get|yes|no>
```

Parameter	Description
get	Returns the status of all BRI lines—yes if enabled, no if disabled.
yes	Enables all BRI lines.
no	Disables all BRI lines.

Feedback Examples

- `briallenable yes`
returns
`bri1enable yes`
`bri2enable yes`
`bri3enable yes`
`bri4enable yes`
- `briallenable no`
returns
`bri1enable no`
`bri2enable no`
`bri3enable no`
`bri4enable no`
- `briallenable get`
returns
`bri1enable no`
`bri2enable no`
`bri3enable no`
`bri4enable no`

Comments

`briallenable yes` only enables lines where the directory numbers have been populated.

User interface screen location: **System > Admin Settings > Network > ISDN** (page 2): **Enable** (for Line 1, Line 2, Line 3, and Line 4)

button

Simulates Polycom remote control buttons.

Syntax

```
button <#|*|0|1|2|3|4|5|6|7|8|9|. >
button <down|left|right|select|up>
button <auto|callhangup|far|graphics|near|zoom+|zoom->
button <help|mute|snapshot|volume+|volume-|lowbattery>
button <pickedup|putdown>
button <camera|delete|directory|home|keyboard|period|pip|preset>
button <info|menu|slides>
button "valid_button" ["valid_button" ...]
```

Parameter	Description
.	Types a period (dot) if the cursor is on a text field.
#	Sends the # button signal to the user interface.
*	Sends the * button signal to the user interface.
["valid_button" ...]	Sends one or more remote control button signals.
0 1 2 3 4 5 6 7 8 9	Sends the corresponding numeric button signal to the user interface.
auto	Sends the Auto button signal to the user interface.
back	Simulates the Back button on multiple-page screens.
callhangup	Sends the call Hang-Up button signal to the user interface.
camera	Sends the Camera button signal to the user interface.
delete	Sends the Delete button signal to the user interface.
directory	Sends the Directory button signal to the user interface.
down	Sends the down arrow button signal to the user interface.
far	Sends the Far button signal to the user interface.
graphics	Sends the Graphics button signal to the user interface.
help	Sends the Help button signal to the user interface.
home	Sends the Home button signal to the user interface.
info	Sends the Info button signal to legacy systems. Deprecated. Polycom recommends using <code>help</code> instead of this button.
keyboard	Brings up the on-screen keyboard if the cursor is on a text field.

Parameter	Description
left	Sends the left arrow button signal to the user interface.
lowbattery	Simulates a low battery alert for the remote control.
menu	Sends the Menu button signal to legacy systems. Deprecated. Polycom recommends using <code>back</code> instead of this button.
mute	Sends the Mute button signal to the user interface, causing a toggle of mute state.
near	Sends the Near button signal to the user interface.
period	Types a period (dot) if the cursor is on a text field.
pickedup	Sends a signal indicating that the remote control has been picked up (remote control feet are out).
pip	Sends the PIP button signal to the user interface.
preset	Sends the Preset button signal to the user interface.
putdown	Sends signal indicating that the remote control has been set down (remote control feet are pushed in).
right	Sends the right arrow button signal to the user interface.
select	Sends the Select (center button) button signal to the user interface.
slides	Sends the Slides button signal to legacy systems. Deprecated. Polycom recommends using <code>graphics</code> instead of this button.
snapshot	Sends the Snapshot button signal to the user interface.
up	Sends the up arrow button signal to the user interface.
volume-	Sends the volume - button signal to the user interface.
volume+	Sends the volume + button signal to the user interface.
zoom-	Sends the zoom - button signal to the user interface.
zoom+	Sends the zoom +button signal to the user interface.

Feedback Examples

- `button up`
sends the up arrow command to the user interface and returns
`button up`

- `button near left right callhangup` is valid, sends the near, left arrow, right arrow, and call hang-up commands to the user interface, and returns


```
button near
button left
button right
button callhangup
```

The command checks for invalid input and reports button responses as they are processed. One of three status values is returned when the command is issued for multiple buttons:

- `succeeded`—all buttons are valid
- `failed`—all input is invalid and none can perform a valid action
- `completed`—some are invalid, and responses specify each as valid or invalid

For example:

- `button camera right center select`

```
returns
button camera
button right
error: button center not a recognized command
button select
button completed
```

Long `button` command sequences will complete before a second command is considered. Feedback for `button` command sequences that include multiple buttons show only the first button name.

Comments

Note that several parameters can be combined in the same command in any order.

The `button` commands are not recommended. When possible, use another API command instead of the `button` commands, which rely on the current organization of the user interface. For example, you can use the `pip` command instead of `button pip`.

See Also

For information about the IR signals to use when programming non-Polycom remote control devices for systems, refer to Appendix F, [IR Codes for Non-Polycom Remotes](#).

calldetail

Displays all or Nth call detail record(s).

Syntax

```
calldetail <"Nth_item" | all>
```

Parameter	Description
Nth_item	Displays the Nth call detail record.
all	Displays all call detail records.

Feedback Examples

- calldetail 1
 returns
 1,02/Jun/2007,16:34:34,02/Jun/2007,16:34:34,0:00:00,---,"Polycom
 VSX Demo",192.168.1.101,---,h323,384Kbps,Polycom/VSX
 7000/8.7,Out,2,1,---,---,---,terminal,192.168.1.101:1720,
 Siren14,Siren14,H.263,CIF,CIF,Normal call clearing has
 occurred.",16,---,0.00,0.00,0.00,0.00,16.00,16,00,29,29,4.00,6.00,
 19,21

Comments

User interface screen location: **Recent Calls** button

This button is only available if enabled on the Home Screen Settings screen.

calldetailreport

Sets or gets whether to generate a report of all calls made with the system.

Syntax

```
calldetailreport <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Turns on call detail reporting.
no	Turns off call detail reporting.

Feedback Examples

- `calldetailreport yes`
returns
`calldetailreport yes`
- `calldetailreport no`
returns
`calldetailreport no`
- `calldetailreport get`
returns
`calldetailreport no`

Comments

`calldetail no` disables both the Call Detail Report and Recent Calls features.
User interface screen location: **System > Admin Settings > General Settings > System Settings > Call Settings (page 2): Call Detail Report**

callencryption (deprecated)

Sets or gets the call encryption mode. You cannot use this command while a call is in progress.

With the implementation of the [encryption](#) command on page 4-98, this command has been deprecated.

Syntax

```
callencryption <get|whenavailable|disabled>
```

Parameter	Description
get	Returns the current setting.
whenavailable	Use encryption when the far site is capable of encryption.
disabled	Disables call encryption.

Feedback Examples

- callencryption disabled
returns
callencryption disabled
- callencryption whenavailable
returns
callencryption whenavailable
- callencryption get
returns
callencryption whenavailable

Comments

The Encryption options are only visible on the user interface if an encryption key has been entered.

User interface screen location: **System > Admin Settings > General Settings > Security: AES Encryption**

callinfo

Returns information about the current call. If you are in a multipoint call, this command returns one line for each site in the call.

Syntax

```
callinfo all
callinfo callid "callid"
```

Parameter	Description
all	Returns information about each connection in the call.
callid	Returns information about the connection with the specified call ID.

Feedback Examples

The callid information is returned using the following format:

```
callinfo:<callid>:<Far site name>:<far site number>:<speed>:
<connection status>:<mute status>:<call direction>:<call type>
```

- ```
callinfo all
returns
callinfo begin
callinfo:43:Polycom VSX Demo:192.168.1.101:384:connected:
notmuted:outgoing:videocall
callinfo:36:192.168.1.102:256:connected:muted:outgoing:videocall
callinfo end
```
- ```
callinfo callid 36
returns
callinfo:36:192.168.1.102:256:connected:muted:outgoing:videocall
```
- ```
callinfo all
returns
system is not in a call
when no call is currently connected
```

## callpreference

Sets or gets the supported call types.

### Syntax

```
callpreference get
callpreference <analogphone|basicmode|h239|h320|h323|isdngateway|sip|
v35|voiceoverisdn>
```

| Parameter     | Description                                                                                                   |
|---------------|---------------------------------------------------------------------------------------------------------------|
| get           | Returns information about which call types are enabled. Only call types supported by the system are returned. |
| analogphone   | Specifies the analog phone call type.                                                                         |
| basicmode     | Specifies basic mode.                                                                                         |
| h239          | Specifies H.239 capability.                                                                                   |
| h320          | Specifies the H.320 (ISDN) call type.                                                                         |
| h323          | Specifies the H.323 (IP) call type.                                                                           |
| isdngateway   | Specifies ISDN gateway calling.                                                                               |
| sip           | Specifies the SIP call type.                                                                                  |
| v35           | Specifies the V.35 call type.                                                                                 |
| voiceoverisdn | Specifies the Voice Over ISDN call type.                                                                      |

### Feedback Examples

- ```
callpreference get
returns
basicmode no
h239 yes
h323 yes
sip no
isdngateway no
```
- ```
callpreference basicmode yes
returns
callpreference yes
```

### Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > Network > Call Preference: Enable IP H.323 and Enable ISDN H.320**



## callstate

Sets or gets the call state notification for call state events.

### Syntax

```
callstate <get|register|unregister>
```

| Parameter  | Description                                                   |
|------------|---------------------------------------------------------------|
| get        | Returns the current setting.                                  |
| register   | Registers the system to give notification of call activities. |
| unregister | Disables the register mode.                                   |

### Feedback Examples

- `callstate register`  
returns  
`callstate registered`
- `callstate unregister`  
returns  
`callstate unregistered`
- `callstate get`  
returns  
`callstate unregistered`

After registering, the callstate (cs:) data is returned as follows:

```
cs: call[0] chan[0] dialstr[IP:192.168.1.103] state [RINGING]
cs: call[0] chan[0] dialstr[IP:192.168.1.103] state [RINGING]
cs: call[0] chan[0] dialstr[IP:192.168.1.103] state [CONNECTED]
cs: call[0] chan[0] dialstr[IP:192.168.1.103] state [COMPLETE]
active: call[0] speed[128]
cleared: call[0] line[0] bchan[0] cause[16]
dialstr[IP:192.168.1.103]
ended: call[0]
```

### See Also

Polycom recommends using the [notify](#) command on page 4-187 and [nonotify](#) command on page 4-186 instead of `callstate register` and `callstate unregister` as those notifications are easy to parse.

For more information about call status messages, refer to Appendix E, [Status Messages](#).

## callstats

Returns call summary information.

### Syntax

```
callstats
```

### Feedback Examples

- ```
callstats
returns
timeinlastcall 0:02:35
totalnumberofcalls 23
totalnumberofipcalls 23
totaltimeipcalls 2:08:44
percentageipcalls 100%
totalnumberofisdncalls 0
totaltimeisdncalls 00:00:00
percentageisdncalls 0%
```

Comments

User interface screen location: **System > Diagnostics > Call Statistics** (page 5)

camera

Sets or gets the near-site or far-site camera settings.

Syntax

```
camera near {1..4}
camera far {1..5}
camera <near|far> move <left|right|up|down|zoom+|zoom-|stop>
camera <near|far> move <continuous|discrete>
camera <near|far> source
camera <near|far> stop
camera <near|far> tracking <get|on|off|to_presets>
camera near <getposition|setposition "x" "y" "z">
camera <register|unregister>
camera register get
```

Parameter	Description
near	Specifies that the command selects or controls the near camera.
far	Specifies that the command selects or controls the far camera.
{1..4}, {1..5}	Specifies a near or far camera as the main video source.
move	Changes the near or far camera's direction or zoom. Only <code>continuous</code> and <code>discrete</code> return feedback. Valid directions are: <code>left</code> , <code>right</code> , <code>up</code> , <code>down</code> , <code>zoom+</code> , <code>zoom-</code> , <code>stop</code> , <code>continuous</code> , and <code>discrete</code> .
left	Starts moving the camera left.
right	Starts moving the camera right.
up	Starts moving the camera up.
down	Starts moving the camera down.
zoom+	Starts zooming in.
zoom-	Starts zooming out.
stop	Stops the near or far camera when in continuous mode. Returns no feedback.
continuous	Selects continuous movement mode. The camera will move in direction specified until a <code>camera <near far> move stop</code> command is sent.
discrete	Selects discrete movement mode. The camera will move a small amount in the direction specified and then stop. No stop command is required.
source	Returns the number of the near or far camera source currently selected.

Parameter	Description
tracking	Sets the tracking mode. Returns the current near or far camera tracking mode when followed by the <code>get</code> parameter.
on	Turns on the near or far camera tracking mode. The far-site system must have the option Far Control of Near Camera enabled and auto-tracking turned on.
off	Turns off the near or far camera tracking mode.
to_presets	Turns on the near or far camera tracking to presets.
getposition	Gets the pan, tilt, and zoom coordinates of the currently selected PTZ camera in the format of <code>pan tilt zoom</code> .
setposition "x" "y" "z"	Sets the pan (x), tilt (y), and zoom (z) coordinates of the currently selected PTZ camera. Camera PTZ range: $-880 \leq \text{pan} \leq 880$ $-300 \leq \text{tilt} \leq 300$ $0 \leq \text{zoom} \leq 1023$ Note: Some D30 cameras might not be able to reach the designed range limit. For example, although the pan limit is 880, the camera might only be able to reach 860.
register	Registers to receive feedback when the user changes the camera source. Returns the current camera registration state when followed by the <code>get</code> parameter.
unregister	Unregisters to receive feedback when the user changes the camera source.

Feedback Examples

- `camera far 2`
specifies camera 2 at the far-site and returns
`camera far 2`
- `camera far move left`
causes the far-site camera to start panning to the left and returns
event: `camera far move left`
- `camera near move zoom+`
causes the near-site camera to zoom in and returns
event: `camera near move zoom+`
- `camera register`
returns
`camera registered`

- camera unregister
returns
camera unregistered
- backlightcompensation no
returns
backlightcompensation no
- backlightcompensation get
returns
backlightcompensation no
- camera near tracking off
returns
camera near tracking off
- camera near tracking to_presets
returns
camera near tracking to_presets

cameradirection

Sets or gets the camera pan direction.

Syntax

```
cameradirection <get|normal|reversed>
```

Parameter	Description
get	Returns the current setting.
normal	Sets the direction of the camera to normal; the camera moves in the same direction as the left/right arrows on the remote control.
reversed	Sets the direction of the camera to reversed; the camera moves in the opposite direction of the left/right arrows on the remote control.

Feedback Examples

- cameradirection normal
returns
cameradirection normal
- cameradirection reversed
returns
cameradirection reversed
- cameradirection get
returns
cameradirection reversed

Comments

User interface screen location: **System > Admin Settings > Cameras: Camera Direction**

camerainput

Sets or gets the format for a video source.

Syntax

```
camerainput <1|2|3> <get|s-video|composite>
```

Parameter	Description
<1..3>	Specifies the video source.
get	Returns the current setting.
s-video	Specifies that the video source is connected using S-Video.
composite	Specifies that the video source is connected using a composite connector.

Feedback Examples

- ```
camerainput 1 composite
returns
camerainput 1 component
```
- ```
camerainput 2 s-video
returns
camerainput 2 s-video
```
- ```
camerainput 2 get
returns
camerainput 2 s-video
```

### Comments

User interface screen location: **System > Admin Settings > Cameras (page 2): Source**

## chaircontrol

Sends various chair control commands while the system is in a multipoint call.

### Syntax

```
chaircontrol end_conf
chaircontrol hangup_term "term_no"
chaircontrol list
chaircontrol rel_chair
chaircontrol <register|unregister>
chaircontrol req_chair
chaircontrol req_floor
chaircontrol req_term_name "term_no"
chaircontrol req_vas
chaircontrol set_broadcaster "term_no"
chaircontrol set_password "string"
chaircontrol set_term_name "term_no" "term_name"
chaircontrol stop_view
chaircontrol view "term_no"
chaircontrol view_broadcaster
```

| Parameter                    | Description                                                                                                                                                        |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| end_conf                     | Ends the call and returns the same feedback as hangup_term for each site in the call.                                                                              |
| hangup_term<br>"term_no"     | Disconnects the specified site from the call.                                                                                                                      |
| list                         | Lists the sites in the call.                                                                                                                                       |
| rel_chair                    | Releases the chair.                                                                                                                                                |
| register                     | Registers to receive feedback on all chair control operations.                                                                                                     |
| unregister                   | Unregisters (stops feedback on all chair control operations).                                                                                                      |
| req_chair                    | Requests the chair.                                                                                                                                                |
| req_floor                    | Requests the floor.                                                                                                                                                |
| req_term_name<br>"term_no"   | Requests the name for the specified terminal number.                                                                                                               |
| req_vas                      | Requests voice-activated switching.                                                                                                                                |
| set_broadcaster<br>"term_no" | Requests the specified terminal to become the broadcaster.                                                                                                         |
| set_password<br>"string"     | Sets the chaircontrol password. This password is the Meeting Password ( <b>System &gt; Admin Settings &gt; General Settings &gt; Security: Meeting Password</b> ). |



| Parameter                                 | Description                                      |
|-------------------------------------------|--------------------------------------------------|
| set_term_name<br>"term_no"<br>"term_name" | Sets the name for the specified terminal number. |
| stop_view                                 | Stops viewing the specified terminal.            |
| view "term_no"                            | Views the specified terminal.                    |
| view_broadcaster                          | Views the broadcaster.                           |

### Feedback Examples

- ```
chaircontrol rel_chair
returns
rel_chair & view 1.1
```
- ```
chaircontrol req_vas
returns
req_vas & view 1.2
```
- ```
chaircontrol view 1.3
returns
view 1.3
```
- ```
chaircontrol register
returns
chaircontrol registered
```
- ```
chaircontrol req_floor
returns
chaircontrol req_floor not in mcu call
when no MCU call is currently connected
```
- ```
chaircontrol view_broadcaster
returns
view_broadcaster
```
- ```
chaircontrol hangup_term 1.4
returns
chaircontrol del_term 1.4
cleared: call[34]
dialstring[IP:192.168.1.101 NAME:Polycom VSX Demo]
ended call[34]
```

Comments

Terminal numbers are set by the MCU and are of the form x.y where x is the MCU and y is the participant.

You only need to enclose a parameter in quotes if it contains a space.

colorbar

Turns the video diagnostics color bars on or off.

Syntax

colorbar <on|off>

Parameter	Description
on	Turns on the color bar test pattern.
off	Turns off the color bar test pattern.

Feedback Examples

- colorbar on
returns
colorbar on
- colorbar off
returns
colorbar off

Comments

User interface screen location: **System > Diagnostics > Video**

colorscheme

Sets or gets the interface color scheme of the VSX system.

Syntax

```
colorscheme <get|1|2|3|4|5|20>
```

Parameter	Description
get	Returns the current setting.
1 2 3 4 5 20	Sets the system color scheme. 1 = Ocean Blue 2 = Wine Red 3 = Concrete Gray 4 = Midnight Gray 5 = Steel Gray 20 = ViewStation Classic

Feedback Examples

- colorscheme 4
returns
colorscheme 4

Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Appearance: Color Scheme**

configchange (deprecated)

Sets or gets the notification state for configuration changes. This command has been deprecated.

Syntax

```
configchange <get|register|unregister>
```

Parameter	Description
get	Returns the current setting.
register	Registers to receive notifications when configuration variables have changed.
unregister	Unregisters to receive notifications when configuration variables have changed.

Feedback Examples

- `configchange register`
returns
`configchange registered`
- `configchange unregister`
returns
`configchange unregistered`
- `configchange get`
returns
`configchange unregistered`

configdisplay

Sets or gets the video format and aspect ratio for Monitor 1 or Monitor 2.

Syntax

```
configdisplay get
configdisplay <monitor1|monitor2> get
configdisplay <monitor1|monitor2> <s_video|composite|vga> <4:3|16:9>
configdisplay monitor2 off
```

Parameter	Description
get	Returns the current setting.
monitor1	Specifies Monitor 1.
monitor2	Specifies Monitor 2.
s_video	Sets the specified display to S-Video format.
composite	Sets the specified display to Composite format.
vga	Sets the specified display to VGA format.
4:3	Sets the display aspect ratio to 4:3 (standard).
16:9	Sets the display aspect ratio to 16:9 (wide screen).
off	Sets Monitor 2 to off.

Feedback Examples

- ```
configdisplay get
returns
configdisplay monitor1 composite 4:3, monitor2 s_video off
```
- ```
configdisplay monitor1 get
returns
configdisplay monitor1 composite 4:3
```
- ```
configdisplay monitor1 vga 16:9
returns
configdisplay monitor1 vga 16:9
and restarts the system
```

## Comments

Changing from S-Video or composite to VGA, or from VGA to S-Video or composite causes the system to restart. If Monitor 1 is set to VGA, Monitor 2 is disabled.

User interface screen location: **System > Admin Settings > Monitors**

## configparam

Sets or gets the value of many different configuration settings.

### Syntax

```
configparam <"parameter"> get
configparam <"parameter"> set <"value">
```

| Parameter                         | Possible Values        | Description                                                                                                                   |
|-----------------------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| allow_directory_changes           | yes no                 | Sets or gets whether users can save changes they make to the directory.                                                       |
| area_code_required                | yes no                 | Sets or gets whether an area code is required to place ISDN calls in the specified country.                                   |
| audio_in_level                    | 0 1 2 3 4 5 6 7 8 9 10 | Sets or gets the volume level of the audio input.                                                                             |
| balanced_input_type               | line_input microphone  | Sets or gets the type of equipment that is connected to the balanced audio inputs.                                            |
| balanced_output_mode              | variable fixed         | Sets or gets whether the volume for a device connected to the balanced audio output connectors is variable or fixed.          |
| camera_video_quality<br><1 2 3 4> | motion sharpness       | Sets or gets the video quality setting for the specified video input for motion or for sharpness (for images without motion). |
| camera1_video_quality             | motion sharpness       | Sets or gets the video quality setting for video input 1 for motion or for sharpness (for images without motion).             |
| camera2_video_quality             | motion sharpness       | Sets or gets the video quality setting for video input 2 for motion or for sharpness (for images without motion).             |
| camera3_video_quality             | motion sharpness       | Sets or gets the video quality setting for video input 3 for motion or for sharpness (for images without motion).             |
| camera4_video_quality             | motion sharpness       | Sets or gets the video quality setting for video input 4 for motion or for sharpness (for images without motion).             |

| Parameter                 | Possible Values                                  | Description                                                                                                |
|---------------------------|--------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| contactlist_as_homescreen | yes   no                                         | Sets or gets whether to display the contact list home screen.                                              |
| date_format               | mm_dd_yyyy   dd_mm_yyyy   yyyy_mm_dd             | Sets or gets the format for the date display.                                                              |
| displaylastnumberdialed   | yes   no                                         | Sets or gets whether to display the last number dialed or clear the dialing field on the home screen.      |
| do_not_disturb            | yes   no                                         | Sets or gets whether the system refuses incoming calls automatically.                                      |
| enable_analog_phone       | yes   no                                         | Sets or gets whether to allow the system to make voice-only calls to any phone using an analog phone line. |
| enable_ftp_access         | yes   no                                         | Sets or gets whether to allow remote access to the system by FTP.                                          |
| enable_isdn_gateway       | yes   no                                         | Sets or gets whether to place IP-to-ISDN calls through a gateway.                                          |
| enable_polycom_mic        | yes   no                                         | Sets or gets whether integrated and attached Polycom microphones are enabled.                              |
| enable_polycom_stereo     | yes   no                                         | Sets or gets whether Polycom StereoSurround™ is used for all calls.                                        |
| enable_sip                | yes   no                                         | Sets or gets whether to allow the system to use SIP when connecting IP calls.                              |
| enable_telnet_access      | yes   no                                         | Sets or gets whether to allow remote access to the system by Telnet.                                       |
| enable_web_access         | yes   no                                         | Sets or gets whether to allow remote access to the system by the web.                                      |
| firewall_fixed_ports      | yes   no                                         | Sets or gets whether to define the TCP and UDP firewall ports.                                             |
| ip_max_incoming_speed     | 128   256   384   512   768   1024   1472   1920 | Sets or gets the maximum speed for an incoming IP call.                                                    |

| Parameter                | Possible Values                                           | Description                                                                                                                   |
|--------------------------|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| line_input_red           | vcr vcnx                                                  | Sets or gets whether a VCR or an ImageShare II, Visual Concert VSX, or laptop is connected to the red (right) audio line in.  |
| line_input_white         | vcr vcnx                                                  | Sets or gets whether a VCR or an ImageShare II, Visual Concert VSX, or laptop is connected to the white (left) audio line in. |
| line_output_mode         | variable fixed                                            | Sets or gets the audio output mode.                                                                                           |
| mainscreensites          | yes no                                                    | Sets or gets whether the main monitor displays the call sites.                                                                |
| preferred_dialing_method | auto manual                                               | Sets or gets the preferred method for dialing various call types.                                                             |
| remote_control_keypad    | presets tones                                             | Sets or gets whether pressing remote control keypad buttons moves the camera to presets or generates DTMF tones.              |
| sites_button_name        | speed_dial buddy_list                                     | Sets or gets whether the button text for pre-defined sites on the home screen is displayed as Speed Dial or the site name.    |
| snap_button_option       | calendar callhistory systeminformation callstatistics off | Sets or gets the use for the Snap button on the remote control.                                                               |
| use_non-polycom_remote   | yes no                                                    | Sets or gets whether the system accepts input from a programmable, non-Polycom remote control.                                |
| video_pro-motion         | auto off 512 768 1024                                     | Sets or gets Pro-Motion™ minimum call speed settings for video inputs that are set for motion.                                |

### Feedback Examples

- ```
configparam allow_directory_changes get
returns
allow_directory_changes yes
```


- `configparam audio_in_level set 4`
returns
`audio_in_level 4`
- `configparam camera_video_quality 1 set motion`
returns
`camera1_video_quality motion`
- `configparam camera1_video_quality set motion`
returns
`camera1_video_quality motion`
- `configparam date_format set mm_dd_yyyy`
returns
`date_format mm_dd_yyyy`
- `configparam ip_max_incoming_speed set 384`
returns
`ip_max_incoming_speed 384`
- `configparam line_input_red set vcnx`
returns
`line_input_red vcnx`
and sets the red line input to the Visual Concert VSX
- `configparam mainscreensites set no`
returns
`mainscreensites no`
- `configparam video_pro-motion get`
returns
`video_pro-motion 768`

Comments

After using `configparam enable_ftp_access`,
`configparam enable_telnet_access`, or
`configparam enable_web_access`, you are prompted to restart the system.

configpresentation

Sets or gets the content presentation settings for Monitor 1 or Monitor 2.

Syntax

```
configpresentation get
configpresentation <monitor1|monitor2> get
configpresentation monitor1 <near|far|content|near-or-far|
  content-or-near|content-or-far|all|none>
configpresentation monitor2 <near|far|content|near-or-far|
  content-or-near|content-or-far|all|none>
configpresentation monitor1 "value" monitor2 "value"
```

Parameter	Description
get	Returns the current settings for the active monitors.
monitor1	Specifies settings for Monitor 1.
monitor2	Specifies settings for Monitor 2.
near	Selects near-site video as the video source to display on the specified monitor.
far	Selects far-site video as the video source to display on the specified monitor.
content	Selects content as the video source to display on the specified monitor.
near-or-far	Selects both near-site and far-site video as video sources to display on the specified monitor.
content-or-near	Selects both near-site video and content as video sources to display on the specified monitor.
content-or-far	Selects both content and far-site video as video sources to display on the specified monitor.
all	Selects content, near-site video, and far-site video as video sources for the specified monitor.
none	Clears all video sources for the specified monitor.
"value"	Sets presentation mode for both monitors.

Feedback Examples

- `configpresentation monitor1 get`
returns
`configpresentation monitor1:all`
- `configpresentation monitor2 get`
returns
`configpresentation monitor2:near-or-far`
- `configpresentation monitor2 far`
returns
`error: configpresentation not applied since monitor2 is off`
`when monitor 2 is off`

Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors** (page 2)

confirmdiradd

Sets or gets the configuration for prompting users to add directory entries for the far sites when a call disconnects.

Syntax

```
confirmdiradd <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	When a call disconnects, the user is prompted to create a local directory entry for the far site if it is not already in the directory.
no	The user is not prompted to create a local directory entry after a call disconnects.

Feedback Examples

- ```
confirmdiradd no
returns
confirmdiradd no
```
- ```
confirmdiradd yes
returns
confirmdiradd yes
```
- ```
confirmdiradd get
returns
confirmdiradd yes
```

### Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Directory: Confirm Directory Additions Upon Call Disconnect**

## confirmdirdel

Sets or gets the configuration for requiring users to confirm directory deletions.

### Syntax

```
confirmdirdel <get|yes|no>
```

| Parameter | Description                                                                                                                       |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                                      |
| yes       | When deleting an entry from the directory (address book), the user is prompted with "Are you sure you want to delete this entry?" |
| no        | When deleting an entry from the directory (address book), the user is not prompted with a message.                                |

### Feedback Examples

- `confirmdirdel no`  
returns  
`confirmdirdel no`
- `confirmdirdel yes`  
returns  
`confirmdirdel yes`
- `confirmdirdel get`  
returns  
`confirmdirdel yes`

### Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Directory: Confirm Directory Deletions**

## contentauto

Sets or gets the automatic bandwidth adjustment for people and content in point-to-point H.323 calls. Automatic adjustment maintains equal image quality in the two streams.

### Syntax

```
contentauto <get|on|off>
```

| Parameter | Description                                                                                                                    |
|-----------|--------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                                   |
| on        | Enables automatic bandwidth adjustment for people and content.                                                                 |
| off       | Disables automatic bandwidth adjustment for people and content. The system <b>Quality Preference</b> settings is used instead. |

### Feedback Examples

- ```
contentauto off
returns
contentauto FALSE
```
- ```
contentauto on
returns
contentauto TRUE
```
- ```
contentauto get
returns
contentauto on
```

See Also

To set the bandwidth split for people and content, use the [vgaqualitypreference](#) command on page 4-299.

country

Sets or gets the country setting for the system. This allows you to specify country-specific calling parameters for your location.

Syntax

```
country get
country set {afghanistan...zimbabwe}
```

Parameter	Description
get	Returns the current setting.
set	Sets the country. A country name parameter is required.
{algeria...zimbabwe}	Name of a country from the system's country list. Use quotation marks around a compound name or strings containing spaces. Example: "united states"

Feedback Examples

- ```
country set germany
returns
country germany
```
- ```
country set "united states"
returns
country "united states"
```
- ```
country get
returns
country "united states"
```

### Comments

User interface screen location: **System > Admin Settings > General Settings > Location: Country**

## cts

Sets or gets the CTS serial interface control signal (clear to send) configuration. This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
cts <get|normal|inverted|ignore>
```

| Parameter | Description                                           |
|-----------|-------------------------------------------------------|
| get       | Returns the current setting.                          |
| normal    | Sets the signal to normal (high voltage is logic 1).  |
| inverted  | Sets the signal to inverted (low voltage is logic 1). |
| ignore    | Ignores the signal.                                   |

### Feedback Examples

- ```
cts normal
returns
cts normal
```
- ```
cts inverted
returns
cts inverted
```
- ```
cts get
returns
cts inverted
```

Comments

The default setting for this signal is "normal".

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings > V.35/RS-449/RS-530** (page 3): CTS

daylightsavings

Sets or gets the daylight savings time setting. When you enable this setting, the system clock automatically changes for daylight saving time.

Syntax

```
daylightsavings <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables automatic adjustment for daylight savings time.
no	Disables automatic adjustment for daylight savings time.

Feedback Examples

- ```
daylightsavings no
returns
daylightsavings no
```
- ```
daylightsavings yes
returns
daylightsavings yes
```
- ```
daylightsavings get
returns
daylightsavings yes
```

### Comments

User interface screen location: **System > Admin Settings > General Settings > Location (page 2): Auto Adjust for Daylight Saving Time**

## dcd

Sets or gets the configuration for the DCD serial interface control signal (data carrier detect). This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
dcd <get|normal|inverted>
```

| Parameter | Description                                           |
|-----------|-------------------------------------------------------|
| get       | Returns the current setting.                          |
| normal    | Sets the signal to normal (high voltage is logic 1).  |
| inverted  | Sets the signal to inverted (low voltage is logic 1). |

### Feedback Examples

- dcd normal  
returns  
dcd normal
- dcd inverted  
returns  
dcd inverted
- dcd get  
returns  
dcd inverted

### Comments

The default setting for this signal is "normal".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): DCD**

## dcdfilter

Sets or gets the filter setting of the DCD serial interface control signal (data carrier detect). This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
dcdfilter <get|on|off>
```

| Parameter | Description                  |
|-----------|------------------------------|
| get       | Returns the current setting. |
| on        | Enables the DCD filter.      |
| off       | Disables the DCD filter.     |

### Feedback Examples

- dcdfilter on  
returns  
dcdfilter on
- dcdfilter off  
returns  
dcdfilter off
- dcdfilter get  
returns  
dcdfilter off

### Comments

When this filter is enabled, DCD drops for 60 seconds before changing the call state. The default setting for this signal is "off".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): Delayed DCD hangup**

## defaultgateway

Sets or gets the default gateway.

### Syntax

```
defaultgateway get
defaultgateway set "xxx.xxx.xxx.xxx"
```

| Parameter         | Description                                                                |
|-------------------|----------------------------------------------------------------------------|
| get               | Returns the default gateway IP address.                                    |
| set               | Sets the default gateway when followed by the "xxx.xxx.xxx.xxx" parameter. |
| "xxx.xxx.xxx.xxx" | IP address to use as the default gateway.                                  |

### Feedback Examples

- ```
defaultgateway set 192.168.1.101
returns
defaultgateway 192.168.1.101
restart system for changes to take effect. restart now? <y,n>
```

Comments

This setting can only be changed if DHCP is turned off. After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties**
(page 2): **Default Gateway**

dhcp

Sets or gets DHCP options.

Syntax

```
dhcp <get|off|client|server>
```

Parameter	Description
get	Returns the selected DHCP option.
off	Disables DHCP.
client	Enables DHCP client, setting the system to obtain an IP address from a server on your network.
server	Enables DHCP server, setting the system to provide IP addresses to the other computers on your network.

Feedback Examples

- dhcp off
returns
restart system for changes to take effect. restart now? <y,n>
- dhcp client
returns
restart system for changes to take effect. restart now? <y,n>
- dhcp get
returns
dhcp client

Comments

After making a change, you are prompted to restart the system. If the user or administrator has chosen not to allow the DHCP server option, it will not be available.

User interface screen location: **System > Admin Settings > LAN Properties: IP Address: Obtain IP address automatically or Enter IP address manually**

dial

Dials video or audio calls either manually or from the directory.

Syntax

```
dial addressbook "addr book name"
dial auto "speed" "dialstr"
dial manual <56|64> "dialstr1" "dialstr2" [h320]
dial manual "speed" "dialstr1" ["dialstr2"] [h323|h320|ip|isdn|sip]
dial phone "dialstring"
```

Parameter	Description
addressbook	Dials a directory (address book) entry. Requires the name of the entry.
"addr book name"	The name of the directory (address book) entry. The name may be up to 25 characters. Use quotation marks around strings that contain spaces. For example: "John Doe".
auto	Dials a video call number dialstr1 at speed of type h323 or h320. Requires the parameters "speed" and "dialstr". Allows the user to automatically dial a number. The system first attempts H.323 and if that fails, rolls over to H.320. Deprecated. Instead of this command, Polycom recommends using dial manual and not specifying a call type.
"speed"	Valid data rate for the network.
"dialstr", "dialstr1", "dialstr2"	Valid ISDN or IP directory number.
manual	Dials a video call number dialstr1 at speed of type h323 or h320. Requires the parameters "speed" and "dialstr1". Use dial manual "speed" "dialstr" "type" when you do not want automatic call rollover or when the dialstring might not convey the intended transport (for example, an extension with an IP gateway might look like an ISDN number, but in fact corresponds to an IP address).
56 64	Specifies speed for two-channel calls.
h323 h320 ip isdn sip	Type of call. Note: The parameters ip and isdn are deprecated.
phone	Dials an analog phone number.
"dialstring"	Numeric string specifying the phone number to dial. Enclose the string in quotation marks if it includes spaces. Example: "512 555 1212"

Feedback Examples

- `dial manual 64 5551212 h320`
returns
dialing manual
cs: call[34] chan[0] dialstr[5551212] state[ALLOCATED]
cs: call[34] chan[0] dialstr[5551212] state[RINGING]
cs: call[34] chan[0] dialstr[5551212] state[CONNECTED]
cs: call[34] chan[0] dialstr[5551212] state[CONNECTED]
cs: call[34] chan[0] dialstr[5551212] state[COMPLETE]
cs: call[34] chan[0] dialstr[5551212] state[COMPLETE]
active: call[34] speed[64]
- `dial addressbook "John Polycom"`
returns
dialing addressbook 29
dialing Monday meeting
cs: call[35] chan[0] dialstr[192.168.1.101] state[ALLOCATED]
cs: call[35] chan[0] dialstr[192.168.1.101] state[RINGING]
cs: call[35] chan[0] dialstr[192.168.1.101] state[CONNECTED]
cs: call[35] chan[0] dialstr[192.168.1.101] state[COMPLETE]
active: call[35] speed[384]

Comments

When searching for feedback from the dial command, expect to see the set of described strings as many times as there are channels in the call.

See Also

Refer to the `callstate` command on page 4-39. You can use `callstate register` to obtain updated information on the status of a call. For example, when using the `dial manual` to place a call, `callstate register` can tell you when the call is connected.

dialchannels

Sets or gets whether to dial ISDN channels in parallel. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
dialchannels get  
dialchannels set n
```

Parameter	Description
get	Returns the current setting.
set	Sets the number of channels to dial.
n	Sets the number of channels to dial. n is 8 for QBRI, 12 for PRI.

Feedback Examples

- dialchannels set 8
returns
dialchannels 8
- dialchannels get
returns
dialchannels 8

Comments

User interface screen location: **System > Admin Settings > Network > ISDN**
(page 3)

dialingdisplay

Sets or gets the home screen dialing display.

Syntax

```
dialingdisplay <get|dialingentry|displaymarquee|none>
```

Parameter	Description
get	Returns the current setting.
dialingentry	Displays a field for users to enter numbers manually.
displaymarquee	Displays text in the dialing entry field. Users cannot enter numbers manually when this option is selected. The text displayed is specified by the <code>marqueedisplaytext</code> command.
none	Removes the dialing entry field from the display.

Feedback Examples

- ```
dialingdisplay none
returns
dialingdisplay none
```
- ```
dialingdisplay dialingentry
returns
dialingdisplay dialingentry
```
- ```
dialingdisplay displaymarquee
returns
dialingdisplay displaymarquee
```
- ```
dialingdisplay get
returns
dialingdisplay displaymarquee
```

Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: Dialing Display**

See Also

The text displayed is specified by the [marqueedisplaytext](#) command on page 4-164.

dialingentryfield

Sets or gets the configuration of the dialing entry field on the Place a Call screen.

Syntax

```
dialingentryfield <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Adds the dialing entry field to the Place a Call screen.
no	Removes the dialing entry field from the Place a Call screen.

Feedback Examples

- dialingentryfield yes
returns
dialingentryfield yes
- dialingentryfield no
returns
dialingentryfield no
- dialingentryfield get
returns
dialingentryfield no

diffservaudio, diffservfecc, diffservvideo

Sets or gets the DiffServ option and specifies a priority level for audio, far-end camera control (FECC), and video, respectively. The priority level value for each can be between 0 and 63.

Syntax

```
diffservaudio get
diffservaudio set {0..63}
diffservfecc get
diffservfecc set {0..63}
diffservvideo get
diffservvideo set {0..63}
```

Parameter	Description
get	Returns the current setting.
set	Sets the command. A priority level in the range {0..63} is required.
{0..63}	Specifies the priority level.

Feedback Examples

- ```
diffservaudio set 2
returns
diffservaudio 2
```
- ```
diffservaudio get
returns
diffservaudio 2
```

Comments

If the [typeservice](#) command on page 4-279 is set to ip-precedence rather than to diffserv, these commands are not applicable.

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service: Type of Service > DiffServ**

dir

Lists flash files. No wild cards are allowed.

Syntax

```
dir ["string"]
```

Parameter	Description
"string"	Lists flash files which partially match a string (such as "dat" or "abk") of up to 250 alphanumeric characters. To list all the files, omit "string".

Feedback Examples

- `dir abk`
returns a list of all files in the local directory (address book)

directory

Sets or gets whether the **Directory** button appears on the home screen.

Syntax

```
directory <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Displays the Directory button on the home screen.
no	Removes the Directory button from the home screen.

Feedback Examples

- `directory yes`
returns
`directory yes`
- `directory no`
returns
`directory no`
- `directory get`
returns
`directory no`

Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: Directory**

display (deprecated)

Displays information about the current call or the system. With the implementation of the `callinfo` command on page 4-37 and `whoami` command on page 4-309, this command has been deprecated.

Syntax

```
display call
display whoami
```

Parameter	Description
call	Displays the following information about the current call: call ID, status, speed, the number to which this system is connected.
whoami	Returns information about the current system.

Feedback Examples

- ```
display call
returns
Call ID Status Speed Dialed Num
----- -
34 CM_CALLINFO_CONNECTED 384 192.168.1.101
```
- ```
display whoami
returns
Hi, my name is: Polycom VSX Demo
Here is what I know about myself:
Model: VSX7000
Serial Number: 82065205E72EB1
Software Version: Release 8.7 - 26Jun2007 11:30
Build Information: root on domain.polycom.com
FPGA Revision: 4.3.0
Main Processor: BSP15
Time In Last Call: 0:43:50
Total Time In Calls: 87:17:17
Total Calls: 819
SNTP Time Service: auto insync ntp1.polycom.com
Local Time is: Mon, 9 Jul 2007
Network Interface: NONE
IP Video Number: 192.168.1.101
ISDN Video Number: 7005551212
MP Enabled: True
H.323 Enabled: True
FTP Enabled: True
HTTP Enabled: True
SNMP Enabled: True
```

displayglobaladdresses

Sets or gets the display of global addresses in the global directory.

Syntax

```
displayglobaladdresses <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the display of global addresses.
no	Disables the display of global addresses.

Feedback Examples

- `displayglobaladdresses yes`
returns
`displayglobaladdresses yes`
- `displayglobaladdresses no`
returns
`displayglobaladdresses no`
- `displayglobaladdresses get`
returns
`displayglobaladdresses no`

Comments

User interface screen location: **System > Admin Settings > Global Services > Directory Servers: Display Global Addresses**

displaygraphics

Sets or gets the display of graphic icons while in a call.

Syntax

displaygraphics <get|yes|no>

Parameter	Description
get	Returns the current setting.
yes	Enables the display of graphic icons.
no	Disables the display of graphic icons.

Feedback Examples

- displaygraphics yes
returns
displaygraphics yes
- displaygraphics no
returns
displaygraphics no
- displaygraphics get
returns
displaygraphics no

Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors: Display Icons in a Call**

displayipext

Sets or gets the display of the IP extension field. This extension is needed when placing a call through a gateway.

Syntax

```
displayipext <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the display of the IP extension.
no	Enables the display of the IP extension.

Feedback Examples

- displayipext yes
returns
displayipext yes
- displayipext no
returns
displayipext no
- displayipext get
returns
displayipext no

Comments

When this option is selected, the extension field is visible on the Place a Call screen.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings: Display H.323 Extension**

displayipisdninfo (deprecated)

Sets or gets the display of IP and ISDN information on the home screen. This command has been deprecated. Polycom recommends using the [ipisdninfo](#) command on page 4-149.

Syntax

```
displayipisdninfo <yes|no|both|ip-only|isdn-only|none|get>
```

Parameter	Description
yes	Enables the display of both IP and ISDN information. Provides feedback <code>both</code> .
no	Disables the display of IP and ISDN information. Provides feedback <code>none</code> .
both	Enables the display of both IP and ISDN information.
ip-only	Disables the display of IP information.
isdn-only	Enables the display of ISDN information.
none	Disables the display of IP and ISDN information.
get	Returns the current setting.

Feedback Examples

- ```
displayipisdninfo yes
returns
displayipisdninfo both
```
- ```
displayipisdninfo no
returns
displayipisdninfo none
```
- ```
displayipisdninfo ip-only
returns
displayipisdninfo ip-only
```
- ```
displayipisdninfo get
returns
displayipisdninfo ip-only
```

Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings** (page 2): **IP or ISDN Information**

displayparams

Outputs a list of system settings.

Syntax

displayparams

Feedback Examples

- displayparams
returns
systemname Polycom VSX Demo
hostname <empty>
ipaddress 192.168.1.101
wanipaddress 192.168.1.102
version "release 8.7 - 26jun2007 11:30"
serialnum 82065205E72EB1
allowremotemonitoring no
daylightsavings yes
requireacctnumtodial no
validateacctnum no
timediffgmt -12:00
gabserverip <empty>
gabpassword <empty>
displayglobaladdresses no
registerthissystem no
showaddrsingab both
primarycallchoice manual
secondarycallchoice none
preferredalias extension
gatewaynumbertype number+extension
usegatekeeper off
numdigitsdid 7
numdigitsext 4
gatewaycountrycode <empty>
gatewayareacode <empty>
gatewaynumber <empty>
gatekeeperip <empty>
h323name <empty>
e164ext 7878
gatewayext 123456789
usepathnavigator required

dns

Sets or gets the configuration for up to four DNS servers.

Syntax

```
dns get {1..4}
dns set {1..4} "xxx.xxx.xxx.xxx"
```

Parameter	Description
get	Returns the current IP address of the specified server. A server identification number {1..4} is required.
{1..4}	Specifies the server identification number.
set	Sets the IP address of the specified DNS server when followed by the "xxx.xxx.xxx.xxx" parameter. A server identification number {1..4} is required.
"xxx.xxx.xxx.xxx"	Specifies the IP address for the specified server.

Feedback Examples

- ```
dns set 1 192.168.1.205
returns
dns 1 192.168.1.205
restart system for changes to take effect. restart now? <y,n>
```

### Comments

After making a change, you are prompted to restart the system. These values cannot be set if the system is in DHCP client mode.

User interface screen location: **System > Admin Settings > LAN Properties (page 2): DNS Servers**

## dsr

Sets or gets the configuration of the DSR serial interface control signal (data set ready). This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
dsr <get|normal|inverted>
```

| Parameter | Description                                           |
|-----------|-------------------------------------------------------|
| get       | Returns the current setting.                          |
| normal    | Sets the signal to normal (high voltage is logic 1).  |
| inverted  | Sets the signal to inverted (low voltage is logic 1). |

### Feedback Examples

- dsr normal  
returns  
dsr normal
- dsr inverted  
returns  
dsr inverted
- dsr get  
returns  
dsr inverted

### Comments

The default setting for this signal is "normal".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): DSR**

## dsranswer

Sets or gets the configuration of the DSR serial interface control signal to indicate an incoming call. This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
dsranswer <get|on|off>
```

| Parameter | Description                  |
|-----------|------------------------------|
| get       | Returns the current setting. |
| on        | Turns on the option.         |
| off       | Turns off the option.        |

### Feedback Examples

- dsranswer on  
returns  
dsranswer on
- dsranswer off  
returns  
dsranswer off
- dsranswer get  
returns  
dsranswer off

### Comments

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): Answer on DSR**

## dtr

Sets or gets the configuration of the DTR serial interface control signal (data terminal ready). This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
dtr <get|normal|inverted|on>
```

| Parameter | Description                                                                                     |
|-----------|-------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                    |
| normal    | Sets the signal to normal (high voltage is logic 1).                                            |
| inverted  | Sets the signal to inverted (low voltage is logic 1).                                           |
| on        | Sets constant high voltage. If this option is selected, <code>inverted</code> is not an option. |

### Feedback Examples

- ```
dtr normal
returns
dtr normal
```
- ```
dtr inverted
returns
dtr inverted
```
- ```
dtr on
returns
dtr on
```
- ```
dtr get
returns
dtr on
```

### Comments

The default setting for the signal is "normal".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): DTR**

## dualmonitor

Sets or gets whether video is displayed using dual monitor emulation, or split-screen mode, when using one monitor.

### Syntax

```
dualmonitor <get|yes|no>
```

| Parameter | Description                      |
|-----------|----------------------------------|
| get       | Returns the current setting.     |
| yes       | Enables dual monitor emulation.  |
| no        | Disables dual monitor emulation. |

### Feedback Examples

- dualmonitor yes  
returns  
dualmonitor yes
- dualmonitor no  
returns  
dualmonitor no
- dualmonitor get  
returns  
dualmonitor no

### Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors: Dual Monitor Emulation**



## dynamicbandwidth

Sets or gets the use of dynamic bandwidth allocation for Quality of Service.

### Syntax

```
dynamicbandwidth <get|yes|no>
```

| Parameter | Description                            |
|-----------|----------------------------------------|
| get       | Returns the current setting.           |
| yes       | Enables the dynamic bandwidth option.  |
| no        | Disables the dynamic bandwidth option. |

### Feedback Examples

- ```
dynamicbandwidth yes
returns
dynamicbandwidth yes
```
- ```
dynamicbandwidth no
returns
dynamicbandwidth no
```
- ```
dynamicbandwidth get
returns
dynamicbandwidth no
```

Comments

The system's dynamic bandwidth function automatically finds the optimum line speed for a call. If you experience excessive packet loss while in a call, the dynamic bandwidth function decrements the line speed until there is no packet loss. This is supported in calls with end points that also support dynamic bandwidth.

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service (page 2): Dynamic Bandwidth**

e164ext

Sets or gets an H.323 (IP) extension, also known as an E.164 name, needed for inbound calls going through a gateway.

Syntax

```
e164ext get
e164ext set "e.164name"
```

Parameter	Description
get	Returns the current setting.
set	Sets the E.164 extension when followed by the "e.164name" parameter. To erase the current setting, omit "e.164name".
"e.164name"	A valid E.164 extension (usually a four-digit number).

Feedback Examples

- ```
e164ext set
returns
e164ext <empty>
```
- ```
e164ext set 7878
returns
e164ext 7878
```
- ```
e164ext get 7878
returns
e164ext 7878
```

### Comments

The extension number is associated with a specific LAN device.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings: H.323 Extension (E.164)**

# echo

Prints "string" back to the API client screen.

## Syntax

```
echo "string"
```

| Parameter | Description                       |
|-----------|-----------------------------------|
| "string"  | Text to be printed to the screen. |

## Feedback Examples

- `echo End of abk range results`  
returns  
End of abk range results

## Comments

Certain API commands print multiple lines without any delimiter string to notify end of command response. This forces a control panel program to guess when the command's response string is going to end. In those scenarios, control panel can issue the legacy command followed by echo command with a delimiter string of their choosing. Once legacy command's response ends, echo command gets processed which will result in the delimiter string printed to the API client.

## echocanceller

Sets or gets the configuration of echo cancellation, which prevents users from hearing their voices loop back from the far site.

### Syntax

```
echocanceller <get|yes|no>
```

| Parameter | Description                         |
|-----------|-------------------------------------|
| red       | Line in red.                        |
| white     | Line in white.                      |
| get       | Returns the current setting.        |
| yes       | Enables the echo canceller option.  |
| no        | Disables the echo canceller option. |

### Feedback Examples

- ```
echocanceller yes
returns
echocancellerred yes
echocancellerwhite yes
```
- ```
echocanceller no
returns
echocancellerred no
echocancellerwhite no
```
- ```
echocanceller get
returns
echocancellerred no
echocancellerwhite no
```

Comments

This option is enabled by default. Polycom strongly recommends that you do not turn off echo cancellation except when using an external microphone system with its own built-in echo cancellation.

Sending `echocanceller yes` is equivalent to sending both `echocancellerred yes` and `echocancellerwhite yes`.

Sending `echocanceller no` is equivalent to sending both `echocancellerred no` and `echocancellerwhite no`.

User interface screen location: **System > Admin Settings > Audio** (page 2):
Echo Canceller

See Also

You can also use the [echocancellerred](#) command on page 4-92 and [echocancellerwhite](#) command on page 4-93.

echocancelledred

Sets or gets the line in red (right) echo canceller setting.

Syntax

```
echocancelledred <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the echo canceller option for red line in.
no	Disables the echo canceller option for red line in.

Examples

- echocancelledred no
returns
echocancelledred no
- echocancelledred yes
returns
echocancelledred yes
- echocancelledred get
returns
echocancelledred yes

Comments

User interface screen location: **System > Admin Settings > Audio** (page 2):
Echo Canceller

echocancellerwhite

Sets or gets the line in white (left) echo canceller setting.

Syntax

```
echocancellerwhite <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the echo canceller option for white line in.
no	Disables the echo canceller option for white line in.

Feedback Examples

- echocancellerwhite no
returns
echocancellerwhite no
- echocancellerwhite yes
returns
echocancellerwhite yes
- echocancellerwhite get
returns
echocancellerwhite yes

Comments

User interface screen location: **System > Admin Settings > Audio** (page 2):
Echo Canceller

enablefirewalltraversal

Sets or gets the **Enable NAT/Firewall Traversal** setting. This feature requires an Edgewater session border controller that supports H.460.

Syntax

```
enablefirewalltraversal <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the firewall traversal feature.
no	Disables the firewall traversal feature.

Feedback Examples

- enablefirewalltraversal yes
returns
enablefirewalltraversal yes
- enablefirewalltraversal no
returns
enablefirewalltraversal no
- enablefirewalltraversal get
returns
enablefirewalltraversal no

Comments

User interface screen location: **System > Admin Settings > Network > IP > Firewall (page 2): Enable NAT/Firewall Traversal**

enablepvec

Sets or gets the PVEC (Polycom Video Error Concealment) setting on the system.

Syntax

```
enablepvec <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the PVEC option.
no	Disables the PVEC option.

Feedback Examples

- enablepvec yes
returns
enablepvec yes
- enablepvec no
returns
enablepvec no
- enablepvec get
returns
enablepvec no

Comments

This option is enabled by default.

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service: Enable PVEC**

enablersvp

Sets or gets the RSVP (Resource Reservation Setup Protocol) setting on the system, which requests that routers reserve bandwidth along an IP connection path.

Syntax

```
enablersvp <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the RSVP option.
no	Disables the RSVP option.

Feedback Examples

- enablersvp yes
returns
enablersvp yes
- enablersvp no
returns
enablersvp no
- enablersvp get
returns
enablersvp no

Comments

This option is enabled by default.

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service: Enable RSVP**

enablesnmp

Sets or gets the SNMP configuration.

Syntax

```
enablesnmp <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the SNMP option.
no	Disables the SNMP option.

Feedback Examples

- enablesnmp yes
returns
enablesnmp yes
- enablesnmp no
returns
enablesnmp no
- enablesnmp get
returns
enablesnmp no

Comments

Changing this setting causes the system to restart. This option is enabled by default.

User interface screen location: **System > Admin Settings > Global Services > SNMP: Enable SNMP**

encryption

Sets or gets the AES encryption mode for the system.

Syntax

```
encryption <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Use encryption when the far site is capable of encryption.
no	Disables encryption.

Feedback Examples

- encryption yes
returns
encryption yes
- encryption no
returns
encryption no
- encryption get
returns
encryption no

Comments

You cannot use this command while a call is in progress.

The encryption options are only visible on the user interface if an encryption key has been entered.

User interface screen location: **System > Admin Settings > General Settings > Security (page 2): AES Encryption**

exit

Ends the API command session.

Syntax

```
exit
```

Feedback Examples

- ```
exit
```

```
returns
```

```
Connection to host lost.
```

## Comments

This command ends a Telnet session. For serial sessions, this command effectively starts a new session.

## farcontrolnearcamera

Sets or gets far control of the near camera, which allows far sites to control the camera on your system.

### Syntax

```
farcontrolnearcamera <get|yes|no>
```

| Parameter | Description                                                                         |
|-----------|-------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                        |
| yes       | Allows the far site to control the near camera if the far site has this capability. |
| no        | Disables far control of the near camera.                                            |

### Feedback Examples

- farcontrolnearcamera yes  
returns  
farcontrolnearcamera yes
- farcontrolnearcamera no  
returns  
farcontrolnearcamera no
- farcontrolnearcamera get  
returns  
farcontrolnearcamera no

### Comments

User interface screen location: **System > Admin Settings > Cameras: Far Control of Near Camera**

## farnametimedisplay

Sets or gets the length of time the far-site name is displayed on the system.

### Syntax

```
farnametimedisplay off
farnametimedisplay <get | on | 15 | 30 | 60 | 120>
```

| Parameter          | Description                                                                              |
|--------------------|------------------------------------------------------------------------------------------|
| off                | Disables the far site name display.                                                      |
| get                | Returns the current setting.                                                             |
| on                 | Displays the far site name for the duration of the call.                                 |
| 15   30   60   120 | Specifies the number of seconds to display the far site name at the beginning of a call. |

### Feedback Examples

- ```
farnametimedisplay off
returns
farnametimedisplay off
```
- ```
farnametimedisplay on
returns
farnametimedisplay on
```
- ```
farnametimedisplay 60
returns
farnametimedisplay 60
```
- ```
farnametimedisplay get
returns
farnametimedisplay 60
```

### Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Call Settings (page 2): Far Site Name Display Time**

## flash

Flashes the analog phone call, either an analog phone or a SoundStation VTX 1000.

### Syntax

```
flash ["callid"]
flash ["callid"] ["duration"]
```

| Parameter | Description                         |
|-----------|-------------------------------------|
| callid    | Specifies the callid to flash.      |
| duration  | Specifies the pulse duration in ms. |

### Feedback Examples

- `flash 34 5`  
returns  
`flash 34 5`  
and flashes callid 34 for 5 ms



# gabk

Returns global directory (address book) entries.

## Syntax

```
gabk all
gabk batch {0..59}
gabk batch define "start_no" "stop_no"
gabk batch search "pattern" "count"
gabk letter {a..z}
gabk range "start_no" "stop_no"
gabk refresh
```

| Parameter  | Description                                                                                                                                                                                                                                                          |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| all        | Returns all entries in the global directory.                                                                                                                                                                                                                         |
| batch      | Returns a batch of global directory entries in batches (batch size determined by global directory). Requires a batch number, which must be an integer in the range {0..59}. Batches should be requested sequentially to ensure receiving a complete list of entries. |
| define     | Returns a batch of entries in the range defined by "start_no" to "stop_no." Polycom recommends using <code>gabk range</code> instead of this command.                                                                                                                |
| "start_no" | Specifies the beginning of the range of entries to return.                                                                                                                                                                                                           |
| "stop_no"  | Specifies the end of the range of entries to return.                                                                                                                                                                                                                 |
| search     | Specifies a batch search.                                                                                                                                                                                                                                            |
| "pattern"  | Specifies pattern to match for the batch search.                                                                                                                                                                                                                     |
| "count"    | Specifies the number of entries to list that match the pattern.                                                                                                                                                                                                      |
| letter     | Returns entries beginning with the letter specified from the range {a..z}. Requires one or two alphanumeric characters. Valid characters are:<br>- _ / ; @ , . \<br>0 through 9, a through z                                                                         |
| range      | Returns global directory entries numbered "start_no" through "stop_no". Requires two integers.                                                                                                                                                                       |
| refresh    | Gets a more current copy of the global directory.                                                                                                                                                                                                                    |

## Feedback Examples

```
gabk all
```

Feedback is similar to feedback returned from the [abk](#) command on page 4-5, but preceded with `gabk`.

# gabpassword

Sets or gets the password to gain access to the Global Directory Server.

## Syntax

```
gabpassword [{1..5}|all] get
gabpassword [{1..5}] set ["password"]
```

| Parameter  | Description                                                                                                                                                                                   |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| {1..5}     | References GDS server {1..5}.                                                                                                                                                                 |
| all        | Returns all current entries.                                                                                                                                                                  |
| get        | Returns the current setting.                                                                                                                                                                  |
| set        | Sets the GDS password to "password". To erase the current setting, omit "password".                                                                                                           |
| "password" | Password to access the GDS server. Valid characters are: a through z (lower and uppercase), -, _, @, /, ;, ,, ., \, 0 through 9. Enclose the string in quotation marks if it includes spaces. |

## Feedback Examples

- ```
gabpassword set gabpass
returns
gabpassword gabpass
```
- ```
gabpassword get
returns
gabpassword gabpass
```
- ```
gabpassword 1 set gabpass
returns
gabpassword 1 gabpass
```
- ```
gabpassword 1 get
returns
gabpassword 1 gabpass
```



This command might not return the current password in correct case-sensitive format.

## Comments

This command cannot be used unless the [adminpassword](#) command on page 4-8 (or the Remote Access password in the user interface) has been set. User interface screen location: **System > Admin Settings > Global Services > Directory Servers: Password**

## gabserverip

Sets or gets the IP address of the Global Directory Server.

### Syntax

```
gabserverip [{1..5}|all] get
gabserverip [{1..5}] set ["xxx.xxx.xxx.xxx"]
```

| Parameter         | Description                                                                                                                                            |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| {1..5}            | References GDS server {1..5}.                                                                                                                          |
| get               | Returns the current setting.                                                                                                                           |
| all               | References all GDS servers.                                                                                                                            |
| set               | Sets the GDS server's IP address when followed by the parameter "xxx.xxx.xxx.xxx". To erase the current setting, omit the "xxx.xxx.xxx.xxx" parameter. |
| "xxx.xxx.xxx.xxx" | IP address of the GDS server. Can be a numeric or character string.                                                                                    |

### Feedback Examples

- ```
gabserverip set
returns
gabserverip <empty>
```
- ```
gabserverip set gab.polycom.com
returns
gabserverip gab.polycom.com
```
- ```
gabserverip get
returns
gabserverip gab.polycom.com
```
- ```
gabserverip 2 set 192.168.1.101
returns
gabserverip 2 192.168.1.101
```
- ```
gabserverip all get
returns
gabserverip 1 gab.polycom.com
gabserverip 2 192.168.1.101
gabserverip 3 <empty>
gabserverip 4 <empty>
gabserverip 5 <empty>
```

Comments

User interface screen location: **System > Admin Settings > Global Services > Directory Servers: Global Directory (GDS)**

gatekeeperip

Sets or gets the IP address of the primary gatekeeper.

Syntax

```
gatekeeperip get
gatekeeperip set ["xxx.xxx.xxx.xxx"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the gatekeeper IP address when followed by the "xxx.xxx.xxx.xxx" parameter. To erase the current setting, omit "xxx.xxx.xxx.xxx".
"xxx.xxx.xxx.xxx"	IP address of the gatekeeper.

Feedback Examples

- ```
gatekeeperip set 192.168.1.205
returns
gatekeeperip 192.168.1.205
```
- ```
gatekeeperip get
returns
gatekeeperip 192.168.1.205
```

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 2): Gatekeeper IP Address**

The Use Gatekeeper option on the same page must be set to Auto or Specify for the Gatekeeper IP Address to be available.

gatekeeperpin

Sets or gets the gatekeeper Authentication Pin.

Syntax

```
gatekeeperpin get
gatekeeperpin set ["pin"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the Authentication PIN when followed by the "pin" parameter. To erase the current setting, omit the "pin" parameter.
"pin"	Authentication PIN for the gatekeeper.

Feedback Examples

- gatekeeperpin set
returns
gatekeeperpin <empty>
- gatekeeperpin set 12345
returns
gatekeeperpin 12345
- gatekeeperpin get
returns
gatekeeperpin 12345

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 2): Authentication PIN**

The Use Gatekeeper option on the same page must be set to Specify with PIN for Authentication PIN to be available.

gatewayareacode

Sets or gets the gateway area code.

Syntax

```
gatewayareacode get
gatewayareacode set ["areacode"]
```

Parameter	Description
get	Returns the area code for the gateway.
set	Sets the area code when followed by the "areacode" parameter. To erase the current setting, omit "areacode".
"areacode"	Numeric string specifying the area code.

Feedback Examples

- gatewayareacode get
returns
gatewayareacode <empty>
- gatewayareacode set 512
returns
gatewayareacode 512
- gatewayareacode get
returns
gatewayareacode 512

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 4): Area Code**

gatewaycountrycode

Sets or gets the gateway country code.

Syntax

```
gatewaycountrycode get
gatewaycountrycode set ["countrycode"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the gateway country code when followed by the "countrycode" parameter. To erase the current setting, omit "countrycode".
"countrycode"	Numeric string specifying the gateway country code.

Feedback Examples

- gatewaycountrycode set 1
returns
gatewaycountrycode 1
- gatewaycountrycode get
returns
gatewaycountrycode 1

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 4): Country Code**

gatewayext

Sets or gets the gateway extension number.

Syntax

```
gatewayext get
gatewayext set ["extension"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the gateway extension number when followed by the "extension" parameter. To erase the current setting, omit "extension".
"extension"	Numeric string specifying the gateway extension.

Feedback Examples

- gatewayext set 59715
returns
gatewayext 59715
- gatewayext get
returns
gatewayext 59715

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings** (page 4): **H.323 Extension (E.164)**

gatewaynumber

Sets or gets the gateway number.

Syntax

```
gatewaynumber get
gatewaynumber set ["number"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the gateway number when followed by the "number" parameter. To erase the current setting, omit "number".
"number"	Numeric string specifying the gateway number.

Feedback Examples

- gatewaynumber set 5551212
returns
gatewaynumber 5551212
- gatewaynumber get
returns
gatewaynumber 5551212

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 4): Number**

gatewaynumbertype

Sets or gets the Gateway Number Type, which can be either Direct Inward Dial (DID) or Number+Extension.

Syntax

```
gatewaynumbertype <get|did|number+extension>
```

Parameter	Description
get	Returns the current setting.
did	Indicates that the gateway number is a direct inward dial number; it has no extension.
number+extension	Indicates that the gateway number includes an extension. This option allows the call to go through directly (it dials the Gateway Number + ## + Extension as one number).

Feedback Examples

- ```
gatewaynumbertype did
returns
gatewaynumbertype direct_inward_dial
```
- ```
gatewaynumbertype number+extension
returns
gatewaynumbertype number_plus_extension
```
- ```
gatewaynumbertype get
returns
gatewaynumbertype number_plus_extension
```

### Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 4): Gateway Number Type**

## gatewayprefix

Sets or gets the gateway prefixes for the corresponding speeds.

### Syntax

```
gatewayprefix get "valid speed"
gatewayprefix set "valid speed" ["value"]
```

| Parameter     | Description                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get           | When followed by the "valid speed" parameter, returns the current value for this speed.                                                                                                                                                                                                                                                                                                                        |
| "valid speed" | Valid speeds are: 56, 64, 2x56, 112, 2x64, 128, 168, 192, 224, 256, 280, 320, 336, 384, 392, 7x64, 8x56, 504, 512, 560, 576, 616, 640, 672, 704, 728, 768, 784, 832, 840, 16x56, 14x64, 952, 960, 1008, 1024, 1064, 1088, 1120, 1152, 1176, 1216, 1232, 1280, 1288, 24x56, 21x64, 1400, 1408, 1456, 1472, 1512, 1536, 1568, 1600, 1624, 1664, 1680, 1728, 1736, 32x56, 28x64, 1848, 1856, 1904, and 1920 kbps. |
| set           | Sets the gateway prefix when followed by the "value" parameter. To erase the current setting, omit "value".                                                                                                                                                                                                                                                                                                    |
| "value"       | Prefix (code) used for a particular call speed. Consult your gateway instruction manual to determine which codes are appropriate.                                                                                                                                                                                                                                                                              |

### Feedback Examples

- ```
gatewayprefix set 168 90
returns
gatewayprefix 168 90
```
- ```
gatewayprefix get 168
returns
gatewayprefix 168 90
```

### Comments

Some gateways require a number to be prepended (prefix) to the gateway number. The prefix identifies which gateway is used to dial a call at a particular data rate.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 4): Prefix**

## gatewaysetup

Lists all available speeds and values at once.

### Syntax

gatewaysetup

### Feedback Examples

- gatewaysetup  
returns  
56            <empty>       <empty>  
64            #14            #16  
2x56        #222        #333  
112        #444        #555  
2x64        <empty>     <empty>  
and so on.

### Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings** (page 4): **Prefix and Suffix**

## gatewaysuffix

Sets or gets the gateway suffix.

### Syntax

```
gatewaysuffix get "valid speed"
gatewaysuffix set "valid speed" ["value"]
```

| Parameter     | Description                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get           | Returns the current value for this speed.                                                                                                                                                                                                                                                                                                                                                                      |
| "valid speed" | Valid speeds are: 56, 64, 2x56, 112, 2x64, 128, 168, 192, 224, 256, 280, 320, 336, 384, 392, 7x64, 8x56, 504, 512, 560, 576, 616, 640, 672, 704, 728, 768, 784, 832, 840, 16x56, 14x64, 952, 960, 1008, 1024, 1064, 1088, 1120, 1152, 1176, 1216, 1232, 1280, 1288, 24x56, 21x64, 1400, 1408, 1456, 1472, 1512, 1536, 1568, 1600, 1624, 1664, 1680, 1728, 1736, 32x56, 28x64, 1848, 1856, 1904, and 1920 kbps. |
| set           | Sets the gateway suffix when followed by the "value" parameter. To erase the current setting, omit "value".                                                                                                                                                                                                                                                                                                    |
| "value"       | Suffix (code) used for a particular call speed. Consult your gateway instruction manual to determine which codes are appropriate. Use quotation marks around a compound name or strings that contain spaces. For example: "united states" or "111 222 333".                                                                                                                                                    |

### Feedback Examples

- ```
gatewaysuffix set 192 11
returns
gatewaysuffix 192 11
```
- ```
gatewaysuffix get 192
returns
gatewaysuffix 192 11
```

### Comments

Some gateways require a number to be appended (suffix) to the gateway number. The suffix identifies which gateway is used to dial a call at a particular data rate.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings** (page 4): **Suffix**

## gendial

Generates DTMF dialing tones over a video call.

### Syntax

```
gendial <{0..9}|#|*>
```

| Parameter | Description                                                     |
|-----------|-----------------------------------------------------------------|
| {0..9}    | Generates the DTMF tone corresponding to telephone buttons 0-9. |
| #         | Generates the DTMF tone corresponding to a telephone # button.  |
| *         | Generates the DTMF tone corresponding to a telephone * button.  |

### Feedback Examples

- gendial 2  
returns  
gendial 2  
and causes the system to produce the DTMF tone corresponding to a telephone's 2 button

### Comments

User interface screen location: On the near or far video screen, press # on the remote control to access a keypad for generating tones.

## gentialtonepots (deprecated)

Generates DTMF dialing tones over an analog phone line. This command has been deprecated. Polycom recommends using the [gential](#) command on page 4-116.

### Syntax

```
gentialtonepots <{0..9}|#|*>
```

| Parameter | Description                                                     |
|-----------|-----------------------------------------------------------------|
| {0..9}    | Generates the DTMF tone corresponding to telephone buttons 0-9. |
| #         | Generates the DTMF tone corresponding to a telephone # button.  |
| *         | Generates the DTMF tone corresponding to a telephone * button.  |

### Feedback Examples

- ```
gentialtonepots 2
```

returns

```
gentialtonepots 2
```

and causes the system to produce the DTMF tone corresponding to a telephone's 2 button

See Also

To generate DTMF tones over video, use the [gential](#) command on page 4-116.

generatetone

Turns the test tone on or off. The tone is used to check the monitor audio cable connections or to monitor the volume level.

Syntax

```
generatetone <on|off>
```

Parameter	Description
on	Turns on the test tone.
off	Turns off the test tone.

Feedback Examples

- generatetone on
returns
generatetone on
and the system produces a test tone
- generatetone off
returns
generatetone off
and the system stops producing a test tone

Comments

User interface screen location: **System > Diagnostics > Audio > Speaker Test**

get screen

Returns the name of the current screen so that the control panel programmer knows which screen the user interface is currently displaying.

Syntax

```
get screen
```

Feedback Examples

- ```
get screen
returns
screen: near
```
- ```
get screen  
returns  
screen: makeacall
```
- ```
get screen
returns
screen: generatetone
```

### See Also

You can also use the [screen](#) command on page 4-237.

## getcallstate

Gets the state of the calls in the current conference.

### Syntax

```
getcallstate
```

### Feedback Examples

- `getcallstate`  
returns  
cs: call[34] speed[384] dialstr[192.168.1.101] state[connected]  
cs: call[1] inactive  
cs: call[2] inactive

### Comments

User interface screen location: **System > Diagnostics > Call Statistics**

### See Also

To register the shell session to receive notifications about call state activities, see the [callstate](#) command on page 4-39.

## gmscity

Sets or gets the Global Management System™ city information.

### Syntax

```
gmscity get
gmscity set ["city"]
```

| Parameter | Description                                                                                                                   |
|-----------|-------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                                  |
| set       | Sets the Global Management System city name when followed by the "city" parameter. To erase the current setting, omit "city". |
| "city"    | Character string specifying the city. Enclose the string in quotation marks if it includes spaces. Example: "San Antonio"     |

### Feedback Examples

- gmscity get  
returns  
gmscity <empty>
- gmscity set Paris  
returns  
gmscity Paris
- gmscity get  
returns  
gmscity Paris

### Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: City**

## gmscontactemail

Sets or gets the Global Management System contact E-mail information.

### Syntax

```
gmscontactemail get
gmscontactemail set ["email"]
```

| Parameter | Description                                                                                                                                  |
|-----------|----------------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current contact E-mail address.                                                                                                  |
| set       | Sets the Global Management system contact E-mail address when followed by the "email" parameter. To erase the current setting, omit "email". |
| "email"   | Alphanumeric string specifying the E-mail address.                                                                                           |

### Feedback Examples

- ```
gmscontactemail get
returns
gmscontactemail <empty>
```
- ```
gmscontactemail set john_polycom@polycom.com
returns
gmscontactemail john_polycom@polycom.com
```
- ```
gmscontactemail get
returns
gmscontactemail john_polycom@polycom.com
```

Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: Contact Email**

gmscontactfax

Sets or gets the Global Management System contact fax information

Syntax

```
gmscontactfax get
gmscontactfax set ["fax number"]
```

Parameter	Description
get	Returns the current contact fax information.
set	Sets the Global Management System contact fax information when followed by the "fax number" parameter. To erase the current setting, omit "fax number".
"fax number"	Character string specifying the fax number. Enclose the string in quotation marks if it includes spaces. Example: "408 555 2323"

Feedback Examples

- ```
gmscontactfax get
returns
gmscontactfax <empty>
```
- ```
gmscontactfax set "408 555 2323"
returns
gmscontactfax 4085552323
```
- ```
gmscontactfax get
returns
gmscontactfax 4085552323
```

### Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: Contact Fax**

## gmscontactnumber

Sets or gets the Global Management System contact number information.

### Syntax

```
gmscontactnumber get
gmscontactnumber set ["number"]
```

| Parameter | Description                                                                                                                            |
|-----------|----------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current contact number.                                                                                                    |
| set       | Sets the Global Management System contact number when followed by the "number" parameter. To erase the current setting, omit "number". |
| "number"  | Numeric string specifying the contact number. Enclose the string in quotation marks if it includes spaces.<br>Example: "408 555 2323"  |

### Feedback Examples

- ```
gmscontactnumber get
returns
gmscontactnumber <empty>
```
- ```
gmscontactnumber set "408 555 2323"
returns
gmscontactnumber 4085552323
```
- ```
gmscontactnumber get
returns
gmscontactnumber 4085552323
```

Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: Contact Number**

gmscontactperson

Sets or gets the Global Management System contact person information.

Syntax

```
gmscontactperson get
gmscontactperson set ["person"]
```

Parameter	Description
get	Returns the current contact person information.
set	Sets the Global Management System contact person name when followed by the "person" parameter. To erase the current setting, omit "person".
"person"	Character string specifying the contact person. Enclose the string in quotation marks if it includes spaces. Example: "Mary Polycom"

Feedback Examples

- ```
gmscontactperson get
returns
gmscontactperson <empty>
```
- ```
gmscontactperson set "Mary Polycom"
returns
gmscontactperson "Mary Polycom"
```
- ```
gmscontactperson get
returns
gmscontactnumber "Mary Polycom"
```

### Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: Contact Person**

## gmscountry

Sets or gets the Global Management System country information.

### Syntax

```
gmscountry get
gmscountry set ["countryname"]
```

| Parameter     | Description                                                                                                                                           |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| get           | Returns the current country setting.                                                                                                                  |
| set           | Sets the Global Management System country information when followed by the "countryname" parameter. To erase the current setting, omit "countryname". |
| "countryname" | Character string specifying the country. Enclose the string in quotation marks if it includes spaces. Example: "United States"                        |

### Feedback Examples

- ```
gmscountry get
returns
gmscountry <empty>
```
- ```
gmscountry set Argentina
returns
gmscountry Argentina
```
- ```
gmscountry get
returns
gmscountry Argentina
```

Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: Country**

gmsstate

Sets or gets the Global Management System state information.

Syntax

```
gmsstate get
gmsstate set ["state"]
```

Parameter	Description
get	Returns the current state information.
set	Sets the Global Management System state information when followed by the "state" parameter. To erase the current setting, omit the "state" parameter.
"state"	Character string specifying the state information. Enclose the string in quotation marks if it includes spaces. Example: "West Virginia"

Feedback Examples

- ```
gmsstate get
returns
gmsstate <empty>
```
- ```
gmsstate set Texas
returns
gmsstate Texas
```
- ```
gmsstate get
returns
gmsstate Texas
```

### Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: State/Province**

## gmstechsupport

Sets or gets the Global Management System technical support phone number.

### Syntax

```
gmstechsupport get
gmstechsupport set ["tech_support_digits"]
```

| Parameter             | Description                                                                                                                                            |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| get                   | Returns the current tech support phone number information.                                                                                             |
| set                   | Sets the technical support information when followed by the "tech_support_digits" parameter. To erase the current setting, omit "tech_support_digits". |
| "tech_support_digits" | Numeric string specifying the tech support phone number. Enclose the string in quotation marks if it includes spaces. Example: "408 555 2323"          |

### Feedback Examples

- ```
gmstechsupport get
returns
gmstechsupport <empty>
```
- ```
gmstechsupport set "408 555 2323"
returns
gmstechsupport 4085552323
```
- ```
gmstechsupport get
returns
gmstechsupport 4085552323
```

Comments

User interface screen location: **System > Admin Settings > Global Services > My Information: Tech Support**

gmsurl

Sets or gets the URL of the Global Management System server that manages your system. This command automatically appends `/pwx/vs_status.asp`.

Syntax

```
gmsurl get {1..10}
gmsurl set {1..10} "xxx.xxx.xxx.xxx"
gmsurl get all
```

Parameter	Description
get	Returns the current URL information for a selected server. A server must be specified.
{1..10}	Global Management System server number. The primary Global Management System server that performs account validation is always server 1.
set	Sets the current URL information for a selected server. A server must be specified.
all	Returns information for all Global Management System servers.

Feedback Examples

- ```
gmsurl set 1 192.168.1.101
returns
gmsurl 1 192.168.1.101/pwx/nx_status.asp
```
- ```
gmsurl get 1
returns
gmsurl 1 192.168.1.101/pwx/nx_status.asp
```

Comments

When you are registered with the Global Management System, this information is automatically configured.

User interface screen location: **System > Admin Settings > Global Services > Management Servers**

graphicsmonitor

Sets or gets the graphics monitor configuration for one of these choices: monitor1, monitor2, or a Visual Concert VSX monitor.

Syntax

```
graphicsmonitor <get|tv|fxvga|visualconcert|1|2|vcnx>
```

Parameter	Description
get	Returns the current setting.
tv	Deprecated.
fxvga	Deprecated.
visualconcert	Deprecated.
1	Selects Monitor 1 as the graphics monitor.
2	Selects Monitor 2 as the graphics monitor.
vcnx	Selects Visual Concert VSX as the graphics monitor. Enable this option if Visual Concert VSX is connected to your system and the graphics monitor is directly connected to Visual Concert VSX. This allows your system to display your computer desktop on your system's VGA monitor.

Feedback Examples

- ```
graphicsmonitor 1
returns
graphicsmonitor 1
```
- ```
graphicsmonitor vcnx
returns
graphicsmonitor vcnx
```
- ```
graphicsmonitor get
returns
graphicsmonitor vcnx
```

### Comments

When you use this command to set the graphics monitor, you automatically turn off the other two choices.

User interface screen location: **System > Admin Settings > Monitors > Monitors: Graphics Content Display**

## h239enable

Sets or gets the H.239 People+Content™ setting.

### Syntax

```
h239enable get
h239enable <yes|no>
```

| Parameter | Description                                  |
|-----------|----------------------------------------------|
| get       | Returns the current setting.                 |
| yes       | Enables H.239 People+Content on the system.  |
| no        | Disables H.239 People+Content on the system. |

### Feedback Examples

- h239enable yes  
returns  
h239enable yes
- h239enable no  
returns  
h239enable no
- h239enable get  
returns  
h239enable no

### Comments

User interface screen location: **System > Admin Settings > Network > Call Preference: Enable H.239**

## h323name

Sets or gets the system's H.323 name.

### Syntax

```
h323name get
h323name set ["H.323name"]
```

| Parameter   | Description                                                                                                                         |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------|
| get         | Returns the current setting.                                                                                                        |
| set         | Sets the H.323 name when followed by the "H.323name" parameter. To erase this setting, omit the "H.323name" parameter.              |
| "H.323name" | Character string specifying the H.323 name. Use quotation marks around strings that contain spaces. For example: "Polycom VSX Demo" |

### Feedback Examples

- ```
h323name set My
returns
h323name my
```
- ```
h323name set "Polycom VSX Demo"
returns
h323name "polycom vsx demo"
```
- ```
h323name get
returns
h323name "polycom vsx demo"
```

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings: H.323 Name**

h331audiomode

Set or gets the audio protocol sent during H.331 calls. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
h331audiomode
<get|g729|g728|g711u|g711a|g722-56|g722-48|g7221-16|g7221-24|
g7221-32|siren14|siren14stereo|off>
```

Parameter	Description
get	Returns the current setting.
g729 g728 g711u g711a g722-56 g722-48 g7221-16 g7221-24 g7221-32 siren14 siren14stereo	Sets the audio protocol to this value for H.331 calls.
off	Turns audio mode off for H.331 calls.

Feedback Examples

- h331audiomode g.728
returns
h331audiomode g.728
- h331audiomode "siren 14"
returns
h331audiomode "siren 14"
- h331audiomode off
returns
h331audiomode off

Comments

This value cannot be changed during a call.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 5): Audio Protocol**

h331dualstream

Set or gets the dual stream setting used for H.331 calls. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
h331dualstream <get|on|off>
```

Parameter	Description
get	Returns the current setting.
on	Turns on dual stream for H.331 calls.
off	Turns off dual stream for H.331 calls.

Feedback Examples

- h331dualstream on
returns
h331dualstream on
- h331dualstream off
returns
h331dualstream off
- h331dualstream get
returns
h331dualstream off

Comments

This value cannot be changed during a call.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 5): Enable People+Content**

h331framerate

Sets or gets the frame rate sent during H.331 calls. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
h331framerate <get|30|15|10|7.5>
```

Parameter	Description
get	Returns the current setting.
30 15 10 7.5	Sets the frame rate to this value for H.331 calls.

Feedback Examples

- ```
h331framerate 15
returns
h331framerate 15
```
- ```
h331framerate 30
returns
h331framerate 30
```
- ```
h331framerate get
returns
h331framerate 30
```

### Comments

This value cannot be changed during a call.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 5): Frame Rate**

## h331videofORMAT

Sets or gets the video format for H.331 calls. This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
h331videofORMAT <get|fcif>
```

| Parameter | Description                                    |
|-----------|------------------------------------------------|
| get       | Returns the current setting.                   |
| fcif      | Sets the video format to FCIF for H.331 calls. |

### Feedback Examples

- h331videofORMAT fcif  
returns  
h331videofORMAT fcif
- h331videofORMAT get  
returns  
h331videofORMAT fcif

### Comments

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 5): Video Format**

## h331videoprotocol

Sets or gets the H.331 video protocol sent during H.331 calls. This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
h331videoprotocol <get|h264|h263+|h263|h261>
```

| Parameter            | Description                                            |
|----------------------|--------------------------------------------------------|
| get                  | Returns the current setting.                           |
| h264 h263+ h263 h261 | Sets the video protocol to this value for H.331 calls. |

### Feedback Examples

- h331videoprotocol h264  
returns  
h331videoprotocol h264
- h331videoprotocol h263+  
returns  
h331videoprotocol h263+
- h331videoprotocol get  
returns  
h331videoprotocol h263+

### Comments

This value cannot be changed during a call.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 5): Video Protocol**

# hangup

Hangs up the current video or phone call.

## Syntax

```
hangup phone
hangup video ["callid"]
hangup all
```

| Parameter | Description                                                                                                                       |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------|
| phone     | Disconnects the current analog phone (audio-only) site.                                                                           |
| video     | Disconnects the current video call. If the "callid" parameter is omitted, the system disconnects all video far sites in the call. |
| all       | Disconnects all video and audio sites in the call.                                                                                |

## Feedback Examples

- ```
hangup video 2
returns
hanging up video call
cleared: call[34]
dialstring[IP:192.168.1.101 NAME:Polycom VSX Demo]
ended: call[34]
and disconnects the specified site, leaving other sites connected
```

Comments

After sending the `hangup` command, feedback that the call has ended can take up to 15 seconds.

help

Returns a simple or detailed list of commands when used with the parameters `all`, `help`, `string`, or `syntax`. Also switches help display mode when used with the parameters `verbose` or `terse`. This command without parameters returns the list of command names only.

Syntax

```
help [all|help|"string"]
help [verbose|terse|syntax]
help apropos "string"
```

Parameter	Description
<code>all</code>	Describes the various types of help described in this section.
<code>help</code>	Returns help for using the <code>help</code> command.
<code>"string"</code>	Returns detailed help for any commands beginning with <code>"string"</code> . Use quotation marks around strings that contain spaces. For example: <code>"display call"</code>
<code>verbose</code>	Selects verbose mode, which shows syntax and help for commands.
<code>terse</code>	Selects terse mode, which shows help for commands without showing syntax.
<code>syntax</code>	Returns the help syntax conventions.
<code>apropos</code>	Returns help on any command or command description containing <code>"string"</code> .

Feedback Examples

- ```
help terse
returns
current help mode is: terse
```
- ```
help dualmonitor
returns
dualmonitor <get|yes|no>
-Get/set dual monitor emulation.
```

history

Lists the last commands used in the current session.

Syntax

history

Feedback Examples

- history
returns
1 ipaddress set 192.168.1.101
2 hostname set My
3 lanport 100fdx
4 callstate register
5 lanport get
6 history

Comments

If more than 64 commands have been issued, only the last 64 are displayed, with the most recent always at the bottom.

homecallquality

Sets or gets whether users are allowed to select the bandwidth for calls from the home screen.

Syntax

```
homecallquality <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Displays the Call Quality menu on the home screen.
no	Removes the Call Quality menu from the home screen.

Feedback Examples

- homecallquality yes
returns
homecallquality yes
- homecallquality no
returns
homecallquality no
- homecallquality get
returns
homecallquality no

Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: Call Quality**

homemultipoint

Sets or gets whether users are allowed to access the multipoint dialing screen via a Multipoint button on the home screen.

Syntax

```
homemultipoint <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Displays the Multipoint button on the home screen.
no	Removes the Multipoint button from the home screen.

Feedback Examples

- ```
homemultipoint yes
returns
homemultipoint yes
```
- ```
homemultipoint no
returns
homemultipoint no
```
- ```
homemultipoint get
returns
homemultipoint no
```

### Comments

This option is only available if multipoint calling is enabled.

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: Multipoint**



## homerecentcalls

Sets or gets whether users are allowed to access a list of recent calls made with the system by displaying the Recent Calls button on the home screen.

### Syntax

```
homerecentcalls <get|yes|no>
```

| Parameter | Description                                           |
|-----------|-------------------------------------------------------|
| get       | Returns the current setting.                          |
| yes       | Displays the Recent Calls button on the home screen.  |
| no        | Removes the Recent Calls button from the home screen. |

### Feedback Examples

- homerecentcalls yes  
returns  
homerecentcalls yes
- homerecentcalls no  
returns  
homerecentcalls no
- homerecentcalls get  
returns  
homerecentcalls no

### Comments

This option is only available if the Call Detail Report option is enabled.

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings (page 2): Recent Calls**

## homesystem

Sets or gets whether users are allowed to access the system screen by displaying the System button on the home screen.

### Syntax

```
homesystem <get|yes|no>
```

| Parameter | Description                                     |
|-----------|-------------------------------------------------|
| get       | Returns the current setting.                    |
| yes       | Displays the System button on the home screen.  |
| no        | Removes the System button from the home screen. |

### Feedback Examples

- homesystem yes  
returns  
homesystem yes
- homesystem no  
returns  
homesystem no
- homesystem get  
returns  
homesystem no

### Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: System**

## homesystemname

Sets or gets whether to display the name of the system on the home screen, above the PIP window.

### Syntax

```
homesystemname <get|yes|no>
```

| Parameter | Description                                   |
|-----------|-----------------------------------------------|
| get       | Returns the current setting.                  |
| yes       | Displays the system name on the home screen.  |
| no        | Removes the system name from the home screen. |

### Feedback Examples

- homesystemname yes  
returns  
homesystemname yes
- homesystemname no  
returns  
homesystemname no
- homesystemname get  
returns  
homesystemname no

### Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings (page 2): System Name**

## hostname

Sets or gets the LAN host name, which is assigned to the system for TCP/IP configuration and can be used in place of an IP address when dialing IP calls.

### Syntax

```
hostname get
hostname set ["hostname"]
```

| Parameter  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get        | Returns the current setting.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| set        | Sets the system's LAN host name when followed by the "hostname" parameter. If "hostname" is omitted, the system automatically sets it to Admin.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| "hostname" | Character string specifying the LAN host name of the system. The LAN host name follows these format rules:<br>Starts with a letter (A-a to Z-z). It is not case sensitive.<br>Ends with a letter (A-a to Z-z) or a number (0 to 9).<br>May include letters, numbers, and a hyphen.<br>May not be longer than 63 characters.<br><b>Note:</b> The LAN host name is initialized during the out-of-box setup sequence. The LAN host name is the same as the system name, if the system name conforms to the rules above. If the system name does not conform to these rules, the invalid characters are removed from the system name. If the resulting string is empty, the default LAN host name is Admin. |

### Feedback Examples

- ```
hostname set
returns
hostname ADMIN
restart system for changes to take effect. restart now? <y,n>
```
- ```
hostname set "My"
returns
hostname My
restart system for changes to take effect. restart now? <y,n>
```
- ```
hostname get
returns
hostname My
```

Comments

A LAN host name is required; it cannot be deleted or left blank. After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties: Host Name**

ipaddress

Sets or gets the LAN IP address of the system.

Syntax

```
ipaddress get
ipaddress set "xxx.xxx.xxx.xxx"
```

Parameter	Description
get	Returns the current setting.
set	Sets the LAN IP address to the "xxx.xxx.xxx.xxx" parameter. This setting can only be changed when DHCP is off.
"xxx.xxx.xxx.xxx"	IP address of the system.

Feedback Examples

- ```
ipaddress set 192.168.1.101
returns
ipaddress 192.168.1.101
restart system for changes to take effect. restart now? <y,n>
```
- ```
ipaddress get
returns
ipaddress 192.168.1.101
```

Comments

Use this command when you need to allocate a static IP address to your system. After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties: Use the Following IP Address**

ipdialspeed

Sets or gets the valid IP dialing speed, and enables or disables the specified speed.

Syntax

```
ipdialspeed get "valid speed"
ipdialspeed set "valid speed" <on|off>
```

Parameter	Description
get	Returns the current setting. The parameter "valid speed" is required.
"valid speed"	Valid speeds are: 56, 64, 2x56, 112, 2x64, 128, 168, 192, 224, 256, 280, 320, 336, 384, 392, 7x64, 8x56, 504, 512, 560, 576, 616, 640, 672, 704, 728, 768, 784, 832, 840, 16x56, 14x64, 952, 960, 1008, 1024, 1064, 1088, 1120, 1152, 1176, 1216, 1232, 1280, 1288, 24x56, 21x64, 1400, 1408, 1456, 1472, 1512, 1536, 1568, 1600, 1624, 1664, 1680, 1728, 1736, 32x56, 28x64, 1848, 1856, 1904, and 1920 kbps.
set	Sets the IP dialing speed. The parameters "valid speed" and on or off are required.
on	Enables the specified speed.
off	Disables the specified speed.

Feedback Examples

- ```
ipdialspeed set 168 on
returns
ipdialspeed set 168 on
```
- ```
ipdialspeed set 168 off
returns
ipdialspeed set 168 off
```
- ```
ipdialspeed get 168
returns
ipdialspeed 168 off
```

### Comments

User interface screen location: **System > Admin Settings > Network > Call Preference (page 3): Preferred Speeds**

## ipisdninfo

Sets or gets whether the home screen displays IP information, ISDN information, both, or neither.

### Syntax

```
ipisdninfo <get|both|ip-only|isdn-only|none>
```

| Parameter | Description                                                     |
|-----------|-----------------------------------------------------------------|
| get       | Returns the current setting.                                    |
| both      | Displays IP and ISDN information on the home screen.            |
| ip-only   | Displays only IP information on the home screen.                |
| isdn-only | Displays only ISDN information on the home screen.              |
| none      | Does not display any IP or ISDN information on the home screen. |

### Feedback Examples

- ```
ipisdninfo ip-only
returns
ipisdninfo ip-only
```
- ```
ipisdninfo both
returns
ipisdninfo both
```
- ```
ipisdninfo get
returns
ipisdninfo both
```

Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings (page 2): IP or ISDN Information**

ipprecaudio, ipprefecc, ipprecvideo

Sets or gets the IP Precedence priority level (Type of Service Value) for audio, far-end camera control (FECC), and video. The value for each can be between 0 and 7.

Syntax

```
ipprecaudio get
ipprecaudio set {0..7}
ipprefecc get
ipprefecc set {0..7}
ipprecvideo get
ipprecvideo set {0..7}
```

Parameter	Description
get	Returns the current setting.
set	Sets the IP precedence. A priority level is required. This must be an integer in the range {0..7}.

Feedback Examples

- ```
ipprecaudio set 5
returns
ipprecaudio 5
```
- ```
ipprecaudio get
returns
ipprecaudio 5
```

Comments

If [typeofservice](#) command on page 4-279 is set to `diffserv`, these commands are not applicable.

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service: Type of Service: IP Precedence and Type of Service Value**

ipstat

Returns the LAN host name, WINS resolution, DHCP, IP address, DNS servers 1-4, default gateway, WINS server, and subnet mask.

Syntax

ipstat

Feedback Examples

- ipstat
returns
hostname My
domainname domain.polycom.com
winsresolution no
dhcp client
ipaddress 192.168.1.101
dnsserver 192.168.1.102
dnsserver1 192.168.1.103
dnsserver2 192.168.1.104
dnsserver3 0.0.0.0
defaultgateway 192.168.1.105
subnetmask 255.255.255.0
winsserver 192.168.1.106
lanport auto
webaccessport 80

Comments

User interface screen location: **System > Admin Settings > LAN Properties**
(both pages)

isdnareacode

Sets or gets the ISDN area code or STD code associated with the area where the system is used. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
isdnareacode get
isdnareacode set ["area code"]
```

Parameter	Description
get	Returns the area code information.
set	Sets the ISDN area code when followed by the "area code" parameter. To erase the current setting, omit "area code".
"area code"	Numeric value.

Feedback Examples

- ```
isdnareacode set 700
returns
isdnareacode 700
```
- ```
isdnareacode get
returns
isdnareacode 700
```

Comments

User interface screen location: **System > Admin Settings > Network > ISDN: Area Code**

This screen is only accessible if you have a Quad BRI network interface connected to your system.

isdncountrycode

Sets or gets the ISDN country code associated with the country where the system is used. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
isdncountrycode get
isdncountrycode set ["country code"]
```

Parameter	Description
get	Returns the country code information.
set	Sets the ISDN country code when followed by the "country code" parameter. To erase the current setting, omit "country code".
"country code"	The ISDN country code.

Feedback Examples

- ```
isdncountrycode set 1
returns
isdncountrycode 1
```
- ```
isdncountrycode get
returns
isdncountrycode 1
```

Comments

The system is generally able to automatically determine the country code based on the country you selected during initial system setup.

User interface screen location: **System > Admin Settings > General Settings > Location: Country Code**

isndialingprefix

Sets or gets the ISDN dialing prefix used to access an outside line if the system is behind a PBX. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
isndialingprefix get
isndialingprefix set ["isdn prefix"]
```

Parameter	Description
get	Returns the dialing prefix.
set	Sets the ISDN prefix when followed by the "isdn prefix" parameter. To erase the current setting, omit "isdn prefix".
"isdn prefix"	The digit(s) that must be dialed to reach an outside line.

Feedback Examples

- ```
isndialingprefix set 9
returns
isndialingprefix 9
```
- ```
isndialingprefix get
returns
isndialingprefix 9
```

Comments

User interface screen location: **System > Admin Settings > Network > ISDN: Outside Line Dialing Prefix**

isdndialspeed

Sets or gets the valid dialing speed of the ISDN network interface. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
isdndialspeed get "valid speed"
isdndialspeed set "valid speed" <on|off>
```

Parameter	Description
get	Returns the current setting. The parameter "valid speed" is required.
set	Sets the ISDN dialing speed. The parameters "valid speed" and on or off are required.
"valid speed"	Valid speeds are: 56, 2x56, 112, 168, 224, 280, 336, 392, 64, 8x56, 2x64, 128, 192, 256, 320, 384, 7x64, 512, 560, 576, 616, 640, 672, 704, 728, 768, 784, 832, 840, 14x64, 952, 960, 1008, 1024, 1064, 1088, 1120, 1152, 1176, 1216, 1232, 1280, 1288, 21x64, 1400, 1408, 1456, 1472, 1512, 1536, 1568, 1600, 1624, 1664, 1680, 1728, 28x64, 1856, and 1920 kbps. Note: The highest speed for BRI systems is 512 kbps, the highest speed for T1 systems is 1472 kbps, and the highest speed for E1 systems is 1920 kbps.
on	Enables the specified speed.
off	Disables the specified speed.

Feedback Examples

- ```
isdndialspeed set 256 on
returns
isdndialspeed set 256 on
```
- ```
isdndialspeed set 168 off
returns
isdndialspeed set 168 off
```
- ```
isdndialspeed get 168
returns
isdndialspeed 168 off
```

### Comments

User interface screen location: **System > Admin Settings > Network > Call Preference (page 5): Call Speeds**

## isdnum

Sets or gets the ISDN video number or numbers assigned to the system. This command is only applicable if you have an ISDN network interface connected to your system.

### Syntax

```
isdnum get <1b1 | 1b2 | 2b1 | 2b2 | 3b1 | 3b2 | 4b1 | 4b2>
isdnum set <1b1 | 1b2 | 2b1 | 2b2 | 3b1 | 3b2 | 4b1 | 4b2> ["number"]
```

| Parameter                                     | Description                                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get                                           | Returns the current ISDN number associated with the specified B channel.                                                                                                                                                                                                                                                  |
| set                                           | Sets the ISDN number for a B channel line when followed by the "number" parameter. To erase the current setting, omit "number".                                                                                                                                                                                           |
| 1b1   1b2   2b1   2b2   3b1   3b2   4b1   4b2 | The line and B channel. Valid values are:<br>1b1    BRI line 1, B channel 1<br>1b2    BRI line 1, B channel 2<br>2b1    BRI line 2, B channel 1<br>2b2    BRI line 2, B channel 2<br>3b1    BRI line 3, B channel 1<br>3b2    BRI line 3, B channel 2<br>4b1    BRI line 4, B channel 1<br>4b2    BRI line 4, B channel 2 |
| "number"                                      | The ISDN number(s) provided by your network service provider for the specified B channel.                                                                                                                                                                                                                                 |

### Feedback Examples

- ```
isdnum set 1b1 "700 555 1212"
returns
isdnum 1b1 7005551212
```
- ```
isdnum get 1b1
returns
isdnum 1b1 7005551212
```

### Comments

User interface screen location: **System > Admin Settings > Network > ISDN**  
(page 3): **Directory Numbers**

## isdnswitch

Sets or gets the ISDN switch protocol. This command is only applicable if you have an ISDN network interface connected to your system.

### Syntax

```
isdnswitch get
isdnswitch <pt-to-pt_at&t_5_ess|multipoint_at&t_5_ess|ni-1>
isdnswitch <nortel_dms-100|standard_etsi_euro-isdn|ts-031|ntt_ins-64>
```

| Parameter                                                                                                               | Description                                |
|-------------------------------------------------------------------------------------------------------------------------|--------------------------------------------|
| get                                                                                                                     | Returns the current switch protocol.       |
| pt-to-pt_at&t_5_ess <br>multipoint_at&t_5_ess <br>ni-1 nortel_dms-100 <br>standard_etsi_euro-isdn<br> ts-031 ntt_ins-64 | Specifies the ISDN switch protocol to use. |

### Feedback Examples

- ```
isdnswitch pt-to-pt_at&t_5_ess
returns
isdnswitch pt-to-pt_at&t_5_ess
```
- ```
isdnswitch nortel_dms-100
returns
isdnswitch nortel_dms-100
```
- ```
isdnswitch get
returns
isdnswitch nortel_dms-100
```

Comments

If more than one switch protocol is supported, you must find out from your telephone service provider which protocol to select. If you change the country settings, a new set of ISDN switch protocols is loaded.

User interface screen location: **System > Admin Settings > Network > ISDN: ISDN Switch Protocols**

See Also

To set the switch type for PRI systems, use the [priswitch](#) command on page 4-219.

keypadaudioconf

Sets or gets the keypad audio confirmation. When this option is enabled, an audio response is echoed when a numeric key is pressed on the remote control.

Syntax

```
keypadaudioconf <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables audio confirmation.
no	Disables audio confirmation.

Feedback Examples

- keypadaudioconf yes
returns
keypadaudioconf yes
- keypadaudioconf no
returns
keypadaudioconf no
- keypadaudioconf get
returns
keypadaudioconf no

Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Remote Control: Keypad Audio Confirmation**

language

Sets or gets the language that will display on the system.

Syntax

```
language <set|get>
language set <chinese|englishuk|englishus|finnish|french|german|
hungarian|italian|japanese|korean|norwegian|polish|portuguese|
russian|spanish|traditional_chinese>
```

Parameter	Description
get	Returns the current language used on the system.
set	Sets the specified language. Requires a language parameter.

Feedback Examples

- language set german
returns
language german
- language get
returns
language german

Comments

User interface screen location: **System > Admin Settings > General Settings > Location: Language**

lanport

Sets or gets the LAN port settings of the system.

Syntax

```
lanport <get|auto|autohdx|autofdxdx|10|10hdx|10fdxdx|100|100hdx|100fdxdx>
```

Parameter	Description
get	Returns the current setting.
auto autohdx autofdxdx 10 10hdx 10fdxdx 100 100hdx 100fdxdx	<p>Sets the LAN speed and duplex mode.</p> <p>auto: Automatically negotiates the LAN speed and duplex mode.</p> <p>autohdx: Automatically negotiates the LAN speed but specifies half-duplex mode.</p> <p>autofdxdx: Automatically negotiates the LAN speed but specifies full-duplex mode.</p> <p>10: 10 Mbps, auto duplex</p> <p>10hdx: 10 Mbps, half duplex</p> <p>10fdxdx: 10 Mbps, full duplex</p> <p>100: 100 Mbps, auto duplex</p> <p>100hdx: 100 Mbps, half duplex</p> <p>100fdxdx: 100 Mbps, full duplex</p>

Feedback Examples

- ```
lanport auto
returns
lanport auto
restart system for changes to take effect. restart now? <y,n>
```
- ```
lanport get
returns
lanport auto
```

Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties**
(page 2): **LAN Speed and Duplex Mode**

linestate

Sets or gets API session registration to receive notifications about IP or ISDN line state changes.

Syntax

```
linestate get  
linestate <register|unregister>
```

Parameter	Description
get	Returns the current setting.
register	Registers to receive notification when IP or ISDN line states change.
unregister	Unregisters to receive notification when IP or ISDN line states change.

Feedback Examples

- ```
linestate register
returns
linestate registered
```
- ```
linestate unregister  
returns  
linestate unregistered
```
- ```
linestate get
returns
linestate unregistered
```

### Comments

IP line state changes are only received in a serial API session.

## listen

Registers the RS-232 session to listen for incoming video calls, phone calls, or system sleep or awake state and, consequently, to give notification when the registered state occurs.

### Syntax

```
listen <video|phone|sleep>
```

| Parameter | Description                                                                                                                                                                                                                                                                                                        |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| video     | Instructs the session to listen for incoming video calls. When this event occurs, the message "listen video ringing" is received.                                                                                                                                                                                  |
| phone     | Instructs the session to listen for incoming phone calls. When this event occurs, the message "listen phone ringing" is received.                                                                                                                                                                                  |
| sleep     | Instructs the session to listen for when the system goes into sleep mode. When this event occurs, the message "listen going to sleep" is received. When the system wakes up, the message "listen waking up" is received. Deprecated. Polycom recommends using <code>sleep register</code> instead of this command. |

### Feedback Examples

- ```
listen sleep
```

returns
listen sleep registered
to acknowledge that the session is now registered to listen for sleep mode
- ```
listen phone
```

**returns**  
listen phone registered  
to acknowledge that the session is now registered to listen for incoming phone calls
- ```
listen video
```

returns
listen video registered
to acknowledge that the session is now registered to listen for incoming video calls

localdatetime

Sets or gets whether to display the local date and time on the home screen.

Syntax

```
localdatetime <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Displays the local date and time on the home screen.
no	Removes the local date and time from the home screen.

Feedback Examples

- localdatetime yes
returns
localdatetime yes
- localdatetime no
returns
localdatetime no
- localdatetime get
returns
localdatetime no

Comments

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings (page 2): Local Date and Time**

marqueedisplaytext

Sets or gets the text to display in the dialing entry field on the Place a Call screen.

Syntax

```
marqueedisplaytext get
marqueedisplaytext set "text"
```

Parameter	Description
get	Returns the current marquee display text.
set	Sets the text to display in the dialing entry field followed by the text to use. Enclose the string in quotation marks if it includes spaces.
"text"	Text to display. Enclose the character string in quotation marks if it includes spaces. If "text" is omitted, the system automatically sets it to <code>Welcome</code> .

Feedback Examples

- ```
marqueedisplaytext set "Select an entry from the directory."
returns
marqueedisplaytext "Select an entry from the directory."
```
- ```
marqueedisplaytext get
returns
marqueedisplaytext "Select an entry from the directory."
```

Comments

This command has an effect only when the `dialingdisplay` is set to display a marquee.

User interface screen location: **System > Admin Settings > General Settings > Home Screen Settings: Enter Marquee Text**

See Also

The dialing display is specified by the `dialingdisplay` command on page 4-71.

maxgabinternationalcallspeed

Sets or gets the maximum speed for international ISDN calls made from the global directory. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
maxgabinternationalcallspeed get
maxgabinternationalcallspeed set "valid speed"
```

Parameter	Description
get	Returns the current valid speed.
set	Sets the maximum speed for international calls when followed by a valid speed value.
"valid speed"	Valid speeds are: 2x64, 128, 256, 384, 512, 768, 1024, and 1472 kbps.

Feedback Examples

- ```
maxgabinternationalcallspeed set 128
returns
maxgabinternationalcallspeed 128
```
- ```
maxgabinternationalcallspeed get
returns
maxgabinternationalcallspeed 128
```

Comments

User interface screen location: **System > Admin Settings > Network > Call Preference** (page 4): **International ISDN Calls**

maxgabinternetcallspeed

Sets or gets the maximum speed for Internet (IP/H.323) calls made from the global directory.

Syntax

```
maxgabinternetcallspeed get
maxgabinternetcallspeed set "valid speed"
```

Parameter	Description
get	Returns the current valid speed.
set	Sets the maximum speed for Internet calls when followed by a valid speed value.
"valid speed"	Valid speeds are: 128, 256, 384, 512, 768, 1024, and 1472 kbps.

Feedback Examples

- maxgabinternetcallspeed set 384
returns
maxgabinternetcallspeed 384
- maxgabinternetcallspeed get
returns
maxgabinternetcallspeed 384

Comments

User interface screen location: **System > Admin Settings > Network > Call Preference** (page 3): **IP Calls**

maxgabisdnncallspeed

Sets or gets the maximum speed for ISDN (H.320) calls made from the global directory. This command is only applicable if you have an ISDN network interface connected to your system.

Syntax

```
maxgabisdnncallspeed get
maxgabisdnncallspeed set "valid speed"
```

Parameter	Description
get	Returns the current valid speed.
set	Sets the maximum speed for ISDN calls when followed by a valid speed value.
"valid speed"	Valid speeds are: 56, 64, 128, 256, 384, 512, 768, 1024, and 1472 kbps.

Feedback Examples

- maxgabisdnncallspeed set 384
returns
maxgabisdnncallspeed 384
- maxgabisdnncallspeed get
returns
maxgabisdnncallspeed 384

Comments

User interface screen location: **System > Admin Settings > Network > Call Preference** (page 4): **ISDN Video Calls (H.320)**

maxtimeincall

Sets or gets the maximum number of minutes allowed for call length.

Syntax

```
maxtimeincall get
maxtimeincall set [{0..999}]
```

Parameter	Description
get	Returns the current setting.
set	Sets the maximum time for calls when followed by a parameter from {0..999}. To erase the current setting, omit the time parameter or set it to 0. The call will then stay up indefinitely.
{0..999}	Maximum call time in minutes. Must be an integer in the range {0..999}.

Feedback Examples

- ```
maxtimeincall set
returns
maxtimeincall <empty>
```
- ```
maxtimeincall set 180
returns
maxtimeincall 180
```
- ```
maxtimeincall get
returns
maxtimeincall 180
```

### Comments

When the time has expired in a call, a message asks you if you want to hang up or stay in the call. If you do not answer within one minute, the call automatically disconnects.

User interface screen location: **System > Admin Settings > General Settings > System Settings > Call Settings: Maximum Time in Call**

## mcupassword

Enters and sends the MCU password to the MCU.

### Syntax

```
mcupassword ["password"]
```

| Parameter | Description                                |
|-----------|--------------------------------------------|
| password  | Specifies the password to send to the MCU. |

## meetingpassword

Sets or gets the meeting password.

### Syntax

```
meetingpassword get
meetingpassword set ["password"]
```

| Parameter  | Description                                                                                                                                                                                          |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get        | Returns the current meeting password.                                                                                                                                                                |
| set        | Sets the meeting password if followed by the password parameter. To erase the current setting, omit the password parameter.                                                                          |
| "password" | User-defined password. Valid characters are: A through Z (lower and uppercase), -, _, @, /, ;, ,, ., \, and 0 through 9. The length is limited to 10 characters. The password cannot include spaces. |

### Feedback Examples

- ```
meetingpassword set psswd
returns
meetingpassword psswd
```
- ```
meetingpassword get
returns
meetingpassword psswd
```
- ```
meetingpassword set "My psswd"
returns
error: command has illegal parameters
```

Comments

User interface screen location: **System > Admin Settings > General Settings > Security: Meeting**

midrangespeaker

Sets or gets whether to use the system's built-in midrange speaker. (VSX 7000, VSX 7000s, and VSX 6000 only)

Syntax

```
midrangespeaker <get|on|off>
```

Parameter	Description
get	Returns the current setting.
on	Turns the midrange speaker on.
off	Turns the midrange speaker off.

Feedback Examples

- midrangespeaker on
returns
midrangespeaker on
- midrangespeaker off
returns
midrangespeaker off
- midrangespeaker get
returns
midrangespeaker off

Comments

This option is only available when Polycom StereoSurround is disabled.
User interface screen location: **System > Admin Settings > Audio** (page 3):
Midrange Speaker

monitor1 (deprecated)

Sets or gets the aspect ratio for Monitor 1. With the implementation of the [configdisplay](#) command on page 4-51, this command has been deprecated.

Syntax

```
monitor1 <get|4:3|16:9|vga>
```

Parameter	Description
get	Returns the current setting.
4:3 16:9	Sets the display aspect ratio to 4:3 (standard) or 16:9 (wide screen).
vga	Sets the display to VGA and causes the system to restart.

Feedback Examples

- ```
monitor1 4:3
returns
monitor1 4:3
```
- ```
monitor1 16:9
returns
monitor1 16:9
```
- ```
monitor1 get
returns
monitor1 16:9
```

### Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors: Monitor**

### See Also

See the [configdisplay](#) command on page 4-51.

## monitor1screensaveroutput

Sets or gets whether to send either black video or "No Signal" to Monitor 1 when the screen saver activates.

### Syntax

```
monitor1screensaveroutput <get|black|no_signal>
```

| Parameter | Description                                                                                  |
|-----------|----------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                 |
| black     | Sends black video to Monitor 1 when the system goes to sleep and the screen saver activates. |
| no_signal | Sends no signal to Monitor 1 when the system goes to sleep and the screen saver activates.   |

### Feedback Examples

- ```
monitor1screensaveroutput black
returns
monitor1screensaveroutput black
```
- ```
monitor1screensaveroutput no_signal
returns
monitor1screensaveroutput no_signal
```
- ```
monitor1screensaveroutput get
returns
monitor1screensaveroutput no_signal
```

Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors**

See Also

See the [monitor2screensaveroutput](#) command on page 4-175.

monitor2 (deprecated)

Sets or gets the aspect ratio for Monitor 2. With the implementation of the [configdisplay](#) command on page 4-51, this command has been deprecated.

Syntax

```
monitor2 off
monitor2 <get|4:3|16:9>
monitor2 vga
```

Parameter	Description
off	Disables the second monitor output.
get	Returns the current setting.
4:3 16:9	Sets the aspect ratio to 4:3 (standard) or 16:9 (wide screen).
vga	Sets the display to VGA.

Feedback Examples

- ```
monitor2 off
returns
monitor2 off
```
- ```
monitor2 16:9
returns
monitor2 16:9
```
- ```
monitor2 get
returns
monitor2 16:9
```

### Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors: Monitor 2**

### See Also

See the [configdisplay](#) command on page 4-51.



## monitor2screensaveroutput

Sets or gets whether to send either black video or "No Signal" to Monitor 2 when the screen saver activates.

### Syntax

```
monitor2screensaveroutput <get|black|no_signal>
```

| Parameter | Description                                                                                  |
|-----------|----------------------------------------------------------------------------------------------|
| black     | Sends black video to Monitor 2 when the system goes to sleep and the screen saver activates. |
| no_signal | Sends no signal to Monitor 2 when the system goes to sleep and the screen saver activates.   |
| get       | Returns the current setting.                                                                 |

### Feedback Examples

- `monitor2screensaveroutput black`  
returns  
`monitor2screensaveroutput black`
- `monitor2screensaveroutput no_signal`  
returns  
`monitor2screensaveroutput no_signal`
- `monitor2screensaveroutput get`  
returns  
`monitor2screensaveroutput no_signal`

### Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors**

### See Also

See the [monitor1screensaveroutput](#) command on page 4-173.

## mpautoanswer

Sets or gets the Auto Answer Multipoint mode, which determines how the system will handle an incoming call in a multipoint video conference.

### Syntax

```
mpautoanswer <get|yes|no|donotdisturb>
```

| Parameter    | Description                                                                                                                                                                                                                           |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get          | Returns the current setting.                                                                                                                                                                                                          |
| yes          | Connects incoming video calls automatically. The screen will split into a multipoint call progress screen as the incoming call is answered.                                                                                           |
| no           | For an incoming video call, the user will be notified and given the choice to answer the call. If the user selects Yes, the call is added to the ongoing conference. If the user selects No, the call is rejected. The default is No. |
| donotdisturb | The user is not notified of incoming video calls. The sites that placed the calls receive a Far Site Busy (H.320) or Call Rejected (H.323) code.                                                                                      |

### Feedback Examples

- ```
mpautoanswer yes
returns
mpautoanswer yes
```
- ```
mpautoanswer no
returns
mpautoanswer no
```
- ```
mpautoanswer get
returns
mpautoanswer no
```
- ```
mpautoanswer donotdisturb
returns
mpautoanswer donotdisturb
```

### Comments

If `mpautoanswer` is set to `no` or `donotdisturb`, you must rely on API session notifications to answer inbound calls.

User interface screen location: **System > Admin Settings > General Settings > System Settings > Call Settings: Auto Answer Multipoint** or **System > User Settings: Auto Answer Multipoint**

## mpmode

Sets or gets the multipoint conference viewing mode for the system in a multipoint call. The multipoint mode can be set to auto, discussion, presentation, or fullscreen. By default, it is set to auto.

### Syntax

```
mpmode <get|auto|discussion|presentation|fullscreen>
```

| Parameter    | Description                                                                                                                                                                                                                   |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get          | Returns the current setting.                                                                                                                                                                                                  |
| auto         | In Auto mode, the system switches between Full Screen Mode and Discussion mode, depending on the interaction between the sites. If one site is talking uninterrupted for 15 seconds or more, the speaker appears full screen. |
| presentation | In Presentation mode, the person who is speaking appears full screen to the far sites, while the person who is speaking sees all the other sites on a split screen.                                                           |
| discussion   | In Discussion mode (also called Continuous Presence mode), every site sees all the sites in the meeting at the same time, on a split screen.                                                                                  |
| fullscreen   | In Full Screen mode, every site in the call sees the current speaker, or the latest person to speak, on the full screen.                                                                                                      |

### Feedback Examples

- `mpmode auto`  
returns  
`mpmode auto`
- `mpmode discussion`  
returns  
`mpmode discussion`
- `mpmode get`  
returns  
`mpmode discussion`

### Comments

This option is not available unless the multipoint option is enabled.

What you see during a multipoint call can depend on many factors such as the system's monitor configuration, the number of sites in the call, whether content is shared, and whether dual monitor emulation is used.

User interface screen location: **System > Admin Settings > Monitors > Multipoint Setup: Multipoint Mode**

## mtumode

Sets or gets the MTU mode. The `mtumode` and `mtusize` commands allow you to change the Maximum Transmission Unit (MTU) size, to adjust for the best interoperability with the host network. Set `mtumode` to `specify`, then use `mtusize` to specify a value. If `mtumode` is set to `default`, the system automatically sets the MTU value to 1260.

### Syntax

```
mtumode <get|default|specify>
```

| Parameter | Description                                                                            |
|-----------|----------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                           |
| default   | Sets the Maximum Transmission Unit size to the default value of 1260.                  |
| specify   | Allows you to specify a Maximum Transmission Unit size other than the default setting. |

### Feedback Examples

- ```
mtumode default
returns
mtumode default
```
- ```
mtumode specify
returns
mtumode specify
```
- ```
mtumode get
returns
mtumode specify
```
- ```
mtusize 660
returns
mtusize 660
```
- ```
mtumode foo
returns
error: command has illegal parameters
```

Comments

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service: Maximum Transmission Unit Size**

See Also

See also the related `mtusize` command on page 4-179.

mtusize

Sets or gets the MTU size. The `mtumode` and `mtusize` commands allow you to change the Maximum Transmission Unit (MTU) size, to adjust for the best interoperability with the host network. Set `mtumode` to `specify`, then use `mtusize` to specify a value. If `mtumode` is set to `default`, the system automatically sets the MTU value to 1260.

Syntax

```
mtusize <get|660|780|900|1020|1140|1260|1500>
```

Parameter	Description
get	Returns the current setting.
660 780 900 1020 1140 1260 1500	Sets the value of the Maximum Transmission Unit size.

Feedback Examples

- ```
mtumode specify
returns
mtumode specify
```
- ```
mtusize 660
returns
mtusize 660
```
- ```
mtusize 1140
returns
mtusize 1140
```
- ```
mtusize get
returns
mtusize 1140
```

Comments

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service: Maximum Transmission Unit Size**

See Also

See also the related [mtumode](#) command on page 4-178.

mute

Sets or gets the near or far site mute settings.

Syntax

```
mute <register|unregister>
mute near <get|on|off|toggle>
mute far get
```

Parameter	Description
register	Registers to receive notification when the mute mode changes.
unregister	Disables register mode.
near	Sets the command for the near site. Requires on, off, toggle, or get.
get	Returns the current setting for the near or far site.
on	Mutes the near site (<code>mute near on</code>).
off	Unmutes the near site (<code>mute near off</code>).
toggle	If mute near mode is <code>mute near on</code> , this switches to <code>mute near off</code> , and vice versa.
far	Returns the mute state of the far site system. Requires the parameter <code>get</code> .

Feedback Examples

- `mute register`
returns
`mute registered`
- `mute near on`
returns
`mute near on`
- `mute far get`
returns
`mute far off`

Comments

In register mode, the system sends notification to the API session when the far or near site is muted or unmuted.

muteautoanswer

Sets or gets the Mute Auto Answer Calls mode. When this setting is selected, the microphone is muted to prevent the far site from hearing the near site when the system answers automatically.

Syntax

muteautoanswer <get|yes|no>

Parameter	Description
get	Returns the current setting.
yes	Enables Mute Auto Answer Calls mode. The microphone will be muted when the system receives a call while in Auto Answer mode.
no	Disables Mute Auto Answer Calls mode. The microphone will not be muted when the system receives a call while in Auto Answer mode.

Feedback Examples

- muteautoanswer yes
returns
muteautoanswercalls yes
- muteautoanswer no
returns
muteautoanswercalls no
- muteautoanswer get
returns
muteautoanswercalls no

Comments

User interface screen location: **System > User Settings: Mute Auto Answer Calls**

natconfig

Sets or gets the NAT configuration.

Syntax

```
natconfig <get|auto|manual|upnp|off>
```

Parameter	Description
get	Returns the current setting.
auto	Specifies that the system is behind a NAT; specifies that the system will automatically discover the public (WAN) address.
manual	Specifies that the system is behind a NAT. Requires the WAN address to be assigned using the wanipaddress command on page 4-307.
upnp	Specifies that the system is behind a firewalled NAT router that is UPnP certified.
off	Disables the option when the system is not behind a NAT.

Feedback Examples

- natconfig auto
returns
natconfig auto
- natconfig manual
returns
natconfig manual
- natconfig off
returns
natconfig off
- natconfig get
returns
natconfig off

Comments

User interface screen location: **System > Admin Settings > Network > IP > Firewall: NAT Configuration**

nath323compatible

Sets or gets the NAT is H.323 Compatible setting.

Syntax

```
nath323compatible <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Specifies that NAT is capable of translating H.323 traffic.
no	Specifies that NAT is not capable of translating H.323 traffic.

Feedback Examples

- ```
nath323compatible yes
returns
nath323compatible yes
```
- ```
nath323compatible no
returns
nath323compatible no
```
- ```
nath323compatible get
returns
nath323compatible no
```

### Comments

User interface screen location: **System > Admin Settings > Network > IP > Firewall: NAT is H.323 Compatible**

This setting is only applicable when **NAT Configuration** is set to **Auto**, **Manual**, or **UPnP**.

## nearloop

Activates or deactivates the Near End Loop test.

### Syntax

```
nearloop <on|off>
```

| Parameter | Description                                                          |
|-----------|----------------------------------------------------------------------|
| on        | Activates the Near End Loop, a complete internal test of the system. |
| off       | Deactivates the Near End Loop.                                       |

### Feedback Examples

- ```
nearloop on
returns
nearloop on
cs: call[41] chan[0] dialstr[] state[ALLOCATED]
active: call[41] speed[384]
```
- ```
nearloop off
returns
nearloop off
cleared: call[41]
dialstring[IP: NAME:]
ended: call[41]
```

### Comments

When Near End Loop is on, you can test the encoder/decoder on the system. This can help you diagnose a problem with a video call. If you perform a near end loop test during a call, the far site sees a loop of itself.

User interface screen location: **System > Diagnostics > Network: Near End Loop**

## netstats

Returns network statistics for each call.

### Syntax

```
netstats [{0..n}]
```

| Parameter | Description                                                                                                                                                                                                              |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| {0..n}    | Call in a multipoint call, where <i>n</i> is the maximum number of calls supported by the system. 0 is the first site connected. If no call is specified, <code>netstats</code> returns information about the near site. |

### Feedback Examples

- ```
netstats 2
returns
call:1 txrate:128 K rxrate:128 K pktloss:0 %pktloss:0.0 % tvp:H.263
rvp:H.263 tvf:CIF rvp:CIF tap:G.722.1 rap:G.722.1 tcp:H.323
rcp:H.323
where:
txrate=transmit clock rate
rxrate=receive clock rate
pktloss=number of packet loss/errors
%pktloss=percentage of packet loss/errors
tvp=transmit video protocol
rvp=receive video protocol
tvf=transmit video format
rvf=receive video format
tap=transmit audio protocol
rap=receive audio protocol
tcp=transmit comm protocol
rcp=receive comm protocol
```

Comments

User interface screen location: **System > Diagnostics > Call Statistics** (page 2)

nonotify

Unregisters the API client to receive status notifications.

Syntax

```
nonotify <callstatus|captions|linestatus|mutestatus|screenchanges>
nonotify <sysstatus|sysalerts|vidsourcechanges>
```

Parameter	Description
callstatus	Stops the system from receiving changes in call status, such as a connection or disconnection.
captions	Stops the system from capturing closed captions as they appear on the screen.
linestatus	Stops the system from receiving line status notifications.
mutestatus	Stops the system from receiving changes in audio mute status.
screenchanges	Stops the system from receiving notification when a user interface screen is displayed.
sysstatus	Stops the system from receiving system status notifications.
sysalerts	Stops the system from receiving system alerts.
vidsourcechanges	Stops the system from receiving notification of camera source changes.

Feedback Examples

- ```
nonotify callstatus
returns
nonotify callstatus success
acknowledging that the session is no longer registered to receive callstatus
notifications
```
- ```
If entered again,
nonotify callstatus
returns
info: event/notification not active:callstatus
```

See Also

See also the related [notify](#) command on page 4-187.

notify

Lists the notification types that are currently being received, or registers to receive status notifications.

Syntax

```
notify
```

```
notify <callstatus|captions|linestatus|mutestatus|screenchanges>
```

```
notify <sysstatus|sysalerts|vidsourcechanges>
```

Parameter	Description
notify	Lists the notification types that are currently being received, in the following format. registered for <num> notifications[:notification type>...]
callstatus	Registers the system to receive changes in call status, such as a connection or disconnection, in the following format. notification:callstatus:<call direction>:<call id>:<far site name>:<far site number>:<connection status>:<call speed>:<status-specific cause code from call engine>:<calltype>
captions	Registers the system to capture closed captions as they appear on the screen, in the following format. notification:caption:<"caption string">
linestatus	Registers the system to receive line status notifications as they occur, in the following format: notification:linestatus:<direction>:<call id>:<line id>:<channel id>:<connection status>
mutestatus	Registers the system to receive changes in audio mute status, in the following format. notification:mutestatus:<near or far>:<call id>:<site name>:<site number>:<mute status>
screenchanges	Registers the system to receive notification when a user interface screen is displayed, in the following format. notification:screenchange:<screen name>:<screen def name>

Parameter	Description
sysstatus	Registers the system to receive system status notifications, in the following format. notification:sysstatus:<sys parameter name>:<value1>[:<value2>...]
sysalerts	Registers the system to receive system alerts, in the following format. notification:sysalert:<alert name>:<value1>[:<value2>...]
vidsourcechanges	Registers the system to receive notification of camera source changes, in the following format. notification:vidsourcechange:<near or far>:<camera index>:<camera name>:<people or content>

Feedback Examples

- notify mutestatus
returns
notification:mutestatus success
acknowledging that the session is now registered to receive mutestatus notifications
- notify callstatus
returns
notification:callstatus success
acknowledging that the session is now registered to receive callstatus notifications
- If entered again,
notify callstatus
returns
info: event/notification already active:callstatus
- notify
returns
registered for 2 notifications:mutestatus:callstatus

The following are examples of notifications that may be returned after registering to receive them.

- notification:callstatus:outgoing:34:Polycom VSX
Demo:192.168.1.101:connected:384:0:videocall
in the format
- notification:mutestatus:near:near:near:near:muted
- notification:screenchange:systemsetup:systemsetup_a
- notification:vidsourcechange:near:1:Main:people

- `notification:linestatus:outgoing:32:0:0:disconnected`
- `notification:vidsourcechange:near:6:ppcip:content`
- `notification:vidsourcechange:near:none:none:content`

Comments

The `notify callstatus` command registers the current API session for call status notifications. The API client receives call status notifications as a call progresses.

Registration for status notifications is session-specific. For example, registering for alerts in a Telnet session does not return alerts in a simultaneous RS-232 session with the same system.

The `notify captions` command registers the current API session to receive notifications as closed captions are displayed. If closed captions are dropped for some reason, no notification is received. This command is typically used for capturing captions being displayed for archival purpose.

Duplicate registrations produce another success response. The `notify` setting remains in effect, even if you restart the system or update the software with system settings saved.

See Also

See also the related `nonotify` command on page 4-186 and `callinfo` command on page 4-37.

ntpmode

Sets or gets the mode of the system's Network Time Protocol (NTP) server. NTP server time is used to ensure synchronized time data in the local Call Detail Report.

Syntax

```
ntpmode <get|auto|off|manual>
```

Parameter	Description
get	Returns the current time server mode.
auto	Automatically selects an NTP server from the Internet.
off	Turns off the use of an NTP server.
manual	Lets you specify a server using the ntpserver command on page 4-191.

Feedback Examples

- ntpmode auto
returns
ntpmode auto
- ntpmode off
returns
ntpmode off
- ntpmode manual
returns
ntpmode manual
- ntpmode get
returns
ntpmode manual

Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings > NTP Setup**

See Also

See the [ntpserver](#) command on page 4-191.

ntpserver

Sets or gets an Network Time Protocol (NTP) server, using the IP address or the DNS name of the server.

Syntax

```
ntpserver get
ntpserver set ["xxx.xxx.xxx.xxx" | "server name"]
```

Parameter	Description
get	Gets the IP address of the NTP server.
set	Sets the IP address of the NTP server when followed by a valid parameter. To erase the current setting, omit the ["xxx.xxx.xxx.xxx" "server name"] parameter.
"xxx.xxx.xxx.xxx"	The IP address of the NTP server.
"server name"	The DNS name of the NTP server.

Feedback Examples

- ntpserver set
returns
ntpserver <empty>
- ntpserver set 192.168.1.205
returns
ntpserver 192.168.1.205
- ntpserver get
returns
ntpserver 192.168.1.205

Comments

This command allows you to use an internal time server and thus synchronize the system's time with the time on your internal network. The system uses this time only for the local Call Detail Report.

User interface screen location: **System > Admin Settings > General Settings > Location > Date and Time (page 2): Time Server**

numberofmonitors (deprecated)

Returns the number of display monitors configured. With the implementation of the [configdisplay](#) command on page 4-51, this command has been deprecated.

Syntax

```
numberofmonitors get
```

Feedback Examples

- ```
numberofmonitors get
```

 returns  

```
numberofmonitors 1
```

 when one monitor is configured for display
- ```
numberofmonitors get
```

 returns

```
numberofmonitors 2
```

 when two monitors are configured for display

Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors**

See Also

The recommended command for accessing display configuration is the [configdisplay](#) command on page 4-51. For example, to determine the state of Monitor 2, use `configdisplay monitor2 get`.

numberofrouterhops

Sets or gets the maximum number of router hops for streaming.

Syntax

```
numberofrouterhops get
numberofrouterhops set {1..127}
```

Parameter	Description
get	Returns the current setting.
set {1..127}	Sets the value for the maximum number of router hops.

Feedback Examples

- ```
numberofrouterhops set 121
returns
numberofrouterhops 121
```
- ```
numberofrouterhops get
returns
numberofrouterhops 121
```
- ```
numberofrouterhops set
returns
error: command needs more parameters to execute successfully
```

## Comments

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Number of Router Hops**

## numdigitsdid

Sets or gets the number of digits in the DID Gateway number (E.164 dialing).

### Syntax

```
numdigitsdid <get|{0..24}>
```

| Parameter | Description                                    |
|-----------|------------------------------------------------|
| get       | Returns the current setting.                   |
| {0..24}   | Specifies the number of digits in DID numbers. |

### Feedback Examples

- ```
numdigitsdid 7
returns
numdigitsdid 7
```
- ```
numdigitsdid get
returns
numdigitsdid 7
```

### Comments

The number of digits in the DID is that portion of the full DID that the Gateway will be given from the ISDN service provider as the Called Party Line Identifier. This, in turn, will be passed to the Gatekeeper for address resolution.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 3): Number of Digits in DID Number**

For this option to be available, the Gateway Number Type on the same page must be set to Direct Inward Dial.

## numdigitsext

Sets or gets the number of digits in the Number+Extension Gateway number (E.164 dialing).

### Syntax

```
numdigitsext <get|{0..24}>
```

| Parameter | Description                                                                                                 |
|-----------|-------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                |
| {0..24}   | The number of digits in the gateway number if <a href="#">gatewaynumbertype</a> is set to number+extension. |

### Feedback Examples

- numdigitsext 10  
returns  
numdigitsext 10
- numdigitsext get  
returns  
numdigitsext 10

### Comments

The number of digits in that number is that portion of the full Number+Extension number that the Gateway will be given from the ISDN service provider as the Called Party Line Identifier. This, in turn, will be passed to the Gatekeeper for address resolution.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 3): Number of Digits in Extension**

## overlayname

Sets or gets the video overlay name setting on the system.

### Syntax

```
overlayname get
overlayname set "name"
```

| Parameter | Description                                                                                                                                                                                                                              |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                                                                                                                                             |
| set       | Sets the overlay name setting.                                                                                                                                                                                                           |
| "name"    | User-defined name to display on the overlay. The overlay name is limited to 20 characters. Enclose the character string in quotation marks if it includes spaces. Enter "" (an empty string) for "name" to remove text from the overlay. |

### Feedback Examples

- overlayname set "Maximum Security"  
returns  
overlayname "Maximum Security"
- overlayname get  
returns  
overlayname "Maximum Security"
- overlayname set ""  
returns  
overlayname ""

### Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Appearance**

# overlaytheme

Sets or gets the video overlay theme setting on the system.

## Syntax

```
overlaytheme get
overlaytheme set <0|1|2|3|4|5>
```

| Parameter   | Description                                                                                                                                                                                                         |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get         | Returns the current setting.                                                                                                                                                                                        |
| set         | Sets the overlay theme setting.                                                                                                                                                                                     |
| 0 1 2 3 4 5 | The overlay theme set on the site, as follows: <ul style="list-style-type: none"> <li>• 0 – None</li> <li>• 1 – Green</li> <li>• 2 – Blue</li> <li>• 3 – Red</li> <li>• 4 – Orange</li> <li>• 5 – Yellow</li> </ul> |

## Feedback Examples

- overlaytheme set 3  
returns  
overlaytheme 3  
and sets the video overlay theme color in the user interface to red
- overlaytheme get  
returns  
overlaytheme 3

## Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Appearance**

## pause

Pauses the command interpreter before executing the next command. Pauses are useful when commands are retrieved from a script file.

### Syntax

```
pause {0..65535}
```

| Parameter  | Description                 |
|------------|-----------------------------|
| {0..65535} | Number of seconds to pause. |

### Feedback Examples

- `pause 3`  
`returns`  
pausing for 3 seconds
- `pause 0`  
`returns`  
pausing for 0 seconds



# phone

Flashes the analog phone line.

## Syntax

```
phone <clear|flash>
```

| Parameter | Description                                                                                                                                                     |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| clear     | Clears phone number from the text box.                                                                                                                          |
| flash     | Sends flash hook to a POTS or VTX 1000 conference phone connection. If both of these call types exist, use the <code>flash</code> command to specify a call ID. |

## See Also

Use the [flash](#) command on page 4-102 to specify a call ID.

## ping

Pings the IP address of a device, to check if it can be reached.

### Syntax

```
ping "xxx.xxx.xxx.xxx" ["count"]
```

| Parameter         | Description                                                                                   |
|-------------------|-----------------------------------------------------------------------------------------------|
| "xxx.xxx.xxx.xxx" | IP address of the device.                                                                     |
| "count"           | Optional parameter defining the number of times the device is to be pinged. The default is 1. |

### Feedback Examples

- ping 192.168.1.101  
returns  
testlan ping 192.168.1.101: passed = 1; failed = 0  
where the number of passed attempts is 1 and the number of failed attempts is 0
- ping 192.168.1.101 23  
returns  
testlan ping 192.168.1.101: passed = 23; failed = 0  
where the number of passed attempts is 23 and the number of failed attempts is 0

### Comments

User interface screen location: **System > Diagnostics > Network: PING**

## pip

Sets or gets the on-screen PIP mode. The PIP feature allows the near site to adjust near-camera views while in a video conference.

### Syntax

```
pip <get|on|off|auto|camera|swap|register|unregister|location>
pip location <get|0|1|2|3>
```

| Parameter  | Description                                                                                                                                                                                            |
|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get        | Returns the current setting.                                                                                                                                                                           |
| on         | Enables PIP mode. The system shows a PIP window that remains in the lower right corner of the screen until the video call is completed.                                                                |
| off        | Disables PIP mode.                                                                                                                                                                                     |
| auto       | Causes the system to show a PIP window when the call is first connected and when the remote control is not resting on a flat surface.                                                                  |
| camera     | Causes the PIP window to appear when the selected camera position is changed. The PIP window disappears when the camera has finished moving.                                                           |
| swap       | Toggles the content of the PIP and the main display between the near-site and far-site view.                                                                                                           |
| register   | Registers the system to give notification when PIP is turned on or off.                                                                                                                                |
| unregister | Unregisters the system to give notification when PIP is turned on or off.                                                                                                                              |
| location   | Places the PIP window in the specified corner of the screen:<br>0 = bottom right corner<br>1 = top right corner<br>2 = top left corner<br>3 = bottom left corner<br>get = Returns the current location |

### Feedback Examples

- pip on  
returns  
pip on
- pip swap  
returns  
pip swapped

- pip location get  
returns  
pip location 1
- pip register  
returns  
pip registered

### Comments

User interface screen location: **System > Admin Settings > Monitors > Monitors: PIP**

or

**System > User Settings (page 2): PIP**

The Allow Access to User Settings option under **System > Admin Settings > General Settings > Security (page 2)** must be checked for the User Settings option to be available.

## popupinfo

Registers or unregisters the session to receive popup text and button choices text.

### Syntax

```
popupinfo <get|register|unregister>
```

| Parameter  | Description                               |
|------------|-------------------------------------------|
| register   | Registers to receive popup information.   |
| unregister | Unregisters to receive popup information. |
| get        | Returns the current setting.              |

### Feedback Examples

- popupinfo register  
returns  
popupinfo registered
- popupinfo unregister  
returns  
popupinfo unregistered
- popupinfo get  
returns  
popupinfo unregistered

The following examples show notifications that may be returned after registering to receive popup text and button choices text.

- popupinfo: question: Sorry. Cannot dial number because you are already in a call with the site.
- popupinfo: choice0: Ok  
is returned if a call fails
- popupinfo: question: Save Changes?  
popupinfo: choice0: Yes  
popupinfo: choice1: No  
popupinfo: answered: Yes  
is returned if the user edits the password field

## preset

Sets or gets the presets or goes (moves) to the presets for the near or far camera source. Also registers or unregisters the API session to give notification when the user sets or goes to presets.

### Syntax

```

preset <register|unregister>
preset register get
preset far <go|set> <{0..15}>
preset near <go|set> <{0..99}>

```

| Parameter        | Description                                                                                                                                                                                  |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| register         | Registers the system to give notification when the user or far site sets or goes to a preset. Returns the current preset registration state when followed by the <code>get</code> parameter. |
| unregister       | Disables register mode.                                                                                                                                                                      |
| far              | Specifies the far camera. Requires a <code>set</code> or <code>go</code> parameter and a preset identifier.                                                                                  |
| go               | Moves the camera to a camera preset. Requires a "preset" parameter.                                                                                                                          |
| set              | Sets a camera preset. Requires a "preset" parameter.                                                                                                                                         |
| {0..15}, {0..99} | Camera preset identifier. Must be an integer in the range {0..15} for a far-site camera or {0..99} for a near-site camera.                                                                   |
| near             | Specifies the near camera. Requires a <code>set</code> or <code>go</code> parameter and a preset identifier.                                                                                 |

### Feedback Examples

- ```

preset register
returns
preset registered

```
- ```

preset near go 1
returns
preset near go 1
and moves the near-site camera to the preset 1 position

```
- ```

preset near set 2
returns
preset near set 2
and saves the current location/position of the near-site camera as preset 2

```

Comments

Up to 100 preset camera positions can be set. These camera presets can be distributed across the far camera and up to four near-site cameras.

priareacode

Sets or gets the PRI area code. This command is only applicable if you have a PRI network interface connected to your system.

Syntax

```
priareacode get
priareacode set ["area code"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the PRI area code when followed by the "area code" parameter. To erase the current setting, omit "area code".
"area code"	Numeric string specifying the area code.

Feedback Examples

- ```
priareacode set 700
returns
priareacode 700
```
- ```
priareacode get
returns
priareacode 700
```

Comments

User interface screen location: **System > Admin Settings > Network > ISDN: Area Code**

This screen is only accessible if you have a PRI network interface connected to your system.

pricallbycall

Sets or gets the PRI call-by-call value. This command is only applicable if you have a PRI network interface connected to your system.

Syntax

```
pricallbycall get
pricallbycall set {0..31}
```

Parameter	Description
get	Returns the current setting.
set	Sets PRI call-by-call when followed by a value from {0..31}.
{0..31}	Range of call-by-call values.

Feedback Examples

- ```
pricallbycall set 1
returns
pricallbycall 1
```
- ```
pricallbycall get
returns
pricallbycall 1
```

Comments

Call-by-call is a number from 0 to 31, which is optionally sent to an upstream telephone company switch, if required. For example, specify a value of 6 for a T1 PRI network interface module that is directly connected to an ATT 5ESS switch, which is provisioned with Accunet. You must consult with the telephone company service provider to determine whether a call-by-call value is required for a particular PRI line. For most cases, the default value of 0 is correct. Always use the value 0 when connected to a PBX. A non-zero value should not be required in Europe. Values greater than 31 are reserved for internal use and must not be used.

User interface screen location: **System > Admin Settings > Network > ISDN (page 3): Call-by-Call**

This screen is only accessible if you have a PRI network interface connected to your system.

prichannel

Sets or gets the PRI channels that will be active for the PRI line. This command is only applicable if you have a PRI network interface connected to your system.

Syntax

```
prichannel get all
prichannel get {1..n}
prichannel set all
prichannel set {1..n} <on|off>
```

Parameter	Description
get	Returns the current setting. Requires a parameter from <all {1..n}>.
all	Selects all PRI channels and returns all channels and settings similar to briallenable.
{1..n}	Range of available PRI channels. For PRI T1, the range is 1..23. For PRI E1, the range is 1..30.
set	Sets the PRI channels to be active when followed by a parameter from <all {1..n}> and from <on off>.
on	Activates the selected PRI channels.
off	Disables the selected PRI channels.

Feedback Examples

- ```
prichannel 1 set on
returns
prichannel 1 on
```
- ```
prichannel set 23 off
returns
prichannel 23 off
```
- ```
prichannel get 23
returns
prichannel 23 off
```

### Comments

User interface screen location: **System > Admin Settings > Network > ISDN (page 5): Active Channels**

This screen is only accessible if you have a PRI network interface connected to your system.

### **Important PRI Channel Information**

**Outgoing Call.** For an outgoing call, the system uses the first active and available channel starting with the lowest number from the channel range (1-23 for a PRI T1 and 1-30 for a PRI E1). If an additional channel is needed, the system chooses the next incremental number. For example, if channels 1 through 7 are inactive, but 8 is active and available, then 8 is the first channel that can be used by the system to place an outgoing call. If an additional channel is needed, the system will use the next available active channel in the range (which could be 9, and so on).

**Incoming Calls.** For incoming calls, the system may use the highest numbered channel in the range and, if needed, proceed to the next channel number in descending order, depending on the type of third-party equipment attached to the system. For example, an incoming call arrives on channel 23, then 22, 21, and so on.

**Dedicated full PRI T1 or E1 Line.** All channels should be active for a full T1 or E1 line dedicated to your system.

**Fractional PRI T1 or E1.** Channel selection should be handled by your PRI network administrator.

**PRI E1 Channel Information.** The PRI Status screen (for E1) shows 30 channels. However, E1 trunk lines have 32 timeslots, numbered 0 - 31. Timeslot 0 is used for framing, and timeslot 16 is used for call signaling (the D channel). The remaining 30 timeslots are used as bearer (data) channels. In call signaling between our equipment and the switch, these channels are numbered 1-15, 17-31. But the PRI Status screen numbers these channels contiguously in the range 1-30. Therefore, on the PRI Status screen, channels 1-15 control the status of timeslots 1-15, and channels 16-30 control the status of timeslots 17-31.

## pricsu

Sets or gets the PRI CSU mode for a T1 interface.

### Syntax

```
pricsu <get|internal|external>
```

| Parameter | Description                                                                        |
|-----------|------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                       |
| internal  | Sets the internal CSU mode. This is the default.                                   |
| external  | Sets the external CSU mode. When selected, you must specify the PRI line buildout. |

### Feedback Examples

- ```
pricsu internal
returns
pricsu internal
```
- ```
pricsu external
returns
pricsu external
```
- ```
pricsu get
returns
pricsu external
```

Comments

By default, the T1 PRI network interface module is set for internal CSU mode. User interface screen location: **System > Admin Settings > Network > ISDN (page 2): External CSU**

This screen is only accessible if you have a PRI network interface connected to your system.

See Also

The PRI line buildout for a T1 interface is set using the [prilinebuildout](#) command on page 4-212.

pridialchannels

Sets or gets the number of PRI channels to dial in parallel. This command is only applicable if you have a PRI network interface connected to your system.

Syntax

```
pridialchannels get
pridialchannels set {1..n}
```

Parameter	Description
set	Sets the number of PRI channels to be dialed in parallel when followed by a parameter from {1..n}. To erase the current setting, omit the parameter.
get	Returns the current number of channels dialed in parallel.
{1..n}	Range of numbers of PRI channels that can be dialed in parallel. For PRI T1, the range is 1..12. For PRI E1, the range is 1..15.

Feedback Examples

- ```
pridialchannels set 3
returns
pridialchannels 3
```
- ```
pridialchannels get
returns
pridialchannels 3
```

Comments

By default, ISDN channels are dialed three at a time. On PRI systems, you can choose the number of channels to dial in parallel.

User interface screen location: **System > Admin Settings > Network > ISDN (page 3): Number of Channels to Dial in Parallel**

This screen is only accessible if you have a PRI network interface connected to your system.

priintlprefix

Sets or gets the PRI international dialing prefix.

Syntax

```
priintlprefix get  
priintlprefix set ["prefix"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the PRI international dialing prefix when followed by the parameter "prefix". To erase the current setting, omit the parameter.
"prefix"	Numeric string.

Feedback Examples

- ```
priintlprefix set 011
returns
priintlprefix 011
```
- ```
priintlprefix get  
returns  
priintlprefix 011
```

Comments

The international prefix defaults to 011 for North America and 00 for European countries. The default depends on the country.

User interface screen location: **System > Admin Settings > Network > ISDN (page 3): International Dialing Prefix**

This screen is only accessible if you have a PRI network interface connected to your system.

prilinebuildout

Sets or gets the PRI line buildout for a T1 interface.

Syntax

```
prilinebuildout get
prilinebuildout set <0|-7.5|-15|-22.5>
prilinebuildout set <0-133|134-266|267-399|400-533|534-665>
```

Parameter	Description
get	Returns the current setting.
set	Sets the PRI line buildout. It requires an output "attenuation in dB" or an "attenuation in feet".
0 -7.5 -15 -22.5	Output attenuation values in dB. For internal CSUs.
0-133 134-266 267-399 400-533 534-665	Output attenuation values in feet. For external CSUs.

Feedback Examples

- ```
prilinebuildout set -7.5
returns
prilinebuildout -7.5
```
- ```
prilinebuildout get
returns
prilinebuildout -7.5
```

Comments

If you are using an internal CSU, enter the output attenuation in dB. If you are using an external CSU, enter the output attenuation in feet.

User interface screen location: **System > Admin Settings > Network > ISDN** (page 3): **Line Build Out**

See Also

The PRI CSU mode for a T1 interface is set using the [pricsu](#) command on page 4-209.

prilinesignal

Sets or gets the PRI line signal.

Syntax

```
prilinesignal get
prilinesignal set <esf/b8zs|crc4/hdb3|hdb3>
```

Parameter	Description
get	Returns the current PRI line signal setting.
set	Sets the PRI line signal. It requires one of the following parameters: <code>esf/b8zs</code> , <code>crc4/hdb3</code> , <code>hdb3</code>
<code>esf/b8zs</code>	A method of signal encoding used with a T1 interface. This is the only choice for T1. This value actually chooses both a framing format and an encoding method. Legacy frame formats, such as D4, are not supported. In addition, older encoding methods, such as B7ZS, are not supported.
<code>crc4/hdb3</code>	A method of signal encoding used with an E1 interface. This is the default value. Data is encoded using HDB3 to ensure proper one-density, and CRC4 error checking is enabled on both transmit and receive.
<code>hdb3</code>	A method of signal encoding used with an E1 interface. CRC4 error checking is disabled.

Feedback Examples

- ```
prilinesignal set esf/b8zs
returns
prilinesignal esf/b8zs
```
- ```
prilinesignal get
returns
prilinesignal esf/b8zs
```

Comments

User interface screen location: **System > Admin Settings > Network > ISDN (page 2): Line Signaling**

This screen is only accessible if you have a PRI network interface connected to your system.

primarycallchoice

Sets or gets the primary call type for placing calls.

Syntax

```
primarycallchoice <get|isdn|ip|sip>
```

Parameter	Description
get	Returns the current primary call type.
isdn	Sets the primary call type to ISDN.
ip	Sets the primary call type to IP.
sip	Sets the primary call type to SIP.

Feedback Examples

- ```
primarycallchoice ip
returns
primarycalltype ip
```
- ```
primarycallchoice get
returns
primarycalltype ip
```

Comments

User interface screen location: **System > Admin Settings > Network > Call Preference** (page 2)

See Also

You can set the secondary call type using the [secondarycallchoice](#) command on page 4-239.

primarycamera

Sets or gets the primary camera that is used when the system powers on.

Syntax

```
primarycamera <get|1|2|3>
```

Parameter	Description
get	Returns the current setting.
1 2 3	Selects the camera to use as the primary video source.

Feedback Examples

- ```
primarycamera 1
returns
primarycamera 1
```
- ```
primarycamera get
returns
primarycamera 1
```

Comments

You cannot disconnect the main camera, but you do not have to set it as the primary camera.

User interface screen location: **System > Admin Settings > Cameras: Primary Camera**

prinumber

Sets or gets the PRI video number.

Syntax

```
prinumber get  
prinumber set ["number"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the PRI video number when followed by the parameter "number". To erase the current setting, omit the parameter.
"number"	Numeric string. This number is provided by your network service provider.

Feedback Examples

- ```
prinumber set 5551212
returns
prinumber 5551212
```
- ```
prinumber get  
returns  
prinumber 5551212
```

Comments

User interface screen location: **System > Admin Settings > Network > ISDN: PRI Video Number**

This screen is only accessible if you have a PRI network interface connected to your system.

prinumberingplan

Sets or gets the PRI numbering plan. This command is only applicable if you have a PRI network interface connected to your system.

Syntax

```
prinumberingplan <get|isdn|unknown>
```

Parameter	Description
get	Returns the current setting.
isdn	With this parameter, the numbering plan is identified to the upstream switch as ISDN, and the number type, which is either national or international, is determined from the dialed phone number. If the dialed phone number starts with the international dialing prefix that is currently selected, the type is set to the international and the prefix is removed from the number before the number is sent to the upstream switch. Otherwise, the number is marked as national and passed to the upstream switch without modification.
unknown	This is the default selection. With this parameter, the numbering plan and number type are sent to the upstream as unknown, and the dialed phone number is sent without notification. The <code>unknown</code> parameter is preferred and should work with all properly configured PBXs and with most telephone company switches. A notable exception in North America is an ATT 5ESS switch, which is provisioned with Accunet, or an ATT 4ESS switch. For these switches, set the numbering type to ISDN.

Feedback Examples

- ```
prinumberingplan isdn
returns
prinumberingplan isdn
```
- ```
prinumberingplan unknown
returns
prinumberingplan unknown
```
- ```
prinumberingplan get
returns
prinumberingplan unknown
```

### Comments

User interface screen location: **System > Admin Settings > Network > ISDN** (page 3): **Numbering Plan**

This screen is only accessible if you have a PRI network interface connected to your system.

## prioutsideline

Sets or gets the PRI number that is dialed for outside line access.

### Syntax

```
prioutsideline get
prioutsideline set ["outside_line"]
```

| Parameter      | Description                                                                                                                              |
|----------------|------------------------------------------------------------------------------------------------------------------------------------------|
| get            | Returns the current setting.                                                                                                             |
| set            | Sets the outside-line-access PRI number when followed by the parameter "outside_line". To erase the current setting, omit the parameter. |
| "outside_line" | Numeric string. This number is provided by your network service provider.                                                                |

### Feedback Examples

- ```
prioutsideline set 9
returns
prioutsideline 9
```
- ```
prioutsideline get
returns
prioutsideline 9
```

### Comments

This number is needed if your system is on a PBX.

User interface screen location: **System > Admin Settings > Network > ISDN: Outside Line Dialing Prefix**

This screen is only accessible if you have a PRI network interface connected to a system.

## priswitch

Sets or gets the PRI switch.

### Syntax

```
priswitch get
priswitch set <att5ess|att4ess|norteldms|ni2>
priswitch set <net5/ctr4|nttins-1500|ts-038>
```

| Parameter                                                  | Description                                                                                                                                                                                                                                          |
|------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get                                                        | Returns the current switch protocol.                                                                                                                                                                                                                 |
| set                                                        | Sets the PRI switch. One of the switch protocol parameters is required.                                                                                                                                                                              |
| att5ess att4ess norteldms ni2 net5/ctr4 nttins-1500 ts-038 | <p>Switch protocol values.</p> <p>For E1, net5/ctr4 is the default. net5/ctr4 is the standard ETSI protocol derived from ITU Q.931.</p> <p>For T1, net5/ctr4 is also provided for certain Asian countries, such as Japan, Hong Kong, and Taiwan.</p> |

### Feedback Examples

- ```
priswitch set att5ess
returns
priswitch att5ess
```
- ```
priswitch get
returns
priswitch att5ess
```

### Comments

If more than one switch protocol is supported, you must find out from your telephone service provider which protocol to select. NET5/CTR4 is the default. It is the standard ETSI protocol derived from ITU Q.931. If you change the country settings, a new set of PRI switch protocols is loaded.

User interface screen location: **System > Admin Settings > Network > ISDN (page 2): Switch Protocol**

This screen is only accessible if you have a PRI network interface connected to your system.

## reboot

Restarts the system.

### Syntax

```
reboot now
reboot [yes|no]
```

| Parameter | Description                                                  |
|-----------|--------------------------------------------------------------|
| now       | Reboots the system without prompting you.                    |
| yes       | Reboots the system. Can be abbreviated to <i>y</i> .         |
| no        | Does not reboot the system. Can be abbreviated to <i>n</i> . |

### Feedback Examples

- `reboot`  
returns  
`reboot, are you sure? <y,n>`
- `reboot y`  
reboots the system with no other feedback returned

### Comments

User interface screen location: **System > Diagnostics > Reset System: Reset System**

## recentcalls

Returns the list of recent calls.

### Syntax

```
recentcalls
```

### Feedback Examples

- recentcalls  
returns  
"Polycom VSX Demo" 16/Jun/2007 14:39:56 Out  
192.168.1.101 16/Jun/2007 14:40:07 Out  
192.168.1.102 16/Jun/2007 14:40:35 Out  
192.168.1.103 16/Jun/2007 20:27:33 Out  
"John Polycom VSX 7000" 17/Jun/2007 02:13:23 In  
192.168.1.104 17/Jun/2007 02:20:08 In  
192.168.1.105 17/Jun/2007 02:21:40 In  
192.168.1.106 17/Jun/2007 05:53:04 In  
"Mary Polycom VSX 7000" 17/Jun/2007 07:00:19 In

### Comments

User interface screen location: **System > Admin Settings > Network > Recent Calls**

# registerall

Alias for the all register command.

## Syntax

```
registerall
```

## Feedback Examples

- registerall  
returns  
callstate registered  
camera registered  
chaircontrol registered  
linestate registered  
mute registered  
pip registered  
popup registered  
popupinfo registered  
preset registered  
screen registered  
vbutton registered  
volume registered  
sleep registered  
phone registered  
video registered  
vcstream registered  
vc pod registered  
vc lan registered

## See Also

This command is an alias for the preferred [all register](#) command on page 4-13.

To unregister user feedback, use the [all unregister](#) command on page 4-14 or the [unregisterall](#) command on page 4-281.



## registerthssystem

Sets or gets the system's IP address to be registered and displayed in the global directory when the system is powered on.

### Syntax

```
registerthssystem [{1..5}|all] <get|yes|no>
```

| Parameter | Description                                 |
|-----------|---------------------------------------------|
| {1..5}    | References GDS server {1..5}.               |
| all       | References all GDS servers.                 |
| get       | Returns the current setting.                |
| yes       | Enables this option (register this system). |
| no        | Disables this option.                       |

### Feedback Examples

- ```
registerthssystem yes
returns
registerthssystem yes
```
- ```
registerthssystem no
returns
registerthssystem no
```
- ```
registerthssystem get
returns
registerthssystem no
```
- ```
registerthssystem all get
returns
registerthssystem 1 no
registerthssystem 2 no
registerthssystem 3 no
registerthssystem 4 no
registerthssystem 5 no
```

### Comments

If you do not enable this option, the system has access to the GDS, but the IP address does not appear in the global directory.

## remotecontrol

Set or gets the setting for intercepting signals from the system remote control.

### Syntax

```
remotecontrol disable <get|all|none>
remotecontrol disable "valid button" ["valid button"...]
remotecontrol dontintercept <all|none>
remotecontrol dontintercept "valid button" ["valid button"...]
remotecontrol enable <all|none>
remotecontrol enable "valid button" ["valid button"...]
remotecontrol intercept <get|all|none>
remotecontrol intercept "valid button" ["valid button"...]
```

| Parameter      | Description                                                                                                                                                                                                                       |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| disable        | Disables specified remote control button(s) so that the system does not respond.                                                                                                                                                  |
| get            | Returns the current setting.                                                                                                                                                                                                      |
| all            | All of the remote control buttons.                                                                                                                                                                                                |
| none           | None of the remote control buttons.                                                                                                                                                                                               |
| "valid button" | Name of a specific button such as call, hangup, left, right, up, down, select, home, directory, back, zoom-, zoom+, volume-, volume+, mute, far, near, auto, camera, preset, pip, keyboard, delete, ., 0-9, *, #, graphics, help. |
| dontintercept  | Stops intercepting specified remote control button(s).                                                                                                                                                                            |
| enable         | Enables specified remote control button(s).                                                                                                                                                                                       |
| intercept      | Disables and intercepts specified remote control button(s). Notification of button press events is sent to the API client.                                                                                                        |

### Feedback Examples

- ```
remotecontrol disable all
returns
remotecontrol disable all success
```
- ```
remotecontrol intercept pip
returns
remotecontrol intercept pip success
```
- ```
remotecontrol disable get
returns
disabled 1 buttons:pip
```

- `remotecontrol intercept get`
returns
`intercepting 0 buttons`
- `remotecontrol intercept all`
returns
`remotecontrol intercept all success`

The following is an example of a notification that may be returned after sending the `intercept` command.

- `notification:buttonintercept::ir:`
`notification:buttonintercept::ir:`
`notification:buttonintercept:home:ir:`

remotemonenable

Gets the state of remote room and call monitoring.

Syntax

```
remotemonenable get
```

Feedback Examples

- remotemonenable get
returns
remotemonenable on
- remotemonenable get
returns
remotemonenable off

Comments

User interface screen location: **System > Admin Settings > General Setting > Security (page 2): Allow Video Display on Web**

repeat

Repeats a specified command from the history list.

Syntax

```
repeat {1..64}
```

Parameter	Description
{1..64}	Repeats the specified command in the history list. Values larger than the number of commands in the history list are not valid. The history list may contain up to 64 commands.

Feedback Examples

- `repeat 3`
returns
`registerthissystem get`
`registerthissystem no`
- `repeat 47`
returns
`remotecontrol disable get`
`disabled 0 buttons`
- `repeat 52`
returns
`repeat: cannot repeat a repeat command`
if the specified command in the history list is a repeat command

requireacctnumtodial

Enables or disables the Require Account Number to Dial option. It is used to log calls to a specific account so that they can be tracked and billed to the appropriate departments.

Syntax

```
requireacctnumtodial <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the option.
no	Disables the option.

Feedback Examples

- ```
requireacctnumtodial yes
returns
requireacctnumtodial yes
```
- ```
requireacctnumtodial no
returns
requireacctnumtodial no
```
- ```
requireacctnumtodial get
returns
requireacctnumtodial no
```

### Comments

When this option is selected, you cannot make a call without first entering an account number. This account number is saved in the Global Management System server database along with information specific to the call. Typically, the Global Management System administrator assigns the account number.

User interface screen location: **System > Admin Settings > Global Services > Account Validation: Require Account Number to Dial**

## roomphonenumber

Sets or gets the number of the phone that is located in the same room as the system.

### Syntax

```
roomphonenumber get
roomphonenumber set ["number"]
```

| Parameter | Description                                                                                                                                         |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                                                        |
| set       | Sets the room phone number when followed by the "number" parameter. To erase the current setting, omit the "number" parameter.                      |
| "number"  | Phone number for a telephone (not the system) in the room. Use quotation marks around the number if it contains spaces. For example: "408 555 2323" |

### Feedback Examples

- ```
roomphonenumber set
returns
roomphonenumber <empty>
```
- ```
roomphonenumber set "408 555 2323"
returns
roomphonenumber 408.555.2323
```
- ```
roomphonenumber get
returns
roomphonenumber 408.555.2323
```

Comments

If the system is managed by the Global Management System software, this number will be provided to the Global Management System administrator if the person using the system requests help.

User interface screen location: **System > Admin Settings > General Settings > Location: Room Telephone Number**

rs232 baud, rs232port1 baud

The `rs232 baud` command sets or gets the baud rate for the first RS-232 port. For systems with two serial ports, use `rs232port1 baud` to set the rate for the second serial port.

Syntax

```
rs232 baud <get|9600|14400|19200|38400|57600|115200>
rs232port1 baud <get|9600|14400|19200|38400|57600|115200>
```

Parameter	Description
get	Returns the current baud rate setting.
9600 14400 19200 38400 57600 115200	Sets the RS-232 port to this baud rate.

Feedback Examples

- ```
rs232 baud 9600
returns
rs232 baud 9600
```
- ```
rs232 baud get
returns
rs232 baud 9600
```
- ```
rs232port1 baud 14400
returns
rs232port1 baud 14400
```
- ```
rs232port1 baud get
returns
rs232port1 baud 14400
```

Comments

User interface screen location: **System > Admin Settings > General Settings > Serial Port: Baud Rate**

rs232 mode, rs232port1 mode

The `rs232 mode` command sets or gets the operational mode of the first RS-232 port. For systems with two serial ports, use `rs232port1 mode` to set the mode for the second serial port.

Syntax

```
rs232 mode <get|passthru|control|debug|sony_ptz|closed_caption|
vortex_mixer|cps|interactive_touch_board|polycom_annotation|
smartboard|pointmaker>
rs232port1 mode <get|passthru|control|debug|sony_ptz|closed_caption|
vortex_mixer|cps|interactive_touch_board|polycom_annotation|
smartboard|pointmaker>
```

Parameter	Description
get	Returns the current mode setting.
passthru	Sets the RS-232 port to Pass Thru mode.
control	Sets the RS-232 port to Control mode.
debug	Sets the RS-232 port to Debug mode.
sony_ptz	Sets the RS-232 port to Sony PTZ mode.
closed_caption	Sets the RS-232 port to Closed Caption mode.
vortex_mixer	Sets the RS-232 port to Vortex Mixer mode.
cps interactive_touc h_board polycom_anno tation smartboard pointmaker	Reserved for future applications.

Feedback Examples

- `rs232 mode control`
returns
`rs232 mode control`
- `rs232port1 mode closed_caption`
returns
`rs232port1 mode closed_caption`
- `rs232port1 mode get`
returns
`rs232port1 mode closed_caption`

Comments

User interface screen location: **System > Admin Settings > General Settings > Serial Port: RS-232 Mode**

rs232monitor

Sets or gets the state of RS-232 serial port monitoring. When RS-232 monitoring is enabled, you can view all communication in and out of the serial port as output to Telnet port 23.

Syntax

```
rs232monitor get
rs232monitor <on|off>
```

Parameter	Description
on	Enables RS-232 serial port monitoring.
off	Disables RS-232 serial port monitoring.
get	Returns the current setting.

Feedback Examples

- rs232monitor on
returns
rs232monitor on succeeded
- rs232monitor off
returns
rs232monitor off succeeded
- rs232monitor get
returns
rs232monitor off

rs366dialing

Sets or gets RS-366 dialing. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
rs366dialing <get|on|off>
```

Parameter	Description
get	Returns the current setting.
on	Enables RS-366 dialing.
off	Disables RS-366 dialing.

Feedback Examples

- rs366dialing on
returns
rs366dialing on
- rs366dialing off
returns
rs366dialing off
- rs366dialing get
returns
rs366dialing off

Comments

Enable this option if you want to call from the system through the DCE connection to the far-site video conferencing system. Disable this option if you are using your DCE to dial the call or if you have a dedicated connection to the far site.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530: RS-366 Dialing**

rt

Sets or gets the RT serial interface control signal (receive timing: clock). This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
rt <get|normal|inverted>
```

Parameter	Description
get	Returns the current setting.
normal	Sets the signal to normal (rising edge receives data).
inverted	Sets the signal to inverted (falling edge receives data).

Feedback Examples

- ```
rt normal
returns
rt normal
```
- ```
rt inverted
returns
rt inverted
```
- ```
rt get
returns
rt inverted
```

**Comments**

The default setting is "normal".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): RT**

## rts

Sets or gets the RTS serial interface control signal (request to send). This command is only applicable if you have a V.35 network interface connected to your system.

### Syntax

```
rts <get|normal|inverted>
```

| Parameter | Description                                           |
|-----------|-------------------------------------------------------|
| get       | Returns the current setting.                          |
| normal    | Sets the signal to normal (high voltage is logic 1).  |
| inverted  | Sets the signal to inverted (low voltage is logic 1). |

### Feedback Examples

- `rts normal`  
returns  
`rts normal`
- `rts inverted`  
returns  
`rts inverted`
- `rts get`  
returns  
`rts inverted`

### Comments

The default setting is "normal".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): RTS**

## run

Loads a file from the flash file system and then executes the API commands contained in it.

### Syntax

```
run "scriptfilename"
```

| Parameter        | Description                                                         |
|------------------|---------------------------------------------------------------------|
| "scriptfilename" | Name of the script file containing the API commands to be executed. |

### Feedback Examples

- `run startcall.bat`  
loads the specified file and executes the API commands within it  
if the specified file is found
- `run startcall.bat`  
returns  
`run: script file startcall.bat not found`  
if the specified file is not found

### Comments

Each API command needs to be placed on a single line with a <CR><LF> as a terminator.

## screen

Returns the name of the current user interface screen on the system, registers or unregisters for screen changes, or goes to a specific user interface screen.

### Syntax

```
screen
screen register get
screen [register|unregister]
screen "screen_name"
```

| Parameter     | Description                                                                                                                                                                                                                                                       |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| screen        | Returns the name of the current user interface screen if not followed by other parameters.                                                                                                                                                                        |
| register      | Registers for user interface screen changes. In register mode, the name of every screen accessed is listed.                                                                                                                                                       |
| get           | Returns the registration state for screen change events when followed by the <code>get</code> parameter.                                                                                                                                                          |
| unregister    | Unregisters from user interface screen changes.                                                                                                                                                                                                                   |
| "screen_name" | Changes the user interface to display the specified screen. The supported screens depend on the system configuration. To determine the name to use for a specific screen, navigate to that screen in the user interface and send the <code>screen</code> command. |

### Feedback Examples

- `screen`  
returns  
`screen: adminsettings`  
if the Admin Settings screen is currently displayed in the user interface
- `screen register`  
returns  
`screen registered`
- `screen monitors`  
returns  
`screen: monitors`  
and displays the Monitors screen in the user interface

## screencontrol

Disables or enables navigation to specified user interface screens of the system.

### Syntax

```
screencontrol enable <all|none|"screen_name">
screencontrol disable <all|none|"screen_name">
```

| Parameter     | Description                                                    |
|---------------|----------------------------------------------------------------|
| enable        | Enables navigation to the specified user interface screen(s).  |
| all           | All of the user interface screens.                             |
| none          | None of the user interface screens.                            |
| "screen_name" | Name of a specific user interface screen.                      |
| disable       | Disables navigation to the specified user interface screen(s). |

### Feedback Examples

- ```
screencontrol enable all
returns
screencontrol enable all success
```
- ```
screencontrol disable adminsettings
returns
screencontrol disable adminsettings success
and disables navigation to the Admin Settings screen of the user interface
```
- ```
screencontrol disable none
returns
screencontrol disable none success
and reverses all screen disable commands
```
- ```
screencontrol disable main
returns
error: screen "main" unknown
screencontrol disable main failed
if "main" is an unknown screen name
```

### See Also

Refer to the [screen](#) command on page 4-237 for details about accessing screen names.



## secondarycallchoice

Sets or gets the secondary call type for placing calls.

### Syntax

```
secondarycallchoice <get|isdn|ip|sip>
```

| Parameter | Description                              |
|-----------|------------------------------------------|
| get       | Returns the current secondary call type. |
| isdn      | Sets the secondary call type to ISDN.    |
| ip        | Sets the secondary call type to IP.      |
| sip       | Sets the secondary call type to SIP.     |

### Feedback Examples

- ```
secondarycallchoice ip  
returns  
secondarycalltype ip
```
- ```
secondarycallchoice get
returns
secondarycalltype ip
```

### See Also

You can set the primary call type using the [primarycallchoice](#) command on page 4-214.

## serialnum

Returns the serial number of the system.

### Syntax

```
serialnum
```

### Feedback Examples

- ```
serialnum  
returns  
serialnum 82065205E72EB1
```

Comments

User interface screen location: **System > System Information: Serial Number**

setaccountnumber

Sets the account number when it is required for dialing out.

Syntax

```
setaccountnumber "account number"
```

Parameter	Description
"account number"	Number that is needed to validate the account before dialing out.

Feedback Examples

- ```
setaccountnumber 1234
returns
setaccountnumber 1234
```

### Comments

The account number is saved in the Global Management System database and is generally assigned by the Global Management System administrator. The [requireacctnumdial](#) command on page 4-228 and the [validateacctnum](#) command on page 4-293 must be enabled for this command to work. When you make a call, you will be prompted to enter your account number.

### See Also

See the related [requireacctnumdial](#) command on page 4-228 and [validateacctnum](#) command on page 4-293.

## showgatekeeper

Returns the gatekeeper addresses specified.

### Syntax

```
showgatekeeper <active|primary|alternates|all>
```

| Parameter  | Description                                                                               |
|------------|-------------------------------------------------------------------------------------------|
| active     | Displays the IP address for the primary or alternate gatekeeper that is currently active. |
| primary    | Displays the IP address for the primary gatekeeper.                                       |
| alternates | Displays the IP address for the alternate gatekeeper(s).                                  |
| all        | Displays the IP address for all gatekeepers.                                              |

### Feedback Examples

- ```
showgatekeeper active
returns
showgatekeeper current ipaddress 192.168.1.200
```
- ```
showgatekeeper primary
returns
gatekeeper primary ipaddress 192.168.1.201
```
- ```
showgatekeeper alternates
returns
showgatekeeper alternates begin
showgatekeeper alternates ipaddress 192.168.1.203
showgatekeeper alternates ipaddress1 192.168.1.204
showgatekeeper alternates ipaddress2 192.168.1.205
showgatekeeper alternates end
```
- ```
showgatekeeper all
returns
showgatekeeper all begin
showgatekeeper current ipaddress 192.168.1.201
showgatekeeper primary ipaddress 192.168.1.202
showgatekeeper alternates ipaddress 192.168.1.203
showgatekeeper alternates ipaddress1 192.168.1.204
showgatekeeper alternates ipaddress2 192.168.1.205
showgatekeeper all end
```

### Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings**

# showpopup

Displays a message box in the user interface.

## Syntax

```
showpopup "text to display"
```

| Parameter         | Description                                                                              |
|-------------------|------------------------------------------------------------------------------------------|
| "text to display" | Message to display to users. Enclose the text in quotation marks if it contains a space. |

## Feedback Examples

- `showpopup "The conference will resume in three minutes."`  
returns  
`showpopup "The conference will resume in three minutes."`  
and displays the message box in the user interface

## Comments

Sending this command displays the message as a popup dialog in the user interface, along with an alert tone.

# sleep

Puts the system in sleep mode within 15 seconds and returns sleep.

## Syntax

```
sleep
sleep <register|unregister>
sleep register get
```

| Parameter  | Description                                                            |
|------------|------------------------------------------------------------------------|
| sleep      | Puts the system in sleep mode if not followed by other parameters.     |
| register   | Registers for sleep or wake events.                                    |
| unregister | Unregisters from sleep or wake events.                                 |
| get        | Returns whether the system is registered for sleep event notification. |

## Feedback Examples

- sleep  
returns  
sleep  
and puts the system in sleep mode within 15 seconds
- sleep register  
returns  
sleep registered
- If entered again,  
sleep register  
returns  
info: event/notification already active:sleep
- sleep unregister  
returns  
sleep unregistered
- If entered again,  
sleep unregister  
returns  
info: event/notification not active:sleep

## See Also

To wake the system from sleep mode, use the [wake](#) command on page 4-306.

## sleeptext

Sets or gets the text to be displayed with the logo for 15 seconds as the system goes into sleep mode.

### Syntax

```
sleeptext get
sleeptext set ["text"]
```

| Parameter | Description                                                                                                                         |
|-----------|-------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current text.                                                                                                           |
| set       | Sets the text to be displayed on the screen saver when followed by the "text" parameter. To erase the current setting, omit "text". |
| "text"    | Screen saver text to be displayed when the system is in sleep mode. Enclose the text in quotation marks if it includes spaces.      |

### Feedback Examples

- ```
sleeptext set  
returns  
sleeptext <empty>
```
- ```
sleeptext set "Pick up the remote control to use the system"
returns
sleeptext "Pick up the remote control to use the system"
```

### Comments

Web interface screen location: **System Setup > Utilities > Screen Saver: Logo Screen Text**

## sleeptime

Sets or gets the wait time value before the system goes to sleep and displays the screen saver.

### Syntax

```
sleeptime <get|0|1|3|15|30|60|120|240|480>
```

| Parameter                  | Description                                                                                           |
|----------------------------|-------------------------------------------------------------------------------------------------------|
| get                        | Returns the current setting.                                                                          |
| 0 1 3 15 30 60 120 240 480 | Sets the number of minutes from last user interaction to entering sleep mode. The default value is 3. |

### Feedback Examples

- sleeptime 30  
returns  
sleeptime 30

### Comments

User interface screen location: **System > Admin Settings > General Settings > System Settings > Appearance: Screen Saver Wait Time**



## snapshottimeout

Sets or gets the Snapshot Timeout setting.

### Syntax

```
snapshottimeout <get|yes|no>
```

| Parameter | Description                                                                                        |
|-----------|----------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                       |
| yes       | Enables the option: the display times out after four minutes and the system returns to live video. |
| no        | Disables the option: the snapshot stays on screen indefinitely.                                    |

### Feedback Examples

- ```
snapshottimeout yes
returns
snapshottimeout yes
```
- ```
snapshottimeout no
returns
snapshottimeout no
```
- ```
snapshottimeout get
returns
snapshottimeout no
```

Comments

By default, all slides and snapshots are displayed for a period of four minutes. When the display times out after four minutes, the VSX system automatically returns to live video. However, when this option is disabled, the snapshot or slide stays on screen indefinitely until the user presses the **Snap** button on the remote control to return to live video.

User interface screen location: **System > Admin Settings > Monitors > Monitors: Snapshot Timeout**

snmpadmin

Sets or gets the SNMP administrator name.

Syntax

```
snmpadmin get
snmpadmin set ["admin name"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the administrator name when followed by the "admin name" parameter. To erase the current setting, omit "admin name".
"admin name"	SNMP administrator contact name. Character string. Enclose the character string in quotation marks if it includes spaces. Example: "John Admin"

Feedback Examples

- ```
snmpadmin set
returns
snmpadmin <empty>
```
- ```
snmpadmin set "John Admin"
returns
snmpadmin "John Admin"
```
- ```
snmpadmin get
returns
snmpadmin "John Admin"
```

### Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > Global Services > SNMP: Contact Name**

## snmpcommunity

Sets or gets the SNMP community name.

### Syntax

```
snmpcommunity get
snmpcommunity set ["community name"]
```

| Parameter        | Description                                                                                                                     |
|------------------|---------------------------------------------------------------------------------------------------------------------------------|
| get              | Returns the current setting.                                                                                                    |
| set              | Sets the SNMP community name when followed by the "community name" parameter. To erase the current setting, omit the parameter. |
| "community name" | SNMP community name. Character string. Enclose the character string in quotation marks if it includes spaces.                   |

### Feedback Examples

- ```
snmpcommunity set
returns
snmpcommunity <empty>
```
- ```
snmpcommunity set Public
returns
snmpcommunity Public
```
- ```
snmpcommunity get
returns
snmpcommunity Public
```

Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > Global Services > SNMP: Community**

snmpconsoleip

Sets or gets the SNMP console IP address.

Syntax

```
snmpconsoleip get
snmpconsoleip set ["xxx.xxx.xxx.xxx"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the SNMP console IP address when followed by the "xxx.xxx.xxx.xxx" parameter. To erase the current setting, omit the parameter.
"xxx.xxx.xxx.xxx"	IP address of the console.

Feedback Examples

- ```
snmpconsoleip set
returns
snmpconsoleip <empty>
```
- ```
snmpconsoleip set 192.168.1.111
returns
snmpconsoleip 192.168.1.111
```
- ```
snmpconsoleip get 192.168.1.111
returns
snmpconsoleip 192.168.1.111
```

### Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > Global Services > SNMP: Console IP Address**

## snmplocation

Sets or gets the SNMP location name.

### Syntax

```
snmplocation get
snmplocation set ["location name"]
```

| Parameter       | Description                                                                                                                   |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------|
| get             | Returns the current setting.                                                                                                  |
| set             | Sets the SNMP location name when followed by the "location name" parameter. To erase the current setting, omit the parameter. |
| "location name" | SNMP location name. Enclose the location name in quotation marks if it includes spaces.                                       |

### Feedback Examples

- ```
snmplocation set
returns
snmplocation <empty>
```
- ```
snmplocation set "Mary_Polycom in United States"
returns
snmplocation "Mary_Polycom in United States"
```
- ```
snmplocation get
returns
snmplocation "Mary_Polycom in United States"
```

Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > Global Services > SNMP: Location Name**

snmpsystemdescription

Sets or gets the SNMP system description.

Syntax

```
snmpsystemdescription get
snmpsystemdescription set ["system description"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the SNMP system description when followed by the "system description" parameter. To erase the current setting, omit the parameter.
"system description"	SNMP system description.

Feedback Examples

- ```
snmpsystemdescription set
returns
snmpsystemdescription <empty>
```
- ```
snmpsystemdescription set "videoconferencing system"
returns
snmpsystemdescription "videoconferencing system"
```
- ```
snmpsystemdescription get
returns
snmpsystemdescription "videoconferencing system"
```

### Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > Global Services > SNMP: System Description**

## snmptrapversion

Sets or gets the SNMP trap version.

### Syntax

```
snmptrapversion get
snmptrapversion set <v1|v2c>
```

| Parameter | Description                                       |
|-----------|---------------------------------------------------|
| get       | Returns the current setting.                      |
| set       | Sets the SNMP trap protocol that the system uses. |
| v1 v2c    | SNMP trap version 1 or version 2c.                |

### Feedback Examples

- snmptrapversion set v1  
returns  
snmptrapversion v1
- snmptrapversion set v2c  
returns  
snmptrapversion v2c
- snmptrapversion get  
returns  
snmptrapversion v2c

### Comments

User interface screen location: **System > Admin Settings > Global Services > SNMP**

## soundeffectsvolume

Sets, gets, or tests the volume level of the ring tone and user alert tone on the system.

### Syntax

```
soundeffectsvolume get
soundeffectsvolume set {0..10}
soundeffectsvolume test
```

| Parameter | Description                                                                              |
|-----------|------------------------------------------------------------------------------------------|
| get       | Returns the current setting along with a test tone from the system at that volume level. |
| set       | Sets the volume of sound effects. Requires a volume parameter in the range {0..10}.      |
| test      | Tests the volume of sound effects.                                                       |

### Feedback Examples

- `soundeffectsvolume set 6`  
returns  
`soundeffectsvolume 6`
- `soundeffectsvolume get`  
returns  
`soundeffectsvolume 6`
- `soundeffectsvolume test`  
returns  
`soundeffectsvolume test`  
and a tone is produced by the system

### Comments

User interface screen location: **System > Admin Settings > Audio: Sound Effects Volume**



## spidnum

Sets or gets the ISDN SPID numbers assigned to the BRI lines used by the system. This command is only applicable if you have a BRI network interface connected to your system.

### Syntax

```
spidnum get <all | 1b1 | 1b2 | 2b1 | 2b2 | 3b1 | 3b2 | 4b1 | 4b2>
```

```
spidnum set <1b1 | 1b2 | 2b1 | 2b2 | 3b1 | 3b2 | 4b1 | 4b2> ["spid number"]
```

| Parameter                                     | Description                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get                                           | Returns the current SPID number associated with a B channel of a particular line.                                                                                                                                                                                                                                 |
| all                                           | Returns SPIDs for all channels of all lines.                                                                                                                                                                                                                                                                      |
| 1b1   1b2   2b1   2b2   3b1   3b2   4b1   4b2 | The line and B channel. Valid values are:<br>1b1   BRI line 1, B channel 1<br>1b2   BRI line 1, B channel 2<br>2b1   BRI line 2, B channel 1<br>2b2   BRI line 2, B channel 2<br>3b1   BRI line 3, B channel 1<br>3b2   BRI line 3, B channel 2<br>4b1   BRI line 4, B channel 1<br>4b2   BRI line 4, B channel 2 |
| set                                           | Sets the SPID number for a B channel line when followed by the "number" parameter. To erase the current setting, omit "number".                                                                                                                                                                                   |
| "spid number"                                 | Numeric string. SPID numbers are generally provided by your network service provider.                                                                                                                                                                                                                             |

### Feedback Examples

- ```
spidnum get all
returns
spidnum 1b1 7005551212
spidnum 1b2 7005552323
spidnum 2b1 7005553434
spidnum 2b2 7005554545
spidnum 3b1 7005555656
spidnum 3b2 7005556767
spidnum 4b1 7005557878
spidnum 4b2 7005558989
if 4 lines with channels 1b1 through 4b2 are attached in the above format
```

- `spidnum set 1b1`
returns
`spidnum 1b1 <empty>`
- `spidnum set 1b1 7005551212`
returns
`spidnum 1b1 7005551212`

Comments

SPIDs generally apply only in the United States and Canada. If you are behind an internal phone system (PBX), SPIDs may not be required.

User interface screen location: **System > Admin Settings > Network > ISDN**
(page 4): **ISDN BRI SPIDs**

st

Sets or gets the st serial interface control signal (send timing: clock) setting. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
st <get|normal|inverted>
```

Parameter	Description
get	Returns the current setting.
normal	Sets the signal to normal (falling edge sends data).
inverted	Sets the signal to inverted (rising edge sends data).

Feedback Examples

- st normal
returns
st normal
- st inverted
returns
st inverted
- st get
returns
st inverted

Comments

The default setting is "normal".

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 3): ST**

stream

Starts or stops streaming from your system.

Syntax

```
stream start ["addr"] ["ttl"] ["vidPort"] ["audPort"] ["vidCmpr"]
  ["audCmpr"] ["bitrate"]
stream stop
```

Parameter	Description
start	Starts streaming. A meeting password may be required.
"addr"	Specifies address for the stream.
"ttl"	Specifies TTL for the stream.
"vidPort"	Specifies video port for the stream.
"audPort"	Specifies audio port for the stream.
"vidCmpr"	Specifies video compression for the stream.
"audCmpr"	Specifies audio compression for the stream.
"bitrate"	Specifies bit rate for the stream.
stop	Stops streaming.

Feedback Examples

- stream start
returns
stream start
- stream stop
returns
stream stop

Comments

User interface screen location: **System > Utilities > Streaming: Start Streaming**

This option is only visible in the user interface if streaming is enabled.

streamannounce

Sets or gets the streaming announcement setting.

Syntax

```
streamannounce <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables streaming announcement.
no	Disables streaming announcement.

Feedback Examples

- streamannounce yes
returns
streamannounce yes
- streamannounce no
returns
streamannounce no
- streamannounce get
returns
streamannounce no

Comments

When this option is enabled, the names of users logged on to your system are displayed on screen.

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Enable Streaming Announcement**

streamaudioport

Sets or gets the stream audio port setting.

Syntax

```
streamaudioport get
streamaudioport set ["stream audio port"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the stream audio port when followed by the "stream audio port" parameter. To erase the current setting, omit the "stream audio port" parameter.
"stream audio port"	Audio port number.

Feedback Examples

- streamaudioport set 16384
returns
streamaudioport 16384
- streamaudioport get
returns
streamaudioport 16384

Comments

By default, the audio port is a fixed port. This may be changed if a user needs to go through the firewall.

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Audio Port**

streamenable

Sets or gets whether streaming is allowed on the system.

Syntax

```
streamenable <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables streaming.
no	Disables streaming.

Feedback Examples

- streamenable yes
returns
streamenable yes
- streamenable no
returns
streamenable no
- streamenable get
returns
streamenable no

Comments

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Allow Streaming**

streammulticastip

Sets or gets the multicast IP address for streaming.

Syntax

```
streammulticastip get
streammulticastip set ["xxx.xxx.xxx.xxx"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the multicast IP address when followed by the "xxx.xxx.xxx.xxx" parameter. To erase the current setting, omit the "xxx.xxx.xxx.xxx" parameter.
"xxx.xxx.xxx.xxx"	Multicast IP address.

Feedback Examples

- ```
streammulticastip set
returns
streammulticastip <empty>
```
- ```
streammulticastip set 192.168.1.101
returns
streammulticastip 192.168.1.101
```
- ```
streammulticastip get
returns
streammulticastip 192.168.1.101
```

### Comments

A default address is entered for you based on your system's serial number. This ensures that you do not have the same multicast address as another Polycom system. You can change this default address using this command. User interface screen location: **System > Admin Settings > Network > IP > Streaming: IP Multicast Address**



## streamrestoredefaults

Restores the stream Speed, IP Multicast Address, Number of Router Hops, Audio Port, and Video Port defaults and prints out the values.

### Syntax

```
streamrestoredefaults
```

### Feedback Examples

- ```
streamrestoredefaults
returns
streamspeed 192
streammulticastip 192.168.1.101
streamrouterhops 1
streamaudioport 16384
streamvideoport 16386
streamenable no
streamannounce yes
```

streamrouterhops

Sets or gets the number of routers you want the streaming video to pass through. This allows you to control who can see your streaming video.

Syntax

```
streamrouterhops get
streamrouterhops set {1..127}
```

Parameter	Description
get	Returns the current setting.
set	Sets the number of routers when followed by a number. To erase the current setting, omit the number.
{1..127}	Numeric value. Number of routers the streaming video has to pass through.

Feedback Examples

- streamrouterhops set 1
returns
streamrouterhops 1
- streamrouterhops get
returns
streamrouterhops 1

Comments

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Number of Router Hops (TTL)**

streamspeed

Sets or gets the speed of the video stream.

Syntax

```
streamspeed <get|192|256|384|512>
```

Parameter	Description
get	Returns the current setting.
192 256 384 512	Sets the streaming speed at the designated number of kbps.

Feedback Examples

- streamspeed 192
returns
streamspeed 192
- streamspeed get
returns
streamspeed 192

Comments

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Speed**

streamvideoport

Sets or gets the stream video port.

Syntax

```
streamvideoport get
streamvideoport set ["video port"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the stream video port when followed by the "video port" parameter. To erase the current setting, omit the parameter.
"video port"	Video port number.

Feedback Examples

- ```
streamvideoport set 16386
returns
streamvideoport 16386
```
- ```
streamvideoport get
returns
streamvideoport 16386
```

Comments

By default, the video port is a fixed port. This command lets you change stream video port to go through a firewall.

User interface screen location: **System > Admin Settings > Network > IP > Streaming: Video Port**

subnetmask

Sets or gets the subnet mask of the system.

Syntax

```
subnetmask get
subnetmask set ["xxx.xxx.xxx.xxx"]
```

Parameter	Description
get	Returns the current subnet mask.
set	Sets the subnet mask of the system when followed by the "xxx.xxx.xxx.xxx" parameter. To erase the current setting, omit "xxx.xxx.xxx.xxx".
"xxx.xxx.xxx.xxx"	Subnet mask of the system.

Feedback Examples

- ```
subnetmask set 255.255.255.0
returns
subnetmask 255.255.255.0
restart system for changes to take effect. restart now? <y,n>
```
- ```
subnetmask get
returns
subnetmask 255.255.255.0
```

Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties**
(page 2): **Subnet Mask**

subwoofer

Sets or gets whether to use the system's subwoofer. This command is only valid for VSX 7000 and VSX 7000s systems.

Syntax

```
subwoofer <get|on|off>
```

Parameter	Description
get	Returns the current setting.
on	Turns the system subwoofer on.
off	Turns the system subwoofer off.

Feedback Examples

- subwoofer on
returns
subwoofer on
- subwoofer off
returns
subwoofer off
- subwoofer get
returns
subwoofer off

Comments

User interface screen location: **System > Admin Settings > Audio** (page 3):
Subwoofer Speaker

subwooferoffset

Sets or gets the volume level for the subwoofer without changing the master audio volume. This command is only valid for VSX 7000 and VSX 7000s systems.

Syntax

```
subwooferoffset <get|+3|+2|+1|0|-1|-2|-3>
```

Parameter	Description
get	Returns the current setting.
+3 +2 +1 0 -1 -2 -3	Sets the subwoofer to this level dB.

Feedback Examples

- ```
subwooferoffset +2
returns
subwooferoffset +2
```
- ```
subwooferoffset get
returns
subwooferoffset +2
```

Comments

User interface screen location: **System > Admin Settings > Audio** (page 3):
Subwoofer Level

sysinfo

Sets or gets registration for ISDN, IP, and gatekeeper status notifications.

Syntax

```
sysinfo <get|register|unregister>
```

Parameter	Description
get	Returns registration status.
register	Registers the shell session to receive ISDN, IP, and gatekeeper status notifications.
unregister	Unregisters the shell session for ISDN, IP, and gatekeeper status notifications.

Feedback Examples

- ```
sysinfo register
returns
sysinfo registered
```
- ```
sysinfo unregister
returns
sysinfo unregistered
```
- ```
sysinfo get
returns
sysinfo unregistered
```

The following are examples of notifications of status changes in ISDN lines that may be returned after registering to receive sysinfo notifications.

- linestate: isdnline[1] down
- linestate: isdnline[2] down
- linestate: isdnline[3] up
- linestate: isdnline[4] up
- linestate: isdnline[1] up
- linestate: isdnline[3] down
- linestate: isdnline[4] down
- linestate: isdnline[2] up



## systemname

Sets or gets the name of the system.

### Syntax

```
systemname get
systemname set "system name"
```

| Parameter     | Description                                                                                                                              |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------|
| get           | Returns the current setting.                                                                                                             |
| set           | Sets the system name to "system name".                                                                                                   |
| "system name" | Character string specifying the system name. Enclose the string in quotation marks if it includes spaces.<br>Example: "Polycom VSX Demo" |

### Feedback Examples

- ```
systemname set "Polycom VSX Demo"
returns
systemname "Polycom VSX Demo"
```
- ```
systemname set get
returns
systemname "Polycom VSX Demo"
```

### Comments

The first character must be a numeric (a digit) or alphabetic (a letter) character including foreign language characters. The name can be any combination of alphanumeric characters and may be up to 30 characters in length. The system name cannot be blank.

User interface screen location: **System > Admin Settings > General Settings > System Settings > Directory: System Name**

## tcpports

Sets or gets the TCP ports on the system.

### Syntax

```
tcpports get
tcpports set [{1024..49150}]
```

| Parameter | Description                                                                                                             |
|-----------|-------------------------------------------------------------------------------------------------------------------------|
| set       | Sets the TCP ports when followed by a value from the range {1024..49150}. To erase the current setting, omit the value. |
| get       | Returns the current TCP port setting.                                                                                   |

### Feedback Examples

- tcpports set 3233  
returns  
tcpports 3233
- tcpports get  
returns  
tcpports 3233

### Comments

The **Fixed Ports** option on the same page must be selected for the **TCP Ports** option to be available.

User interface screen location: **System > Admin Settings > Network > IP > Firewall: Fixed Ports > TCP Ports**

# techsupport

Sends your phone number to Global Management System technical support if your system is managed by the Global Management System.

## Syntax

```
techsupport <"phone num">
```


| Parameter   | Description                                                                                                                                                                                                                    |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "phone num" | Phone number at which the user of this system will be contacted. To obtain rapid assistance, include the area code with the phone number. Enclose the string in quotation marks if it includes spaces. Example: "408 555 2323" |

## Feedback Examples

- techsupport "408 555 2323"  
returns  
techsupport will contact you at 408 555 2323

## Comments

The Support icon is visible only when the system is registered with the Polycom Global Management System.

User interface screen location: On the remote control press the  **Help** button and select **Support**

## teleareacode

Sets or gets the system's area code.

### Syntax

```
teleareacode get
teleareacode set ["telephone_area_code"]
```

| Parameter             | Description                                                                                                                                               |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| get                   | Returns the current setting.                                                                                                                              |
| set                   | Sets the system's area code when followed by the "telephone_area_code" parameter. To erase the current setting, omit the "telephone_area_code" parameter. |
| "telephone_area_code" | System's area code.                                                                                                                                       |

### Feedback Examples

- ```
teleareacode set
returns
teleareacode <empty>
```
- ```
teleareacode set 408
returns
teleareacode 408
```
- ```
teleareacode get
returns
teleareacode 408
```

Comments

User interface screen location: **System > Admin Settings > Network > Telephony**

telenumber

Sets or gets the system's telephone number.

Syntax

```
telenumber get
telenumber set ["telephone_number"]
```

Parameter	Description
get	Returns the current setting.
set	Sets the telephone number when followed by the "telephone number" parameter. To erase the current setting, omit the parameter.
"telephone_number"	System's telephone number. Enclose the string in quotation marks if it includes spaces. Example: "408 555 2323"

Feedback Examples

- ```
telenumber set
returns
telenumber <empty>
```
- ```
telenumber set "408 555 2323"
returns
telenumber "408 555 2323"
```
- ```
telenumber get
returns
telenumber "408 555 2323"
```

## Comments

User interface screen location: **System > Admin Settings > Network > Telephony: Room Telephone Number**

## telnetmonitor

Sets or gets the state of Telnet session monitoring. When Telnet monitoring is enabled, you can view all communication to and from the Telnet port 24 session as output to Telnet port 23.

### Syntax

```
telnetmonitor get
telnetmonitor <on|off>
```

| Parameter | Description                  |
|-----------|------------------------------|
| get       | Returns the current setting. |
| on        | Enables Telnet monitoring.   |
| off       | Disables Telnet monitoring   |

### Feedback Examples

- telnetmonitor on  
returns  
telnetmonitor on succeeded
- telnetmonitor off  
returns  
telnetmonitor off succeeded
- telnetmonitor get  
returns  
telnetmonitor off

## timediffgmt

Sets or gets the time difference from where the system is installed and Greenwich Mean Time (GMT). This allows the Global Management System to view the local time of the managed system.

### Syntax

```
timediffgmt <get|{-12:00..+12:00}>
```

| Parameter        | Description                                                          |
|------------------|----------------------------------------------------------------------|
| get              | Returns the current setting.                                         |
| {-12:00..+12:00} | Sets the time difference from GMT to this value. +00:00 is GMT time. |

### Feedback Examples

- ```
timediffgmt -06:00
returns
timediffgmt -06:00 success
```
- ```
timediffgmt get
returns
timediffgmt -06:00 success
```

### Comments

User interface screen location: **System > Admin Settings > General Settings > Location (page 2): Time Zone**

## traceroute

Runs a trace route to test. If successful, it displays the routing path between the local system and the IP address entered.

### Syntax

```
traceroute host [hops]
```

| Parameter | Description                             |
|-----------|-----------------------------------------|
| host      | Specifies host name or an IP address.   |
| hops      | Value must be $0 < \text{hops} < 100$ . |

### Feedback Examples

- ```
traceroute 192.168.1.109
returns
testlan traceroute complete.
29 hops.
```
- ```
traceroute stereo.polycom.com
returns
hostname stereo.polycom.com (192.168.1.110)
testlan traceroute complete.
29 hops.
```

### Comments

User interface screen location: **System > Diagnostics > Network > Trace Route**



# typeofservice

Sets or gets the type of service for Quality of Service.

## Syntax

```
typeofservice <get|ipprecedence|diffserv>
```

| Parameter    | Description                    |
|--------------|--------------------------------|
| get          | Returns the current setting.   |
| ipprecedence | Selects IP precedence service. |
| diffserv     | Selects DiffServ service.      |

## Feedback Examples

- `typeofservice diffserv`  
returns  
`typeofservice diffserv`
- `typeofservice ipprecedence`  
returns  
`typeofservice ipprecedence`
- `typeofservice get`  
returns  
`typeofservice ipprecedence`

## Comments

User interface screen location: **System > Admin Settings > Network > IP > Quality of Service**

## See Also

See the [ipprecaudio](#), [ipprecfecc](#), [ipprecvideo](#) command on page 4-150 and the [diffservaudio](#), [diffservfecc](#), [diffservvideo](#) command on page 4-73.

## udpports

Sets or gets the UDP ports on the system.

### Syntax

```
udpports get
udpports set [{1024..49150}]
```

| Parameter | Description                                                                                                             |
|-----------|-------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current UDP port setting.                                                                                   |
| set       | Sets the UDP ports when followed by a value from the range {1024..49150}. To erase the current setting, omit the value. |

### Feedback Examples

- ```
udpports set 3230
returns
udpports 3230
```
- ```
udpports get
returns
udpports 3230
```

### Comments

The **Fixed Ports** option on the same page must be selected for the UDP Ports option to be available.

User interface screen location: **System > Admin Settings > Network > IP > Firewall: Fixed Ports: UDP Ports**

# unregisterall

Alias for the all unregister command.

## Syntax

```
unregisterall
```

## Feedback Examples

- `unregisterall`  
**returns**  
`callstate unregistered`  
`camera unregistered`  
`linestate unregistered`  
`mute unregistered`  
`pip unregistered`  
`popup unregistered`  
`popupinfo unregistered`  
`preset unregistered`  
`screen unregistered`  
`vcbutton unregistered`  
`volume unregistered`  
`sleep unregistered`  
`phone unregistered`  
`video unregistered`  
`vcstream unregistered`  
`vc pod unregistered`  
`vc lan unregistered`

## See Also

This command is an alias for the preferred [all unregister](#) command on page 4-14.

To register for user feedback, use the [all register](#) command on page 4-13 or the [registerall](#) command on page 4-222.

## usefixedports

Sets or gets the Fixed Ports configuration.

### Syntax

```
usefixedports <get|yes|no>
```

| Parameter | Description                      |
|-----------|----------------------------------|
| get       | Returns the current setting.     |
| yes       | Enables the use of Fixed Ports.  |
| no        | Disables the use of Fixed Ports. |

### Feedback Examples

- usefixedports yes  
returns  
usefixedports yes
- usefixedports no  
returns  
usefixedports no
- usefixedports get  
returns  
usefixedports no

### Comments

User interface screen location: **System > Admin Settings > Network > IP > Firewall: Fixed Ports**

## usegatekeeper

Sets or gets the gatekeeper mode (off, specify, or auto).

### Syntax

```
usegatekeeper <get|off|specify|auto>
```

| Parameter | Description                                                                                                                                                           |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.<br><b>Note:</b> A gatekeeper is not required to make IP-to-IP LAN calls. In these situations, select the <code>off</code> option.        |
| off       | Select this option if no gatekeeper is required or if you make IP-to-IP LAN calls.                                                                                    |
| specify   | Specifies a gatekeeper.<br>If this option is selected, you must enter the gatekeeper IP address or name using the <a href="#">gatekeeperip</a> command on page 4-106. |
| auto      | Sets the system to automatically find an available gatekeeper.                                                                                                        |

### Feedback Examples

- `usegatekeeper off`  
returns  
`usegatekeeper off`
- `usegatekeeper specify`  
returns  
`usegatekeeper specify`
- `usegatekeeper auto`  
returns  
`usegatekeeper auto`
- `usegatekeeper get`  
returns  
`usegatekeeper auto`

### Comments

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 2): Use Gatekeeper**

### See Also

See the [gatekeeperip](#) command on page 4-106.

## usepathnavigator

Sets or gets the Polycom PathNavigator™ mode, if PathNavigator is used with the system.

### Syntax

```
usepathnavigator <get|always|never|required>
```

| Parameter | Description                                                                                                                                                                                                               |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                                                                                                                                                              |
| always    | Always use PathNavigator to place a multipoint call. Never use the external MCU.                                                                                                                                          |
| never     | Never use PathNavigator to place a multipoint call. Use the external MCU instead.                                                                                                                                         |
| required  | This is the default. When this option is selected, if the multipoint call is within the MCU capabilities, it is handled by the MCU; otherwise, beyond the MCU capabilities, it is handled through the PathNavigator/MGC™. |

### Feedback Examples

- `usepathnavigator always`  
returns  
`usepathnavigator always`
- `usepathnavigator never`  
returns  
`usepathnavigator never`
- `usepathnavigator required`  
returns  
`usepathnavigator required`
- `usepathnavigator get`  
returns  
`usepathnavigator required`

### Comments

This option is only accessible if PathNavigator is used.

Because PathNavigator uses an MGC, it can handle video conferences with more participants and higher speeds than an embedded MCU. PathNavigator, which supports ad-hoc multipoint video conferencing, is required to implement Conference on Demand™. Conference on Demand allows users to bring multiple endpoints together in a video conference on an unscheduled basis. It allows users to place multipoint video calls to remote participants by only using their names and/or numbers that correspond to those remote locations.

User interface screen location: **System > Admin Settings > Network > IP > H.323 Settings (page 2): Use PathNavigator for Multipoint Calls**

# useroompassword

Sets or gets the Use Room Password for Remote Access setting.

## Syntax

```
useroompassword get
useroompassword <yes|no>
```

| Parameter | Description                                                                       |
|-----------|-----------------------------------------------------------------------------------|
| get       | Returns the current setting.                                                      |
| no        | Configures the system to use a separate room password and remote access password. |
| yes       | Configures the system to use the same password for room and remote access.        |

## Feedback Examples

- ```
useroompassword yes
returns
useroompassword yes
```
- ```
useroompassword no
returns
useroompassword no
```
- ```
useroompassword get
returns
useroompassword no
```

Comments

User interface screen location: **System > Admin Settings > General Settings > Security: Use Room Password for Remote Access**

v35broadcastmode

Sets or gets the V.35 broadcast mode. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
v35broadcastmode <get|on|off>
```

Parameter	Description
get	Returns the current setting.
on	Turns on V.35 broadcast.
off	Turns off V.35 broadcast.

Feedback Examples

- v35broadcast on
returns
v35broadcast on
- v35broadcast off
returns
v35broadcast off
- v35broadcast get
returns
v35broadcast off

v35dialingprotocol

Sets or gets the V.35 dialing protocol. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
v35dialingprotocol <get|rs366>
```

Parameter	Description
get	Returns the current setting.
rs366	Enables RS-366 as the dialing protocol. At this time, RS-366 is the only supported dialing protocol on the system.

Feedback Examples

- v35dialingprotocol rs366
returns
v35dialingprotocol rs366
- v35dialingprotocol get
returns
v35dialingprotocol rs366

Comments

Selecting a dialing protocol is not needed if you are using your DCE to dial the call or if you have a dedicated connection to the far site.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530: RS-366 Dialing**

v35num

Sets or gets the ISDN video numbers assigned to the system. This command is only applicable if you have a V.35 network interface connected to your system.

Syntax

```
v35num get <1b1|1b2>
```

```
v35num set <1b1|1b2> ["v35 number"]
```

Parameter	Description
get	Returns the current ISDN video number associated with a B channel of a particular line. Requires <1b1 1b2>.
1b1 1b2	B1 and B2 channels: 1b1 designates line 1, B channel 1 (B1). 1b2 designates line 1, B channel 2 (B2).
set	Sets the ISDN video number for a B channel line when followed by a "v35 number" parameter. To erase the current setting, omit the "v35 number" parameter. 1b1 is port 1 and 1b2 is port 2.
"v35 number"	Numeric string. This is the ISDN video number(s) provided by your network service provider.

Feedback Examples

- ```
v35num set 1b1
returns
v35num 1b1 <empty>
```
- ```
v35num set 1b2 7005551212
returns
v35num 1b2 7005551212
```
- ```
v35num get 1b2
returns
v35num 1b2 7005551212
```

### Comments

The 1b1 and 1b2 parameters follow the convention and nomenclature of the user interface and the [isdnum](#) command on page 4-156.

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530**

### See Also

See the [isdnum](#) command on page 4-156.

## v35portsused

Sets or gets the number of ports to use on the V.35/RS-449/RS-530 network interface module.

### Syntax

```
v35portsused <get|1|1+2>
```

| Parameter | Description                                                           |
|-----------|-----------------------------------------------------------------------|
| get       | Returns the current setting.                                          |
| 1         | Selects one port for one-channel calls.                               |
| 1+2       | Selects two ports for two-channel calls (2 x 56 kbps or 2 x 64 kbps). |

### Feedback Examples

- v35portsused 1  
returns  
v35portsused 1
- v35portsused 1+2  
returns  
v35portsused 1+2
- v35portsused get  
returns  
v35portsused 1+2

### Comments

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530: V.35 Ports Used**

## v35prefix

Sets or gets the V.35 dialing prefix. It assumes that a profile has already been selected.

### Syntax

```
v35prefix get "valid speed"
v35prefix set "valid speed" ["value"]
```

| Parameter     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get           | Returns the current setting for "valid speed".                                                                                                                                                                                                                                                                                                                                                                                                                |
| set           | Sets the V.35/RS-449/RS-530 prefix when followed by a "value" parameter. To erase the current setting, omit the "value" parameter.                                                                                                                                                                                                                                                                                                                            |
| "valid speed" | Valid speeds are 56, 64, 2x56, 112, 2x64, 128, 168, 192, 224, 256, 280, 320, 336, 384, 392, 7x64, 504, 512, 560, 576, 616, 640, 672, 704, 728, 768, 784, 832, 840, 14x64, 952, 960, 1008, 1024, 1064, 1088, 1120, 1152, 1176, 1216, 1232, 1280, 1288, 21x64, 1400, 1408, 1456, 1472, 1512, 1536, 1568, 1600, 1624, 1664, 1680, 1728, 28x64, 1856, 1920, all.<br><br>The parameter "all" lists all the available speeds and their associated dialing prefixes. |
| "value"       | V.35/RS-449/RS-530 prefix, which is a function of your DCE. Consult the DCE user guide for information.                                                                                                                                                                                                                                                                                                                                                       |

### Feedback Examples

- v35prefix set 56  
returns  
v35prefix 56 <empty>
- v35prefix set 112 "#005"  
returns  
v35prefix 112 "#005"  
and associates the dialing prefix 005 with the speed 112
- v35prefix get 112  
returns  
v35prefix 112 "#005"

### Comments

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 2): Prefix**

### See Also

See the [v35profile](#) command on page 4-291.

## v35profile

Sets or gets a V.35 profile associated with dialing through a DCE. It can also display all the settings (speed, prefix or suffix) of the current profile.

### Syntax

v35profile

```
<get|adtran|adtran_isu512|ascend|ascend_vsx|ascend_max|avaya_mcu|
custom_1|fvc.com|initia|lucent_mcu|madge_teleos>
```

| Parameter                                                                                                   | Description                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| get                                                                                                         | Returns the current profile.                                                                                                                         |
| adtran adtran_isu512 ascend ascend_vsx ascend_max avaya_mcu custom_1 fvc.com initia lucent_mcu madge_teleos | V.35/RS-449/RS-530 profile (equipment/manufacture) available.<br>Consult your DCE user guide for additional information on setting dialing profiles. |

### Feedback Examples

- ```
v35profile adtran_isu512
returns
v35profile adtran_isu512
selects adtran_isu512 as the profile
```
- ```
v35profile get
returns
v35profile adtran_isu512
```

### Comments

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 2): Calling Profile**

## v35suffix

Sets or gets the V.35 dialing suffix. It assumes that a profile has already been selected.

### Syntax

```
v35suffix get "valid speed"
v35suffix set "valid speed" ["value"]
```

| Parameter     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| get           | Returns the current setting for valid speed.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| set           | Sets the dialing suffix when followed by a "value" parameter. To erase the current setting, omit the "value" parameter.                                                                                                                                                                                                                                                                                                                                       |
| "valid speed" | Valid speeds are 56, 64, 2x56, 112, 2x64, 128, 168, 192, 224, 256, 280, 320, 336, 384, 392, 7x64, 504, 512, 560, 576, 616, 640, 672, 704, 728, 768, 784, 832, 840, 14x64, 952, 960, 1008, 1024, 1064, 1088, 1120, 1152, 1176, 1216, 1232, 1280, 1288, 21x64, 1400, 1408, 1456, 1472, 1512, 1536, 1568, 1600, 1624, 1664, 1680, 1728, 28x64, 1856, 1920, all.<br><br>The parameter "all" lists all the available speeds and their associated dialing prefixes. |
| "value"       | The dialing suffix, which is a function of your DCE. Consult the DCE user guide for information.                                                                                                                                                                                                                                                                                                                                                              |

### Feedback Examples

- ```
v35suffix set 128
returns
v35suffix 128 <empty>
```
- ```
v35suffix set 128 "#4#2"
returns
v35suffix 128 #4#2
and associates the dialing suffix #4#2 with the speed 128
```
- ```
v35suffix get 128
returns
v35suffix 128 #4#2
```

Comments

User interface screen location: **System > Admin Settings > Network > V.35/RS-449/RS-530 (page 2): Suffix**

See Also

See the [v35profile](#) command on page 4-291.

validateacctnum

Sets or gets the validation for the Global Management System account number that is used when dialing out.

Syntax

```
validateacctnum <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables the Global Management System account number validation option.
no	Disables the Global Management System account number validation option.

Feedback Examples

- validateacctnum yes
returns
validateacctnum yes
- validateacctnum no
returns
validateacctnum no
- validateacctnum get
returns
validateacctnum no

Comments

When the call connects, the system verifies that the account exists with the Global Management System server. If the account does not exist, the call is disconnected.

User interface screen location: **System > Admin Settings > Global Services > Account Validation: Validate Account Number**

This option is only available if **Required Account Number to Dial** is enabled.

vcbutton

Simulates the Visual Concert VSX play and stop buttons. It can also register or unregister to receive notification of Visual Concert VSX events.

Syntax

```
vcbutton <get|play|stop|register|unregister>
```

Parameter	Description
get	Returns the current setting (play or stop).
play	Starts sending the content from the Visual Concert VSX.
stop	Stops sending the content from the Visual Concert VSX.
register	Registers the API session to receive notifications about Visual Concert VSX events.
unregister	Unregisters the API session to receive notifications about Visual Concert VSX events.

Feedback Examples

- vcbutton register
returns
vcbutton registered
- vcbutton get
returns
vcbutton registered
- vcbutton play
returns
Control event: vcbutton play
vcbutton play
- Pressing the play button at the far site
returns
Control event: vcbutton farplay
- Pressing the stop button on the local system
returns
Control event: vcbutton stop

vcraudioout

Enables, disables, or gets the **VCR Audio Out Always On** setting.

Syntax

```
vcraudioout <get|yes|no>
```

Parameter	Description
get	Returns the current setting.
yes	Enables VCR Audio Out Always On.
no	Disables VCR Audio Out Always On.

Feedback Examples

- vcraudioout yes
returns
vcraudioout yes
- vcraudioout no
returns
vcraudioout no
- vcraudioout get
returns
vcraudioout no

vcrrecordsource

Sets or gets the VCR/DVD record source.

Syntax

```
vcrrecordsource get
vcrrecordsource <near|far|auto|content|content-or-near|
content-or-far|content-or-auto|none>
```

Parameter	Description
get	Returns the current setting.
near	Sets the VCR to record the near-site video source.
far	Sets the VCR to record the far-site video source.
auto	Sets the VCR to automatically record the current speaker in a point-to-point call.
content	Sets the VCR to record content, when presented.
content-or-near	Sets the VCR to record near-site video or content, when presented.
content-or-far	Sets the VCR to record far-site video or content, when presented.
content-or-auto	Sets the VCR to record the current speaker or content, when presented.
none	Sets the VCR to record nothing.

Feedback Examples

- `vcrrecordsource near`
returns
`vcrrecordsource near`
- `vcrrecordsource content-or-auto`
returns
`vcrrecordsource content-or-auto`
- `vcrrecordsource get`
returns
`vcrrecordsource content-or-auto`

Comments

If Monitor 2 is enabled, **VCR Record Source** is automatically set to the Monitor 1 image and cannot be configured.

User interface screen location: **System > Admin Settings > Monitors > Monitors** (page 2): **VCR Record Source**

vcstream

Gets the current state of the Visual Concert VSX stream, or registers or unregisters for notification of state changes in the stream.

Syntax

```
vcstream <state|register|unregister>
```

Parameter	Description
state	Returns the current status of the Visual Concert content stream.
register	Registers the Visual Concert stream so that changes to the stream will be displayed to the API control device, and reports the current status of the stream.
unregister	Unregisters the Visual Concert stream.

Feedback Examples

- `vcstream register`
returns
`vcstream registered`
- `vcstream unregister`
returns
`vcstream unregistered`
- `vcstream state`
returns
`vcstream off`

version

Returns the current system's version information.

Syntax

```
version
```

Feedback Examples

- ```
version
```

```
returns
```

```
version "release 8.7 - 26jun2007 11:30"
```

### Comments

User interface screen location: **System > System Information: System Software**

## vgaqualitypreference

Sets or gets the bandwidth split for people and content video.

### Syntax

```
vgaqualitypreference get
vgaqualitypreference <content|people|both>
```

| Parameter | Description                                                       |
|-----------|-------------------------------------------------------------------|
| get       | Returns the current setting.                                      |
| content   | Sets the VGA quality preference to content video.                 |
| people    | Sets the VGA quality preference to people video.                  |
| both      | Sets the VGA quality preference to both people and content video. |

### Feedback Examples

- ```
vgaqualitypreference people
returns
vgaqualitypreference people
```
- ```
vgaqualitypreference content
returns
vgaqualitypreference content
```
- ```
vgaqualitypreference both
returns
vgaqualitypreference both
```
- ```
vgaqualitypreference get
returns
vgaqualitypreference both
```

### Comments

User interface screen location: **System > Admin Settings > Monitors > Graphics VGA**

### See Also

To set the automatic bandwidth adjustment for people and content, use the [contentauto](#) command on page 4-60.

## videocallorder

Sets the video call order of the specified protocol to the specified slot.

### Syntax

```
videocallorder <isdn|h323|sip> <1|2|3>
```

| Parameter | Description                                                                              |
|-----------|------------------------------------------------------------------------------------------|
| isdn      | Specifies ISDN protocol.                                                                 |
| h323      | Specifies IP protocol.                                                                   |
| sip       | Specifies SIP protocol.                                                                  |
| 1 2 3     | Sets the order in which the specified protocol is attempted when a video call is placed. |

### Feedback Examples

- ```
videocallorder h323 1
returns
videocallorder h323 1
```
- ```
videocallorder isdn 2
returns
videocallorder isdn 2
```

### Comments

User interface screen location: **System > Admin Settings > Network > Call Preference** (page 2): **Dialing Order**

### See Also

To set the dialing order for audio-only protocols, use the [voicecallorder](#) command on page 4-301.

## voicecallorder

Sets the voice call order of the specified protocol to the specified slot.

### Syntax

```
voicecallorder <pots|voice|vtx> <1|2|3>
```

| Parameter | Description                                                                                                                                                                                  |
|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| pots      | Specifies analog phone line.                                                                                                                                                                 |
| voice     | Specifies voice over ISDN protocol.                                                                                                                                                          |
| vtx       | Specifies the SoundStation VTX 1000.                                                                                                                                                         |
| 1 2 3     | Sets the order in which the specified method is attempted when a voice call is placed. Positions 1-3 are relative and are shown as 3-5 in the user interface if video protocols are enabled. |

### Feedback Examples

- ```
voicecallorder pots 1
returns
voicecallorder pots 1
```
- ```
voicecallorder voice 2
returns
voicecallorder voice 2
```
- ```
voicecallorder vtx 3
returns
voicecallorder vtx 3
```

Comments

User interface screen location: **System > Admin Settings > Network > Call Preference (page 2): Dialing Order**

See Also

To set the dialing order for video protocols, use the [videocallorder](#) command on page 4-300.

volume

Sets or gets the call audio volume (not sound effects) on the system or registration for volume changes.

Syntax

```
volume <register|unregister>
volume <get|up|down|set {0..50}>
```

Parameter	Description
register	Registers to receive notification when the volume changes.
unregister	Disables register mode.
get	Returns the current volume level.
up	Increases the audio volume by 1.
down	Decreases the audio volume by 1.
set	Sets the volume to a specified level. Requires a volume setting from {0..50}.

Feedback Examples

- ```
volume register
returns
volume registered
```
- ```
If entered again,
volume register
returns
info: event/notification already active:volume
```
- ```
volume set 23
returns
volume 23
```
- ```
volume up
returns
volume 24
```
- ```
volume get
returns
volume 24
```

### Comments

Changes the call audio volume (not sound effects) on the system.

User interface screen location: **System > Admin Settings > Audio** (page 3):  
**Master Audio Volume**



## vortex

Sends commands to a Polycom Vortex mixer.

### Syntax

```
vortex <0|1> mute <on|off>
vortex <0|1> forward "vortex_macro"
```

| Parameter      | Description                                                                                                                     |
|----------------|---------------------------------------------------------------------------------------------------------------------------------|
| 0 1            | Specifies the serial port to which the Vortex mixer is connected.                                                               |
| mute           | Sets the mute state for the Vortex mixer connected to the specified serial port.                                                |
| on             | Mutes the Vortex mixer.                                                                                                         |
| off            | Unmutes the Vortex mixer.                                                                                                       |
| forward        | Forwards the <code>vortex_macro</code> to the Vortex mixer connected to the specified serial port.                              |
| "vortex_macro" | Specifies the Vortex mixer macro command to send. For more information about these commands, refer to the Vortex documentation. |

### Feedback Examples

The response from the Vortex is returned in the following format:

```
vortex <portnum> forward <vortexcmd>:<vortexresponse>
```

- ```
vortex 0 forward FOOPING
```

returns

```
vortex 0 forward FOOPING:FOOPONG
```

if the Vortex responds and

```
vortex 0 forward FOOPING:failed
```

if the Vortex does not respond
- ```
vortex 1 mute on
```

returns

```
vortex 1 mute on
```

and mutes the Vortex connected to the second serial port on the back of the system

### Comments

The Vortex commands are applicable when you have a Vortex mixer connected to a system. An API client can send these commands to control a Vortex mixer using the command format:

```
vortex <portnum> forward <vortexcmd>
```

where <portnum> is 0 if the Vortex is connected to first serial port or 1 if the

Vortex is connected to second serial port, and `<vortexcmd>` is a Vortex-specific command. Whatever value is passed in this parameter will be sent to the Vortex.

## vtxstate

Returns the current state of the SoundStation VTX 1000 conference phone.

### Syntax

```
vtxstate get
```

| Parameter | Description                  |
|-----------|------------------------------|
| get       | Returns the current setting. |

### Feedback Examples

- vtxstate get  
**returns**  
vtxstate false
- vtxstate get  
**returns**  
vtxattached
- vtxstate get  
**returns**  
vtxattachedonhook
- vtxstate get  
**returns**  
vtxattachedoffhook
- vtxstate get  
**returns**  
vtxdetached
- vtxstate get  
**returns**  
vtxerror

## waitfor

This command is used within script files or control panel programs to wait for a specific event before executing the next statement. It causes the API session to wait until a call being placed either connects or fails, or until system is ready to place a call (such as after a reboot waiting for the ISDN lines to come up).

### Syntax

```
waitfor <callcomplete|systemready>
```

| Parameter    | Description                                                                                        |
|--------------|----------------------------------------------------------------------------------------------------|
| callcomplete | Causes the API session to wait until a call being placed either connects or fails.                 |
| systemready  | Causes the system to return the message "system is ready" when the system is ready to make a call. |

### Feedback Examples

- ```
waitfor callcomplete
returns
waiting for call complete
and returns
call is complete
when the call either connects or fails
```
- ```
waitfor systemready
returns
waiting for system ready
and returns
system is ready
when the system is ready to make a call
```

### Comments

This command can be used to synchronize a remote controller with the system. The API session echoes the message "call complete" when the call connects or is aborted.

### See Also

See the [run](#) command on page 4-236.

# wake

Wakes the system from sleep mode.

## Syntax

```
wake
```

## Feedback Examples

- `wake`  
returns  
`wake`  
and wakes the system from sleep mode

## See Also

To put the system in sleep mode, use the [sleep](#) command on page 4-244.

## wanipaddress

Sets or gets the WAN IP address.

### Syntax

```
wanipaddress get
wanipaddress set ["xxx.xxx.xxx.xxx"]
```

| Parameter         | Description                                                                                                                                   |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| set               | Sets the WAN IP address when followed by the "xxx.xxx.xxx.xxx" parameter. To erase the current setting, omit the "xxx.xxx.xxx.xxx" parameter. |
| get               | Returns the WAN IP address.                                                                                                                   |
| "xxx.xxx.xxx.xxx" | WAN IP address.                                                                                                                               |

### Feedback Examples

- ```
wanipaddress set 192.168.1.101
returns
wanipaddress 192.168.1.101
```
- ```
wanipaddress get
returns
wanipaddress 192.168.1.101
```

### Comments

The **NAT Configuration** option on the same page must be set to **Auto**, **Manual**, or **UPnP** for this option to be available.

User interface screen location: **System > Admin Settings > Network > IP > Firewall: NAT Public (WAN) Address**

# webport

Sets or gets the port to use when accessing the system using the web interface.

## Syntax

```
webport get
webport set "port"
```

| Parameter | Description                         |
|-----------|-------------------------------------|
| get       | Returns the current setting.        |
| set       | Sets the web access port to "port". |

## Feedback Examples

- ```
webport set 80
returns
webaccessport 80
restart system for changes to take effect. restart now? <y,n>
```
- ```
webport get
returns
webaccessport 80
```

## Comments

If you change this from the default (port 80), you will need to include the port number with the IP address when you use the web interface to access the system. This makes unauthorized access more difficult. After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > General Settings > Security (page 2): Web Access Port**

## whoami

Displays the same initial banner information as when the RS-232/Telnet session was started with the system.

### Syntax

whoami

### Feedback Examples

- whoami  
**returns**  
Hi, my name is: Polycom VSX Demo  
Here is what I know about myself:  
Model: VSX7000  
Serial Number: 82065205E72EB1  
Software Version: Release 8.7 - 26Jun2007 11:30  
Build Information: root on domain.polycom.com  
FPGA Revision: 4.3.0  
Main Processor: BSP15  
Time In Last Call: 0:43:50  
Total Time In Calls: 87:17:17  
Total Calls: 819  
SNTP Time Service: auto insync ntp1.polycom.com  
Local Time is: Mon, 9 Jul 2007  
Network Interface: NONE  
IP Video Number: 192.168.1.101  
ISDN Video Number: 7005551212  
MP Enabled: True  
H.323 Enabled: True  
FTP Enabled: True  
HTTP Enabled: True  
SNMP Enabled: True



# winsresolution

Sets or gets WINS resolution.

## Syntax

```
winsresolution <get|yes|no>
```

| Parameter | Description                  |
|-----------|------------------------------|
| get       | Returns the current setting. |
| yes       | Enables WINS resolution.     |
| no        | Disables WINS resolution.    |

## Feedback Examples

- winsresolution yes  
returns  
winsresolution yes  
restart system for changes to take effect. restart now? <y,n>
- winsresolution no  
returns  
winsresolution no  
restart system for changes to take effect. restart now? <y,n>
- winsresolution get  
returns  
winsresolution no

## Comments

After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties**  
(page 2): **WINS Resolution**

## winsserver

Sets or gets the WINS server.

### Syntax

```
winsserver get
winsserver set ["xxx.xxx.xxx.xxx"]
```

| Parameter         | Description                                                                                                               |
|-------------------|---------------------------------------------------------------------------------------------------------------------------|
| get               | Returns the WINS server setting.                                                                                          |
| set               | Sets the WINS server IP address to "xxx.xxx.xxx.xxx". To erase the current setting, omit the "xxx.xxx.xxx.xxx" parameter. |
| "xxx.xxx.xxx.xxx" | IP address for the WINS server.                                                                                           |

### Feedback Examples

- ```
winsserver set 192.168.1.101
returns
winsserver 192.168.1.101
restart system for changes to take effect. restart now? <y,n>
```
- ```
winsserver get
returns
winsserver 192.168.1.101
```

### Comments

This option is only available if **IP Address** is set to **Enter IP address manually** on the LAN Properties screen. After making a change, you are prompted to restart the system.

User interface screen location: **System > Admin Settings > LAN Properties** (page 2): **WINS Server**

## xmladvnetstats

Gets advanced network statistics in xml for each call.

### Syntax

```
xmladvnetstats [{0..n}]
```

| Parameter | Description                                                                                                |
|-----------|------------------------------------------------------------------------------------------------------------|
| {0..n}    | Returns stats for call 0, 1, 2, and so on, where n is the maximum number of calls supported by the system. |

### Feedback Examples

- ```

xmladvnetstats
returns
<ADVANCED><CONFERENCE id="0"/><CONNECTION id="1"><FARSITENAME>
Polycom VSX Demo</FARSITENAME><FARSITENUMBER>192.168.1.101
</FARSITENUMBER><FARSITESYSTEM>Polycom/VSX 7000/Release 8.7 -
26Jun2007 11:30</FARSITESYSTEM><CALLTYPE>H.323</CALLTYPE><TRANSMIT>
<AUDIORATE>48 K</AUDIORATE><VIDEORATE>336 K</VIDEORATE>
<VIDEORATEUSED>199 K</VIDEORATEUSED><VIDEOFRAMERATE>15.0
</VIDEOFRAMERATE><VIDEOPACKETLOSS>0</VIDEOPACKETLOSS><VIDEOJITTER>
7 mS</VIDEOJITTER><AUDIOPACKETLOSS>0</AUDIOPACKETLOSS><AUDIOJITTER>
0 mS</AUDIOJITTER><LSDPROTOCOL>---</LSDPROTOCOL><LSDRATE>---
</LSDRATE><MLPPROTOCOL>---</MLPPROTOCOL><MLPRATE>---</MLPRATE>
</TRANSMIT><RECEIVE><AUDIORATE>48 K</AUDIORATE><VIDEORATE>464 K
</VIDEORATE><VIDEORATEUSED>114 K</VIDEORATEUSED><VIDEOFRAMERATE>
29.8</VIDEOFRAMERATE><VIDEOPACKETLOSS>0</VIDEOPACKETLOSS>
<VIDEOJITTER>5 mS</VIDEOJITTER><AUDIOPACKETLOSS>0</AUDIOPACKETLOSS>
<AUDIOJITTER>3 mS</AUDIOJITTER><LSDPROTOCOL>---</LSDPROTOCOL>
<LSDRATE>---</LSDRATE><MLPPROTOCOL>---</MLPPROTOCOL><MLPRATE>---
</MLPRATE></RECEIVE><VIDEOFECERRORS>0</VIDEOFECERRORS><ENCRYPTION>
Disabled</ENCRYPTION></CONNECTION></ADVANCED>

```

xmlnetstats

Gets network statistics in xml for each call.

Syntax

```
xmlnetstats [{0..n}]
```

Parameter	Description
{0..n}	Returns statistics for call 0, 1, 2, and so on, where n is the maximum number of calls supported by the system.

Feedback Examples

- ```
xmlnetstats
returns
<CONFERENCE id="0"/><CONNECTION id="1"><FARSITENAME>
Polycom VSX Demo</FARSITENAME><FARSITENUMBER>192.168.1.101
</FARSITENUMBER><FARSITESYSTEM>Polycom/VSX 7000/Release 8.7 -
26Jun2007 11:30</FARSITESYSTEM><CALLTYPE>H.323</CALLTYPE><TRANSMIT>
<CALLSPEED>512 K</CALLSPEED><B2CALLSPEED>---</B2CALLSPEED>
<TOTPACKETLOSS>0</TOTPACKETLOSS><PERCENTPACKETLOSS>0.0%
</PERCENTPACKETLOSS><VIDEOPROTOCOL>H.264</VIDEOPROTOCOL>
<VIDEOANNEX>---</VIDEOANNEX><VIDEOFORMAT>SIF</VIDEOFORMAT>
<AUDIOPROTOCOL>Siren14</AUDIOPROTOCOL></TRANSMIT><RECEIVE>
<CALLSPEED>512 K</CALLSPEED><B2CALLSPEED>---</B2CALLSPEED>
<TOTPACKETLOSS>0</TOTPACKETLOSS><PERCENTPACKETLOSS>0.0 %
</PERCENTPACKETLOSS><VIDEOPROTOCOL>H.264</VIDEOPROTOCOL>
<VIDEOANNEX>---</VIDEOANNEX><VIDEOFORMAT>SIF</VIDEOFORMAT>
<AUDIOPROTOCOL>Siren14</AUDIOPROTOCOL></RECEIVE><ERRORS>---
</ERRORS><B2ERRORS>---</B2ERRORS><SYNC>---</SYNC><B2SYNC>---
</B2SYNC></CONNECTION></NETWORK>
```

---

# Room Design and Layout

*Reprinted from the Basics of Audio and Visual Systems Design: Revised Edition, Chapter 12, "Videoconferencing" written by Scott Sharer, CTS, and Jim Smith, CVE, CTS, copyright 2003, with permission of InfoComm International®*  
[www.infocomm.org](http://www.infocomm.org)

For clarity of discussion, we have divided this section into the following sub-sections:

- Room construction, including wall construction, windows and window treatments, ceilings and HVAC;
- Interior design and finishes;
- Furniture design, including placement and layout;
- Room acoustics and acoustic treatment; and
- Room lighting.

The initial layout and construction of the space affects all the elements that are discussed in other sections of this book [*Basics of Audio and Visual Systems Design*], including acoustic characteristics and performance, general and ambient light control, and overall comfort.

## Room Requirements

We begin with general room requirements. The total floor space required for VC is much greater than we have become used to for general local presentation and meeting. In architectural terms it is not uncommon to find a rule-of-thumb applied that allows for up to 15 square feet of floor space per participant in a traditional presentation or meeting room. If there is a front-of-room presenter position at a podium, and if there is some use of in-room technology (projection devices, whiteboards, etc.), then this figure may increase to as much as 20 square feet of floor space per participant, but rarely any more than that.

It is here that we have our first conflict. In videoconferencing we have to consider not only the issues related to local viewing and hearing but also the issues of being seen and heard by people at the far-end of the connection. This means that we must consider sight lines and angles of participant interaction that go beyond traditional presentation environments. As a rule we should allow not less than 30 square feet and generally not more than 45 square feet of floor space per participant in a videoconference space. Though two to three times what we are used to allowing, this amount ensures that local participants will see one another and the display of local and remote electronic images. It also ensures that participants at the far-end will see and hear everyone arriving at their location via the connection, and that all will see and hear at a level of quality that does not detract and, in the best deployment, even enhances the communications.

Having determined the required size of the space, we can move on to the actual renovation or construction of the space itself. Again the requirements here are generally less forgiving than those applied in local-only meeting spaces. In the most basic sense this is because, by sheer definition, at least some of the participants in a conference-based meeting are not actually in the room. As such, we cannot count on the typical human mechanisms (the human ears and brain and our ability to locate sound in three-dimensional space) to manage any acoustic anomalies.

If we are, for example, in a room that is adjacent to a double-door entry to the building, then knowing this we can take the inevitable doorway noise into account as we filter the sounds we hear both inside the meeting room and coming from that adjacent entryway. Within our own physical and local environment we have the ability to isolate local unwanted noise from local "sound of interest" (voices of other people, etc.), and place the unwanted noise in an inferior position in our conscious thought pattern. We are able to do this because we know where the noise is coming from and (usually) what is causing it. We may be annoyed by the noise, but we generally are able to ignore it. As soon as we add conferencing to the meeting equation, however, we add the element of electronic pickup and reproduction of all sounds. For the people at the far-end, the unwanted noise is much more difficult (if not impossible) to ignore. They do not have the ability to isolate it in three-dimensional space (the microphones eliminate the spatial reference) and they often do not know what is making the noise. The brain of the far-end participant will devote more and more conscious observation and thought energy to trying to work out these elements, in an attempt to isolate and finally "ignore" the unwanted sound. We have already stated that they cannot do this, however, due to the electronic separation between the locations. Thus they are left with an impossible task that takes up more and more thought energy, eroding the perceived quality of the spoken communication over time. Frustration and exasperation quickly set in, and the communication flow quickly falls apart.

This, then, is one reason we must pay even greater attention to the acoustic and visual issues for any presentation space that will be connected via conference to another. Minor, seemingly insignificant anomalies we often ignore in the local environment become significant impediments to smooth communication

with people at the far-end of any connection. In short, we must always ask ourselves, "What does this look like and sound like to the people at the far end?"

In order to guarantee that the final conference environment will have a solid foundation, we begin with the construction of the walls, floors and ceilings for videoconference spaces.

## Walls

Conference room walls should be built from slab to slab. That is, there should be no gaps from the concrete of one floor to the concrete of the next floor. Resilient, gypsum board mountings should be used to close any gaps. The thickness of the gypsum board should be 5/8" or more (one layer of 5/8" and one layer of 1/2" bonded together would be ideal) on the inside of the room, with 1/2" thick (or as required by local building codes) appropriate for the outside of the walls. There should always be a difference in thickness between the materials used on the inner versus the outer walls. That difference in thickness subdues mechanical coupling (vibration) between the two layers. A good overall wall thickness is 6". It is recommended that "offset stud" construction be used, typically a 6" header and footer with 3.5" verticals attached in an alternating pattern one toward the outside of the footer, the next toward the inside and so on.

Fiberglass dense batting or mineral rock wool, 4" to 6" thick (the equivalent of R-11 to R-13) should be placed in the wall space. The thickness of the batting is not critical. The critical aspect is that it must be loosely placed in the wall space, not compacted to fit. The resultant wall will have excellent acoustic isolation from the outside world. More significant acoustic isolation can be achieved by placing an additional barrier layer within the wall space. Typically this barrier will be made of a dense polymer material, about 1/8" thick, and the improvement regarding loss of sound transmitted through the wall will be roughly a factor of 10. These materials are available from a variety of manufacturers.

## Windows

Windows usually present the equivalent of an acoustic nightmare (as well as altering the way a camera renders colors and brightness). They not only transmit room sound, but also allow unwanted outside noise to intrude on the conference space. In the event that windows cannot be avoided, it becomes essential that window treatment of some sort be used. This treatment should match the interior look and feel of the space, while providing a high level of sound and light block. Typically a heavyweight drape (24 ounces or more) of heavy fullness (not less than 6" fullness on not less than 8" centers per fold) is preferred. In all cases, the use of sheer draperies or standard vertical or horizontal blinds should be avoided, due to their inherent inefficiency in blocking sound and light, and the fine lines they create within the camera field of view.

## Ceiling Tiles

These should be high-quality acoustic tiles, ideally 1"- thick compressed densecore fiberglass. An added benefit of this kind of ceiling tile is that it works well with the indirect lighting as specified elsewhere in this section. To reduce any extraneous noise from leaving or entering the room via the ceiling space, the ceiling tiles can be blanketed completely from the plenum side, with a minimum of 6"- thick unfaced dense fiberglass batting or mineral rock wool, (the equivalent of R-15 to R-19). Here again, a barrier layer will improve the performance, but all local building codes must be followed for allowable materials in the various aspects of room acoustic modifications. To make entry and exit from the ceiling space easier, the blanket and barrier do not need to rest on the ceiling tiles, but may be suspended above it.

## Air Conditioning

It is critical that all air-handling equipment (blowers, heat exchangers, solenoid valves, etc.) be located outside the physical meeting room space. This will prevent the noise burden associated with such equipment from affecting the participants of any meetings held in the room. Location of air-handling equipment within the ceiling space of a conference room often renders that room unusable for video or audio-only conferencing.

The air vents should be of open construction to eliminate "wind noise" while the system is running. These vents normally are specified as "low-velocity" diffusers. The number of air vents within the room should be sufficient to maintain a consistent temperature throughout the space. All HVAC ducts and diffusers should be oversized for the general application in the space, with minimum 2' diameter insulated flexible ducts and matching 2' noise dampening diffusers generally best. All ducts should be installed with gradual bends and curves rather than rigid 90-degree corners. This will minimize "thunder" sounds as the initial air pushes through the ductwork and into the room.

There should be a thermostat to control this specific room system independently of the rest of the building, and that control should be located within the room.

*Important:* Allow an additional 5,000 BTU of cooling capacity for a standard "roll-about" singlemonitor VC system with extended in-room peripherals (PC, document camera, scan converter, etc.) and a minimum of 10,000 BTU for a dual display multimedia presentation system with large screen displays. For the comfort of the participants, the room must accommodate these heat loads, plus the heat load of a room full of people, with minimal temperature rise.



## Interior Design and Finishes

Wall colors within the field of view of the camera have a significant impact on the far-end perception of the room video quality. Certain colors are better suited to video rooms than others. The electronics and software of the videoconferencing system “builds” the images at the far-end from a gray/blue reference image. When there is a minimal difference between the room background and the reference image color, the codec has an easier time turning the image into numbers, with the result that the far-end will see a much higher quality video presentation. In general, light gray with just a touch of blue seems to work best. For rooms that have marginal lighting, slightly darker colors are quite useful.

In keeping with these color recommendations, the acoustic panels (discussed elsewhere in this section) should be ordered in light colors such as silver-gray, quartz or champagne for panels within the camera field of view. For aesthetics, however, panels may be alternated in color along the wall.

## Furniture

As we have noted, VC rooms should be slightly on the large side for the typical number of attendees. The placement of furniture should present a natural rapport with the videoconference system, but shouldn't preclude the local interaction of conference participants. Doorways used for access to the space usually should be within the view of one of the camera presets to prevent the perception from the far-end that people could come into their meeting unseen. Doorways should not, however, be in constant, direct view of the camera system, as this may cause unwanted distractions and movement of people in the picture field.

Any tables within the conference environment should have a light top surface. Glossy tops should be avoided, as should strong colors or any bold wood grain. If glossy or saturated color surfaces are unavoidable, then proper lighting can help reduce (but not necessarily eliminate) their ill effects. The best table surface color is a flat satin finish, in neutral gray. In cases where the worst possible surfaces are present, the proper surface color effect can be achieved by using a table covering, put in place only when the room is being used for videoconferencing. This will, however, create problems related to the use of access ports in the tables or movement of end-user items across the surface.

## Acoustics

Additional general elements related to the interior finish details for the space include acoustics. In terms of ambient noise level, the acoustic design goal for any conference-enabled room is at least NC-30 (NoiseCriteria-30). This level of specification dictates a very quiet space (somewhere around 40-dBC SPL

ambient noise level). A room built to the description found elsewhere in this section will usually fall between NC-30 and NC-35. The actual NC value is not critical; what is important is that the room be built with the intent and care required to achieve the low noise rating. Typically in architectural design, a site evaluation and analysis are required to certify the noise performance of a given space. The quieter the room, the easier it is to hear others in the same room as well as be heard by others who are participating via conference connection to a far-end location (or locations).

Almost every conference room of medium to large size (larger than 12'x15') requires some level of acoustic treatment to provide good speech-rendering to other conference sites. The quality differences lie in the areas of intelligibility and consistency of loudness as presented to the far-end. While the people at the far-end may hear the sounds coming to them, it may be hard for them clearly to distinguish all of the vowels, consonants, inflections and nuances of actual human speech communication. (We all know that it is not simply what you say but how you say it—i.e., the inflections and intonations—that makes the difference in perceived meaning in human communications.)

Good audio practice dictates that the treated surfaces be composed of at least two nonparallel walls. And, as the VCS hardware is a potential source of distracting fan noises, the walls to be treated should include the wall immediately behind the VCS hardware, whenever this hardware is within the conference room proper. To help prevent meeting audio from leaking into adjoining hallways or offices, the walls along those areas also should be treated.

Approximately 50 percent of the wall area needs be covered with acoustic panels. The type recommended is 1" thick compressed, dense-core fiberglass, fabric-covered, or equivalent, with a SABIN (sound absorption index) value of 0.9 average. This specification is sometimes referred to as NRC (noise reduction coefficient). If reduction of sound passing through is required, then an additional barrier layer is laminated to the dense-core material, usually 3/8" thick fiber compression board. The barrier layer is placed against the existing wall material, then the acoustic absorption panels are placed on the interior-room side of that. The barrier panels will have a SABIN of 0.9, but will have an additional specification of an STC (sound transmission coefficient) of 20. STC is a measure of the amount of reduction in loudness of sound passing through the material. Having an STC rating of 20 means there is a factor of 10 reduction in the amount of sound passing through that material. A high-quality conference room wall usually has an STC of 60 or more—that is, less than 1/1,000 of the sound in the room leaks through the wall.

## Room Lighting

The brightness of the lighting in a videoconference room plays an important role in determining the far-end view of the meeting. When there are low to moderate amounts of light—20fc to 35fc (footcandles), typical office lighting—the distance range of “in focus” objects (depth-of-field) usually is

only 2' or 3' from nearest in-focus to furthest in-focus. With bright light (70fc or more) the range of in-focus objects can more than double. Participants at the far-end will see more people in sharp focus, and the codec will have an easier time encoding the image.

Bright standard direct fluorescent lighting has the undesirable side effect of being harsh for the local participants. In addition, the direct down lighting casts significant "drop shadows." The result is undue stress among participants.

The best plan for videoconferencing is to use indirect lighting for 80 to 85 percent of the light, and evenly distributed direct lighting for the remaining 15 to 20 percent. The indirect light will help minimize shadows on the faces of the participants, and make the room more comfortable for viewing the far-end on the TV monitor. The direct light can be used to create backlight separation between foreground and background objects or surfaces.

There should be not less than 55fc and ideally as much as 75fc of light (770lux) on the faces of the participants in the facial field as viewed by the camera in the conference space. The light should be completely even across the field of measure or view, and of one consistent color temperature.

To best meet these requirements, indirect fluorescent lighting most often is recommended. This type of lighting works by using the upper walls and ceiling as diffuse reflectors for the light. The usual recommended color temperature for these is 3,000 to 3,800 degrees Kelvin. If there is a significant quantity of outdoor light entering the room, the lamps should be more than 5,500 degrees Kelvin.

## Light Fixtures

The light fixtures generally recommended for indirect lighting are available from a number of manufacturers. They typically are three-tube, 8" oval indirect up-lights, though they may take the form of chandelier-style pendant lights, wall sconces, cove lights or flushmounted specialized troughs. Many manufacturers work closely with contractors and lighting designers to ensure that the correct light levels and shadow-free zones are designed into the room, especially when used for videoconferencing. Lamps for these fixtures are available in a variety of specified color temperatures from numerous manufacturers, including Sylvania, General Electric and Osram/Phillips. Indirect fixtures are available in a number of different designs or "looks," and can be purchased in configurations that will complement and not detract from the interior design of the space.

Lighting layout recommendations and determination of the number of fixtures needed are handled either by the architectural design firm or by submitting a complete floor plan, including reflected ceiling, walls and furniture placement, to fixture vendors. The vendors will analyze the plans and return a finished lighting layout to the customer, detailing the number of fixtures, placement and required wiring.

It is important to remember that the use of traditional meeting room downcans—even those that have color-corrected light sources—for any lighting in the field of view that may include human faces is to be avoided at all costs. These will result in extremely uneven fields of light, or pools, and heavy, unnatural shadows on the faces of the participants.

## Room Preparation Conclusion

When we follow the above guidelines we dramatically improve the odds for success in the final deployment of live bi-directional conference-based human communications. An added benefit is that this approach dramatically enhances the effectiveness of the room as it operates for more traditional meetings and presentations. The environment is more comfortable and flexible, and less dependent on specialized electronics for “fixing” deficiencies in the environment.

## Audio Elements

Once the space is prepared, we can focus on integration of the various audiovisual tools within the environment: audio, video and control.

### Audio Input

The primary input device for the audio portion of any conference system is the microphone. Elsewhere in this book [*Basics of Audio and Visual Systems Design*] we have discussed how these devices operate within a given acoustic environment. We turn now to a short discussion of how these elements operate within a conference environment, where such factors as “three-to-one” rules and “critical distance” often are pushed to the limit or violated entirely.

When sound travels in a room, it follows “the inverse square law.” This means that the sound level heard at a microphone drops by a factor of four every time the distance doubles. Another important consideration in room audio design is the concept of “critical distance,” or the distance at which the loudness of the room background noise plus reverberation is less than one tenth of the loudness of voices getting to a particular microphone. (This definition is the result of research conducted by Don and Carolyn Davis. that is referenced in the chapter “Designing for Intelligibility” in the Handbook for Sound Engineers.<sup>1</sup>)

<sup>1</sup> Davis, Don and Carolyn. “Designing for Intelligibility” in Handbook for Sound Engineers: The New Audio Cyclopedia, ed. Glen Ballou (Indianapolis: Howard Sams & Co., 1991), 1279-1297.

As an example, we will work with a room having an ambient noise level of approximately 60dBA-SPL. A person speaking in a normal voice is 72dBA-SPL at about 2' distance. At 4' the loudness drops to approximately 66dBA-SPL. This already is farther than the critical distance criteria allow, given the ambient noise level. At 8' distance, a normal speaking voice is approximately 60dBA-SPL. Now the voice energy and the room background noise are about equal. For "send" audio systems in a room to work correctly, therefore, the room noise level would have to be below 40-45dBA-SPL at the microphones at all times. This gives us some measure by which we can begin to plan the microphone array within a space, including selection based on pickup pattern, sensitivity, noise rejection and signal-to-noise in relation to the ambient noise floor or level within the space. The good news is that a room designed and built as described in this section will provide an acoustic space where almost any properly configured and installed audio system can operate with very good results.

Perhaps the most difficult issue for any room designer or system planner is actual microphone placement within the space. Given the fact that many people view conference table space as sacred (to be used for papers, laptops, coffee cups and other end-user items), there often is a great deal of pressure to place the local microphones on the ceiling instead of on the table surface. But this approach must be taken with great caution. We have already seen the dramatic impact of changes in the distance between people (their mouths) and the microphone. Ceiling systems generally place microphones farther away from the participants' mouths, not closer; critical distance calculations may eliminate ceiling placement from consideration for this reason alone. In addition, the ceiling surface generally is one of the noisiest areas of the room. Proximity to HVAC ducts and vents, attachment of tiles and runners to building members that are prone to vibration and shaking, and proximity to noise from other spaces migrating through the plenum make this area one of the least desirable for placement of microphones. This doesn't, however, keep people from looking at this broad open surface as the best place for microphones, to "get them off the table."

If ceiling placement is chosen, the system planner must select the components with great care from a manufacturer that specializes in this type of audio voice reinforcement. The manufacturer must be skilled in live audio and capable of installing the components (that is, being both able and willing to locate microphones at precisely measured distances from speakers, and locating those speakers at precisely measured intervals from each other and from the walls) to extremely tight tolerances. The system provider must fully inform the endusers of the potential downside effects of this approach. In any event, simply mounting a standard tabletop microphone on the ceiling tiles or implementing this solution in an ambient noise environment of 45dBA-SPL or greater will all but guarantee costly failure. No amount of post-microphone processing will fix the problems.

## Audio Output

For conference communication we do not really care about producing the thundering roar of jet aircraft engines, or other sounds reproduced on TV or in the movies. We are interested in reproducing the human voice. The tone, intonation, pitch and level of people speaking from the far-end should sound as much as possible like the sound they would make if they were speaking in the room. Given what has been covered in other sections of this book [*Basics of Audio and Visual Systems Design*], we will touch base here on a couple of simple, basic elements of the speaker technology we deploy in the conference room. These basics fall into three subcategories: direction, power and range/frequency response.

### Direction

As human beings, we feel most comfortable when the voice we hear appears to come from the same direction as the image of the person speaking. This means that reliance on ceiling speakers alone is not an ideal practice when the system is used for videoconferencing. In many small and medium-sized systems, front-firing speakers alone can provide proper direction and adequate coverage. Larger rooms (greater than 12'x15') probably need both front-firing and side or top-fill speakers in order to maintain proper coverage at nominal power levels.

In planning systems for larger rooms, we need to take advantage of the HAAS effect. Basically stated, this is the human brain's interpretation of sound direction when the same sound arrives at the ear from two or more directions within a certain time period. We attribute the direction of the sound to the direction from which the sound is first perceived, even if it is mixed with that same sound arriving from a completely different direction, as long as the two (or more) instances of the sound are within about 30ms of one another. Since sound travels faster electronically than it travels through the open air we may need to add audio delay to the side firing or ceiling speaker arrays in order to keep the primary perceived point source as the front of room/front-firing speakers.

### Power

Power is a function of loudspeaker efficiency and total available system power. Most speakers operate in a power range that is broader than the range in which they operate without distortion. For the purpose of conference communication, we are interested in sound that has little or no distortion. Sound that is reproduced accurately (with no distortion) will most accurately represent the voice of the people from the far-end (our primary goal). Accurate reproduction also will aid the echo-cancellation circuitry in the system, minimizing the amount of echo that the system sends back to the people at the far-end, and thereby increasing perceived ease of intelligibility and understanding. Remember that any distortions present in the playback audio system—whether harmonic, amplitude (gain compression) or temporal (time

delays)—will be recognized by the echo canceller as “new audio information,” and it will send those distortions to the far-end, perhaps wreaking havoc on the system audio quality. In short, speaker power should be matched to overall audio subsystem power. The speakers should provide adequate coverage and be able to present approximately 80 to 85dBA-SPL (continuous) at the local site with the system operating at nominal power utilization, and have a peak reserve of 15 to 20dB before distortion.

## Range/Frequency Response

The human ear is able to hear sounds in a very wide range of frequencies (as low as 70Hz and as high as 12,000Hz). The human voice is able to produce sounds in a narrower range (100Hz to 8,000Hz). Most spoken communication occurs, however, in a range that is only 150Hz to about 6,000Hz. This means that we need to select speakers that operate with ideal performance in a fairly narrow range for human voice (as opposed to speakers used for music, that may have ranges of 20Hz to 20,000Hz). We must also be alert to the crossover characteristics of the speakers we select. Many coaxial and paraxial speakers have their crossover within the middle audio frequencies, thereby inducing potential distortion within the spoken frequency range and creating anomalies within the system that hinder voice communication.

## Video Elements

As a general rule, any display used in a videoconferencing environment should be sized for the number of attendees, the physical distances involved and the type of material presented onscreen. The screen size should allow for clear and easy viewing at the various distances experienced within the room. A measure of required screen size that often is applied to projection technology is: no closer than 1.5 times the diagonal measure and no farther than 7 times that measure. Nobody should have to sit closer than 2 times the screen diagonal measure, nor farther than 8 times that measure.

Direct viewed tube-type displays (monitors) almost always are sharpest and brightest in a videoconferencing environment. “Retro-projector cabinet” displays (which look like largescreen TVs) are next in sharpness and brightness, and “front-screen” projectors come in last. Glare and uncontrolled ambient room lighting adversely affect the quality of the image most with front-screen projectors and least with direct view tubes. A very limited number of frontscreen projection systems have sufficient brightness and contrast to be useful in a properly lit videoconference room.

## Video Projection for Use in Videoconference

Many installations make use of video projection devices. The most important thing to remember in the planning of video projection for a videoconference space is that front projection is vastly inferior to rear projection. Front projection systems are less expensive and easier to implement, but the conflicting interest between the camera and the projection display makes this form of display a very poor choice. Front projection setups operate best when the lighting in the room is dimmed or doused. When this is done, the videoconference cameras can no longer operate, since they require even, bright, color-corrected light. A direct conflict between these two technologies is clear. In the event that a rear projection room cannot be set aside, retro-projection units can be purchased from a number of manufacturers. These units normally are available in sizes ranging from 40" to 72" diagonal measure. To display high-quality video while maintaining optimum lighting for interactive video meetings will require a projector of the "light-valve" or DLP™ class.

Regardless of the exact type of projector selected and the exact nature of "front versus rear," there are certain essential rules for projector placement. The goal in projection is to get the image beam to aim directly into the audience's eyes. In Western cultures the average distance from the floor to a seated person's eye is 4'. That distance becomes the target for the direct beam of the projector. Again keep in mind that front projection should be avoided except in the most extreme cases. If it is employed at all it must be used with an extremely bright projector (2,500 lumens or greater for any space smaller than 25'x40').

## Cameras

There usually is a "main" or "local people" camera positioned on top center of the display, so that it can "see" the participants and anything necessary at the sides of the room, using pan and tilt features. If individual presentations may be made from the side or "front of audience" area of the room, an additional camera should be located at the back of the room, also mounted to allow a view of the presenters when necessary. Some cameras contain an active camera pointing system that also can be used effectively, given proper care in the mounting of the camera assembly. The area immediately surrounding the camera assembly needs to be acoustically "dead" to ensure that the voice tracking and pointing algorithms work correctly. This is another reason to pay close attention to the acoustic environment and acoustic treatment of any space intended for use with this type of camera system.

If local presentation is blended with VC for any events, we must consider the needs of the presenter who will not be "facing" the local image or inbound image displays used by the main body of the local audience. One or two monitors (and a camera) should be mounted at the back of the "audience-end" of the room, with the horizontal centerline at approximately 5' from the floor for ease of presentation interaction between the presenter and the group(s) at the far end(s). Remember that, with the exception of PC-based information that is not in a standard composite narrowband video format, any information we



wish to “show” or “view” must be translated to video, most often with some sort of camera mechanism. Document cameras, 35mm slide-to-video units, video scanners and scan conversion devices all are designed to take one format of source material and convert it to a standard video signal that can be digitized, shipped to the far-end(s), and converted back to composite video for display. Which devices are selected and how they are used depends entirely on the needs and goals of the end-users of the system(s) and the format of their source materials.

## Room Control Elements

To give all participants the easiest use of the room for any and all presentation or conference purposes, a fully integrated room controller is recommended. It is important that one controller operate all devices in the room so that only one user interface needs to be learned by those managing the facility. The common controller also makes it much easier to expand and enhance room capabilities over time by adding or upgrading equipment. A proper room controller can operate and coordinate the use of lighting, curtains, displays, audio devices, VCRs and slide projectors, as well as all the conferencing equipment, including any network-related control needed. In lieu of a complete control system, a limited functionality controller can be located at the presentation interface panel to control the switching and routing of the computer graphics and configure the overhead camera video paths.

It is strongly advised that at least 20 percent of the time spent developing a videoconferencing room be devoted to this important sub-system, as it will complete the integration of the conference and presentation environment.

And remember that simpler is always better. People do not pay for technology. They pay for the benefits that technology can bring. The doorway to those benefits is a simple, straightforward and intuitive user control.



---

## Categorical List of API Commands

The commands are categorized into these sections:

- [API Utility Commands](#)
- [Audio Commands](#)
- [Call Commands](#)
- [Cameras, Content, and Monitors Commands](#)
- [Diagnostics and Statistics Commands](#)
- [Global Services Commands](#)
- [Home Screen Setting Commands](#)
- [Local Directory Commands](#)
- [Network Commands](#)
- [Notification Commands](#)
- [Security and Permissions Commands](#)
- [Serial Port Commands](#)
- [Streaming Commands](#)
- [Systems Settings Commands](#)

## API Utility Commands

- [button](#) on page 4-31
- [dir](#) on page 4-74
- [displayparams](#) on page 4-81
- [echo](#) on page 4-89
- [exit](#) on page 4-99
- [get screen](#) on page 4-119
- [help](#) on page 4-139
- [pause](#) on page 4-198
- [popupinfo](#) on page 4-203
- [reboot](#) on page 4-220
- [remotecontrol](#) on page 4-224
- [rs232monitor](#) on page 4-232
- [run](#) on page 4-236
- [screen](#) on page 4-237
- [screencontrol](#) on page 4-238
- [showpopup](#) on page 4-243
- [sysinfo](#) on page 4-270
- [traceroute](#) on page 4-278
- [version](#) on page 4-298
- [waitfor](#) on page 4-305
- [wake](#) on page 4-306
- [whoami](#) on page 4-309

## Audio Commands

- [alertusertone](#) on page 4-11
- [alertvideotone](#) on page 4-12
- [audiotransmitlevel](#) on page 4-24
- [echocanceller](#) on page 4-90
- [echocancellerred](#) on page 4-92
- [echocancellerwhite](#) on page 4-93
- [gendial](#) on page 4-116
- [gendialtonepots \(deprecated\)](#) on page 4-117
- [generatetone](#) on page 4-118
- [keypadaudioconf](#) on page 4-158
- [midrangespeaker](#) on page 4-171
- [mute](#) on page 4-180
- [muteautoanswer](#) on page 4-181
- [soundeffectsvolume](#) on page 4-254
- [subwoofer](#) on page 4-268
- [subwooferoffset](#) on page 4-269
- [volume](#) on page 4-302

## Call Commands

- [allowmixedcalls](#) on page 4-18
- [answer](#) on page 4-21
- [autoanswer](#) on page 4-25
- [basicmode](#) on page 4-28
- [calldetailreport](#) on page 4-35
- [callpreference](#) on page 4-38
- [chaircontrol](#) on page 4-46
- [contentauto](#) on page 4-60
- [dial](#) on page 4-68
- [dialchannels](#) on page 4-70
- [encryption](#) on page 4-98
- [farnametimedisplay](#) on page 4-101
- [flash](#) on page 4-102
- [gential](#) on page 4-116
- [gentialtonepots \(deprecated\)](#) on page 4-117
- [hangup](#) on page 4-138
- [maxgabinternationalcallspeed](#) on page 4-165
- [maxgabinternetcallspeed](#) on page 4-166
- [maxgabisdncallspeed](#) on page 4-167
- [maxtimeincall](#) on page 4-168
- [mcpassword](#) on page
- [meetingpassword](#) on page 4-170
- [mpautoanswer](#) on page 4-176
- [mpmode](#) on page 4-177
- [muteautoanswer](#) on page 4-181
- [numdigitsdid](#) on page 4-194
- [numdigitsext](#) on page 4-195
- [phone](#) on page 4-199
- [primarycallchoice](#) on page 4-214
- [recentcalls](#) on page 4-221
- [requireacctnumtodial](#) on page 4-228
- [secondarycallchoice](#) on page
- [setaccountnumber](#) on page 4-241
- [validateacctnum](#) on page 4-293
- [videocallorder](#) on page 4-300
- [voicecallorder](#) on page 4-301

## Cameras, Content, and Monitors Commands

- [autoshowcontent](#) on page 4-26
- [backlightcompensation](#) on page 4-27
- [camera](#) on page 4-41
- [cameradirection](#) on page 4-44
- [camerainput](#) on page 4-45
- [colorbar](#) on page 4-48
- [configdisplay](#) on page 4-51
- [configpresentation](#) on page 4-56
- [contentauto](#) on page 4-60
- [displaygraphics](#) on page 4-78
- [dualmonitor](#) on page 4-86
- [farcontrolnearcamera](#) on page 4-100
- [graphicsmonitor](#) on page 4-130
- [h239enable](#) on page 4-131
- [monitor1 \(deprecated\)](#) on page 4-172
- [monitor1saveroutput](#) on page 4-173
- [monitor2 \(deprecated\)](#) on page 4-174
- [monitor2saveroutput](#) on page 4-175
- [mpmode](#) on page 4-177
- [numberofmonitors \(deprecated\)](#) on page 4-192
- [pip](#) on page 4-201
- [preset](#) on page 4-204
- [primarycamera](#) on page 4-215
- [snapshottimeout](#) on page 4-247
- [vcbutton](#) on page 4-294
- [vcrrecordsource](#) on page 4-296
- [vcstream](#) on page 4-297

## Diagnostics and Statistics Commands

- [advnetstats](#) on page 4-9
- [audiometer](#) on page 4-23
- [calldetail](#) on page 4-34
- [callinfo](#) on page 4-37
- [callstate](#) on page 4-39
- [colorbar](#) on page 4-48
- [generatetone](#) on page 4-118
- [getcallstate](#) on page 4-120
- [linestate](#) on page 4-161
- [nearloop](#) on page 4-184
- [netstats](#) on page 4-185
- [ping](#) on page 4-200
- [recentcalls](#) on page 4-221
- [rs232monitor](#) on page 4-232
- [serialnum](#) on page 4-240
- [techsupport](#) on page 4-273
- [telnetmonitor](#) on page 4-276
- [traceroute](#) on page 4-278
- [xmladvnetstats](#) on page 4-312
- [xmlnetstats](#) on page 4-313

## Global Services Commands

- [addressdisplayedgab](#) on page 4-7
- [displayglobaladdresses](#) on page 4-77
- [enablesnmp](#) on page 4-97
- [gabk](#) on page 4-103
- [gabpassword](#) on page 4-104
- [gabserverip](#) on page 4-105
- [gmscopy](#) on page 4-121
- [gmscontactemail](#) on page 4-122
- [gmscontactfax](#) on page 4-123
- [gmscontactnumber](#) on page 4-124
- [gmscontactperson](#) on page 4-125
- [gmscountry](#) on page 4-126
- [gmsstate](#) on page 4-127
- [gmstechsupport](#) on page 4-128
- [gmsurl](#) on page 4-129
- [registerthissystem](#) on page 4-223
- [requireacctnumtodial](#) on page 4-228
- [setaccountnumber](#) on page 4-241
- [snmpadmin](#) on page 4-248
- [snmpcommunity](#) on page 4-249
- [snmpconsoleip](#) on page 4-250
- [snmplocation](#) on page 4-251
- [snmpsystemdescription](#) on page 4-252
- [systemname](#) on page 4-271
- [techsupport](#) on page 4-273
- [usepathnavigator](#) on page 4-284
- [validateacctnum](#) on page 4-293

## Home Screen Setting Commands

- [allowdialing](#) on page 4-17
- [dialingdisplay](#) on page 4-71
- [dialingentryfield](#) on page 4-72
- [directory](#) on page 4-75
- [displayipisdninfo](#) (deprecated) on page 4-80
- [homequality](#) on page 4-141
- [homemultipoint](#) on page 4-142
- [homerecentcalls](#) on page 4-143
- [homesystem](#) on page 4-144
- [homesystemname](#) on page 4-145
- [ipisdninfo](#) on page 4-149
- [localdatetime](#) on page 4-163
- [marqueedisplaytext](#) on page 4-164

## Local Directory Commands

- [abk](#) on page 4-5
- [allowabkchanges](#) on page 4-15
- [confirmdiradd](#) on page 4-58
- [confirmdir](#) on page 4-59
- [directory](#) on page 4-75

## Network Commands

### IP Commands

- [callpreference](#) on page 4-38
- [defaultgateway](#) on page 4-66
- [dhcp](#) on page 4-67
- [diffservaudio](#), [diffservfecc](#), [diffservvideo](#), on page 4-73
- [displayipext](#) on page 4-79
- [dns](#) on page 4-82
- [dynamicbandwidth](#) on page 4-87
- [e164ext](#) on page 4-88
- [enablefirewalltraversal](#) on page 4-94
- [enablersvp](#) on page 4-96
- [gatekeeperip](#) on page 4-106
- [gatewayareacode](#) on page 4-108
- [gatewaycountrycode](#) on page 4-109
- [gatewayext](#) on page 4-110
- [gatewaynumber](#) on page 4-111
- [gatewaynumbertype](#) on page 4-112
- [gatewayprefix](#) on page 4-113
- [gatewaysetup](#) on page 4-114
- [gatewaysuffix](#) on page 4-115
- [h323name](#) on page 4-132
- [hostname](#) on page 4-146
- [ipaddress](#) on page 4-147
- [ipdialspeed](#) on page 4-148
- [ipprecaudio](#), [ipprecfecc](#), [ipprecvideo](#) on page 4-150
- [ipstat](#) on page 4-151
- [lanport](#) on page 4-160
- [linestate](#) on page 4-161
- [mtumode](#) on page 4-178
- [mtusize](#) on page 4-179
- [nath323compatible](#) on page 4-183
- [natconfig](#) on page 4-182
- [ntpmode](#) on page 4-190
- [numdigitsdid](#) on page 4-194
- [numdigitsext](#) on page 4-195
- [subnetmask](#) on page 4-267
- [tcpports](#) on page 4-272
- [typesofservice](#) on page 4-279
- [udpports](#) on page 4-280
- [usefixedports](#) on page 4-282
- [usegatekeeper](#) on page 4-283
- [usepathnavigator](#) on page 4-284
- [wanipaddress](#) on page 4-307
- [webport](#) on page 4-308
- [winsresolution](#) on page 4-310
- [winsserver](#) on page 4-311

## ISDN Commands

The following commands are only applicable if you have an ISDN network interface connected to your system

- [bri1enable, bri2enable, bri3enable, bri4enable](#) on page 4-29
- [briallenable](#) on page 4-30
- [callpreference](#) on page 4-38
- [dialchannels](#) on page 4-70
- [isdnareacode](#) on page 4-152
- [isdncountrycode](#) on page 4-153
- [isdndialingprefix](#) on page 4-154
- [isdndialspeed](#) on page 4-155
- [isdnum](#) on page 4-156
- [isdnswitch](#) on page 4-157
- [linestate](#) on page 4-161
- [maxgabinternationalcallspeed](#) on page 4-165
- [maxgabisdncallspeed](#) on page 4-167
- [priareacode](#) on page 4-205
- [pricallbycall](#) on page 4-206
- [prichannel](#) on page 4-207
- [pricsu](#) on page 4-209
- [pridialchannels](#) on page 4-210
- [priintlprefix](#) on page 4-211
- [prilinebuildout](#) on page 4-212
- [prilinesignal](#) on page 4-213
- [prinumber](#) on page 4-216
- [prinumberingplan](#) on page 4-217
- [prioutsideline](#) on page 4-218
- [priswitch](#) on page 4-219
- [spidnum](#) on page 4-255

## Telephony Commands

- [callpreference](#) on page 4-38
- [teleareacode](#) on page 4-274
- [telenumber](#) on page 4-275
- [voicecallorder](#) on page 4-301

## V.35/RS-449/RS-530 Commands

The following commands are only applicable if you have a V.35 network interface connected to your system.

- [callpreference](#) on page 4-38
- [cts](#) on page 4-62
- [dcd](#) on page 4-64
- [dcdfilter](#) on page 4-65
- [dsr](#) on page 4-83
- [dsranswer](#) on page 4-84
- [dtr](#) on page 4-85
- [h331audiomode](#) on page 4-133
- [h331dualstream](#) on page 4-134
- [h331framerate](#) on page 4-135
- [h331videoframe](#) on page 4-136
- [h331videoprotocol](#) on page 4-137
- [rs366dialing](#) on page 4-233
- [rt](#) on page 4-234
- [rts](#) on page 4-235
- [st](#) on page 4-257
- [v35broadcastmode](#) on page 4-286
- [v35dialingprotocol](#) on page 4-287
- [v35num](#) on page 4-288
- [v35portsused](#) on page 4-289
- [v35prefix](#) on page 4-290
- [v35profile](#) on page 4-291
- [v35suffix](#) on page 4-292



## Notification Commands

- [all register](#) on page 4-13
- [all unregister](#) on page 4-14
- [button](#) on page 4-31
- [callstate](#) on page 4-39
- [configchange \(deprecated\)](#) on page 4-50
- [linestate](#) on page 4-161
- [listen](#) on page 4-162
- [nonotify](#) on page 4-186
- [notify](#) on page 4-187
- [pip](#) on page 4-201
- [registerall](#) on page 4-222
- [sysinfo](#) on page 4-270
- [unregisterall](#) on page 4-281

## Security and Permissions Commands

- [adminpassword](#) on page 4-8
- [allowabkchanges](#) on page 4-15
- [allowcamerapresetssetup](#) on page 4-16
- [allowdialing](#) on page 4-17
- [allowusersetup](#) on page 4-20
- [confirmdiradd](#) on page 4-58
- [confirmdirdel](#) on page 4-59
- [encryption](#) on page 4-98
- [gabpassword](#) on page 4-104
- [meetingpassword](#) on page 4-170
- [remotemonenable](#) on page 4-226
- [useroompassword](#) on page 4-285

## Serial Port Commands

- [rs232 baud, rs232port1 baud](#) on page 4-230
- [rs232 mode, rs232port1 mode](#) on page 4-231
- [rs232monitor](#) on page 4-232

## Streaming Commands

- [allowstreaming](#) on page 4-19
- [numberofrouterhops](#) on page 4-193
- [stream](#) on page 4-258
- [streamannounce](#) on page 4-259
- [streamaudioport](#) on page 4-260
- [streamenable](#) on page 4-261
- [streammulticastip](#) on page 4-262
- [streamrestoredefaults](#) on page 4-263
- [streamrouterhops](#) on page 4-264
- [streamspeed](#) on page 4-265
- [streamvideoport](#) on page 4-266

## Systems Settings Commands

- [colorscheme](#) on page 4-49
- [country](#) on page 4-61
- [daylightsavings](#) on page 4-63
- [dialingdisplay](#) on page 4-71
- [displayipext](#) on page 4-79
- [displayparams](#) on page 4-81
- [farnametimedisplay](#) on page 4-101
- [keypadaudioconf](#) on page 4-158
- [language](#) on page 4-159
- [maxtimeincall](#) on page 4-168
- [mpautoanswer](#) on page 4-176
- [ntpmode](#) on page 4-190
- [ntpserver](#) on page 4-191
- [pip](#) on page 4-201
- [roomphonenumber](#) on page 4-229
- [serialnum](#) on page 4-240
- [sleep](#) on page 4-244
- [sleeptext](#) on page 4-245
- [sleeptime](#) on page 4-246
- [snapshottimeout](#) on page 4-247
- [snmplocation](#) on page 4-251
- [systemname](#) on page 4-271
- [teleareacode](#) on page 4-274
- [telenumber](#) on page 4-275
- [timediffgmt](#) on page 4-277
- [version](#) on page 4-298

---

# Commands that Prompt Restart

The following commands return a prompt to restart the system.



To minimize the number of times your system restarts, Polycom recommends using the user interface or the system's web interface to configure the settings associated with the following API commands.

- `callpreference`
- `configdisplay monitor1 vga|s_video` (prompts a restart only when changing from composite or S-Video to VGA, or from VGA to composite or S-Video)
- `configparam enable_ftp_access`
- `configparam enable_telnet_access`
- `configparam enable_web_access`
- `defaultgateway set`
- `dhcp off|client|server`
- `dns set`
- `enablesnmp`
- `hostname set`
- `ipaddress set`
- `lanport`
- `reboot yes`
- `subnetmask set`
- `snmpadmin`
- `snmpcommunity`
- `snmpconsoleip`
- `snmplocation`
- `snmpsystemdescription`
- `webport set`

- `winsresolution yes|no`
- `winsserver set`

**The restart prompt is:**

`restart system for changes to take effect. restart now? <y,n>`

Typing `n` cancels the restart. Typing `y` returns restarting in 3 seconds...  
and the system reboots.

---

# API Changes in This Version

The following changes have been made to the API for version 8.7.

## Commands Introduced in Version 8.7

- [configparam](#) command on page 4-52
- [enablepvec](#) command on page 4-95
- [overlayname](#) command on page 4-196
- [overlaytheme](#) command on page 4-197
- [showgatekeeper](#) command on page 4-242
- [snmptrapversion](#) command on page 4-253
- [vcraudioout](#) command on page 4-295
- [vgaqualitypreference](#) command on page 4-299

## Commands Newly Deprecated in Version 8.7

- [configchange \(deprecated\)](#) on page 4-50
- [displayipisdninfo \(deprecated\)](#) on page 4-80
- [gentialtonepots \(deprecated\)](#) on page 4-117



---

# Status Messages

## Status Display

The call status can be displayed in a number of ways. The `getcallstate` command on page 4-120 returns a table listing the status, speed, and dialed number of current calls.

To display real-time status on individual B channels (incoming or outgoing calls), either register the API session with the `callstate` command on page 4-39, or start an outbound call with the `dial` command on page 4-68. These two commands will cause the system to re-direct the B channel status messages to the session which has issued one of these two commands. For example, if the RS-232 device issues a `dial` command, then call status is directed to the RS-232 port; if a later session on a Telnet port issues a `dial` command, then call status is also directed to that Telnet port.

## B Channel Status Message Example

The following output example is for B channel status messages, where:

|           |                                                                                                         |
|-----------|---------------------------------------------------------------------------------------------------------|
| cs        | Indicates call status for one B channel.                                                                |
| RINGING   | Indicates a ring-in or ring-out and is equivalent to a 25% blue sphere on the graphical user interface. |
| CONNECTED | Is equivalent to a 50% yellow sphere.                                                                   |
| BONDING   | Indicates the bonding protocol is operational on the channel and is equivalent to a 75% orange sphere.  |
| COMPLETE  | Is equivalent to a 100% green sphere.                                                                   |

## Feedback Examples

- dial manual 384 5551212 ISDN  
**returns**  
 Dialing manual  
 Dialing 5551212 384 none ISDN  
 cs: call[0] chan[0] dialstr[95551212] state[RINGING]  
 cs: call[0] chan[0] dialstr[95551212] state[CONNECTED]  
 cs: call[0] chan[0] dialstr[95551212] state[BONDING]  
 cs: call[0] chan[0] dialstr[95551212] state[COMPLETE]  
 cs: call[0] chan[1] dialstr[95551212] state[RINGING]  
 cs: call[0] chan[1] dialstr[95551212] state[CONNECTED]  
 cs: call[0] chan[2] dialstr[95551212] state[RINGING]  
 cs: call[0] chan[3] dialstr[95551212] state[RINGING]  
 cs: call[0] chan[2] dialstr[95551212] state[CONNECTED]  
 cs: call[0] chan[3] dialstr[95551212] state[CONNECTED]  
 cs: call[0] chan[4] dialstr[95551212] state[RINGING]  
 cs: call[0] chan[5] dialstr[95551212] state[RINGING]  
 cs: call[0] chan[4] dialstr[95551212] state[CONNECTED]  
 cs: call[0] chan[5] dialstr[95551212] state[CONNECTED]  
 cs: call[0] chan[1] dialstr[95551212] state[BONDING]  
 cs: call[0] chan[2] dialstr[95551212] state[BONDING]  
 cs: call[0] chan[3] dialstr[95551212] state[BONDING]  
 cs: call[0] chan[4] dialstr[95551212] state[BONDING]  
 cs: call[0] chan[5] dialstr[95551212] state[BONDING]  
 cs: call[0] chan[0] dialstr[95551212] state[COMPLETE]  
 cs: call[0] chan[1] dialstr[95551212] state[COMPLETE]  
 cs: call[0] chan[2] dialstr[95551212] state[COMPLETE]  
 cs: call[0] chan[3] dialstr[95551212] state[COMPLETE]  
 cs: call[0] chan[4] dialstr[95551212] state[COMPLETE]  
 cs: call[0] chan[5] dialstr[95551212] state[COMPLETE]  
 active: call[0] speed[384]
- hangup video 0  
**returns**  
 hanging up video call  
 cleared: call[0] line[1] bchan[0] cause[16] dialstring[95551212]  
 cleared: call[0] line[2] bchan[0] cause[16] dialstring[95551212]  
 cleared: call[0] line[0] bchan[0] cause[16] dialstring[95551212]  
 cleared: call[0] line[1] bchan[1] cause[16] dialstring[95551212]  
 cleared: call[0] line[2] bchan[1] cause[16] dialstring[95551212]  
 cleared: call[0] line[0] bchan[1] cause[16] dialstring[95551212]  
 ended call[0]



- listen video

**returns**

listen video registered

```
listen video ringing // there is an incoming call, auto answer
is on
```

```
cs: call[0] chan[0] dialstr[7005551212] state[RINGING]
cs: call[0] chan[0] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[0] dialstr[7005551212] state[BONDING]
cs: call[0] chan[0] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[1] dialstr[7005551212] state[RINGING]
cs: call[0] chan[1] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[2] dialstr[7005551212] state[RINGING]
cs: call[0] chan[3] dialstr[7005551212] state[RINGING]
cs: call[0] chan[2] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[3] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[6] dialstr[7005551212] state[RINGING]
cs: call[0] chan[6] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[4] dialstr[7005551212] state[RINGING]
cs: call[0] chan[5] dialstr[7005551212] state[RINGING]
cs: call[0] chan[4] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[5] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[7] dialstr[7005551212] state[RINGING]
cs: call[0] chan[7] dialstr[7005551212] state[CONNECTED]
cs: call[0] chan[1] dialstr[7005551212] state[BONDING]
cs: call[0] chan[2] dialstr[7005551212] state[BONDING]
cs: call[0] chan[3] dialstr[7005551212] state[BONDING]
cs: call[0] chan[6] dialstr[7005551212] state[BONDING]
cs: call[0] chan[4] dialstr[7005551212] state[BONDING]
cs: call[0] chan[5] dialstr[7005551212] state[BONDING]
cs: call[0] chan[7] dialstr[7005551212] state[BONDING]
cs: call[0] chan[0] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[1] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[2] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[3] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[6] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[4] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[5] dialstr[7005551212] state[COMPLETE]
cs: call[0] chan[7] dialstr[7005551212] state[COMPLETE]
active: call[0] speed[512]
```



# IR Codes for Non-Polycom Remotes

This appendix provides information about the IR signals for VSX systems.



This information is provided for reference only. Polycom claims no responsibility or liability for programmed third-party remote control devices.

## Notes

- Wake up—2.6 ms on, 2.6 ms off
- “0”—559 us (22 pulses at 38 kHz) on, 845 us (33 pulses at 38 kHz) off
- “1”—845 us (33 pulses at 38 kHz) on, 1192 us (46 pulses at 38 kHz) off
- EOM—559 us (22 pulses at 38 kHz) on
- System code—“00110101” or 35 hex
- Parity—“00” for even, “01” for odd, and inverts every other time. For example, if parity is odd, first key press is 01, next is 11, next is 01, etc. The first bit is the toggle bit; the second bit is the parity bit.
- Inter-burst timing—2200 pulse times at 38.062 kHz or 57.8 ms
- 38.062 kHz signal—at 1/3 duty cycle to LED
- Protocol—Wake up + System code + Key Code + Parity + EOM

The following table provides binary and hex codes for the IR signals you can send to VSX systems.

| Button/Signal | Binary Code | Hex Code | Parity |
|---------------|-------------|----------|--------|
| 0             | 110000      | 30H      | Even   |
| 1             | 110001      | 31H      | Odd    |
| 2             | 110010      | 32H      | Odd    |
| 3             | 110011      | 33H      | Even   |

| Button/Signal | Binary Code | Hex Code | Parity |
|---------------|-------------|----------|--------|
| 4             | 110100      | 34H      | Odd    |
| 5             | 110101      | 35H      | Even   |
| 6             | 110110      | 36H      | Even   |
| 7             | 110111      | 37H      | Odd    |
| 8             | 111000      | 38H      | Odd    |
| 9             | 111001      | 39H      | Even   |
| #             | 001100      | 0CH      | Even   |
| *             | 001011      | 0BH      | Odd    |
| Auto          | 011001      | 19H      | Odd    |
| Call          | 100101      | 25H      | Odd    |
| Call/Hang Up  | 000011      | 03H      | Even   |
| Colon         | 101111      | 2FH      | Odd    |
| Delete        | 100010      | 22H      | Even   |
| Dial String   | 000000      | 00H      | Even   |
| Directory     | 011010      | 1AH      | Odd    |
| Dot           | 100001      | 21H      | Even   |
| Down Arrow    | 000110      | 06H      | Even   |
| Far           | 010001      | 11H      | Even   |
| Feet Down     | 010110      | 16H      | Odd    |
| Feet Up       | 011000      | 18H      | Even   |
| Hang Up       | 100110      | 26H      | Odd    |
| Home          | 011011      | 1BH      | Even   |
| Info (Help)   | 010100      | 14H      | Even   |
| Keyboard      | 100011      | 23H      | Odd    |
| Left Arrow    | 001001      | 09H      | Even   |
| Low Battery   | 010111      | 17H      | Even   |
| Menu (Back)   | 010011      | 13H      | Odd    |
| Mute          | 111010      | 3AH      | Even   |
| Near          | 001111      | 0FH      | Even   |
| Option        | 101000      | 28H      | Even   |

---

| Button/Signal     | Binary Code | Hex Code | Parity |
|-------------------|-------------|----------|--------|
| Power             | 100111      | 27H      | Even   |
| Return            | 000111      | 07H      | Odd    |
| Right Arrow       | 001010      | 0AH      | Even   |
| Slides (Graphics) | 010010      | 12H      | Even   |
| Snapshot (Snap)   | 010101      | 15H      | Odd    |
| Up Arrow          | 000101      | 05H      | Even   |
| Volume Down       | 111100      | 3CH      | Even   |
| Volume Up         | 111011      | 3BH      | Odd    |
| Zoom In           | 001101      | 0DH      | Odd    |
| Zoom Out          | 001110      | 0EH      | Odd    |



---

# Index

## Symbols

! command 4-3

## A

abk command 4-5

account number

command for requiring 4-228

command for setting 4-241

command for validating 4-293

adapters

BNC to S-Video 2-11

null modem 2-35

RS-232 2-20

S-Video to RCA 2-22

V.35/RS-449/RS-530 2-4

addressdisplayingab command 4-7

adminpassword command 4-8

advnetstats command 4-9

alertusertone command 4-11

alertvideotone command 4-12

all register command 4-13

all unregister command 4-14

Allow Video Display on Web 4-226

allowabkchanges command 4-15

allowcamerapresetssetup command 4-16

alldialing command 4-16, 4-17

allowmixedcalls command 4-18

allowstreaming command 4-19

allowusersetup command 4-20

answer command 4-21

API

using over LAN 3-3

using over RS-232 3-1

API utility commands B-2

area code

command for BRI 4-22

command for gateway 4-108

command for ISDN 4-152

command for PRI 4-205

command for system 4-274

areacode command 4-22

attenuator, subwoofer volume 2-29

audio

cable 2-23

connector, balanced 2-25

integration 1-18

audio commands B-2

audio mode, command for H.331 calls 4-133

audio out, VCR 4-295

audio port, command for stream 4-260

audiometer command 4-23

audiotransmitlevel 4-24

Authentication Pin 4-107

auto answer, command for multipoint 4-176

auto mode, command for multipoint display  
4-177

autoanswer command 4-25

## B

B channel status messages E-1

backlightcompensation command 4-27

bandwidth 4-299

basicmode command 4-28

baud rate, command to set RS-232 port 4-230

BNC adapter 2-11

BNC to S-Video cable 2-10

BRI cable 2-2

briallenable command 4-30

brienable commands 4-29

broadcaster setting 4-47

broadcasting, V.35 command 4-286

button command 4-31

## C

### cables

- analog telephone 2-3
- audio 2-23
- BNC to S-Video 2-10
- BRI 2-2
- composite video 2-14
- ImageShare II 2-37
- ISDN 2-2
- LAN 2-1
- null modem 2-34
- plenum-rated CAT5 adapters 1-5
- POTS 2-3
- PowerCam break-out 2-17
- PowerCam control 2-18, 2-21
- PowerCam Plus primary 2-15
- PowerCam primary 2-16
- PRI 2-2
- RS-232 2-30
- RS-366 2-6, 2-7, 2-8
- RS-449 2-7
- RS-530 2-8
- serial 2-32
- S-Video 2-9
- V.35 2-5, 2-6
- VCR/DVD composite 2-12
- VGA 2-13
- VISCA 2-18
- Visual Concert 2-36
- Visual Concert to VTX 2-28
- Vortex 2-24, 2-26
- VSX to VTX 2-27

call commands B-3

call quality, command for access 4-141

call speed

- command for Internet 4-166
- command for ISDN 4-167
- international calls, maximum speed 4-165
- maximum command 4-165

call status, displaying E-1

call type

- primary 4-214
- secondary 4-239

calldetail command 4-34

calldetailreport command 4-35

callencryption command 4-36

callinfo command 4-37

callpreference command 4-38

callstate command 4-39

callstats command 4-40

camera command 4-41

camera commands B-3

camera presets, command to allow 4-16

cameradirection command 4-44

camerainput command 4-45

cameras, connecting

- ELMO camera 1-18
- PowerCam as main camera 1-6–1-8
- PowerCam as secondary camera 1-8
- PowerCam Plus as main camera 1-13
- PTZ camera 1-15
- Sony camera 1-18

chaircontrol command 4-46

city, command for GMS 4-121

colorbar command 4-48

colorscheme command 4-49

command, configuring parameters 4-52

composite video cable 2-14

configchange command 4-50

configdisplay command 4-51

configparam command 4-52

configpresentation command 4-56

configuration settings 4-52

configuring parameters 4-52

confirmdiradd command 4-58

confirmdirdel command 4-59

connectors

- balanced audio 2-25
- IR receiver 2-38
- subwoofer 2-29

contact, command for GMS 4-122, 4-125

content commands B-3

contentauto command 4-60

conventions, syntax 4-2

country code

- command for gateway 4-109
- command for ISDN 4-153

country command 4-61

country, command for GMS 4-126

Crestron systems 2-35, 3-3

cts command 4-62

## D

date and time, command to display 4-163

daylightsavings command 4-63

dcd command 4-64

dcdfilter command 4-65

defaultgateway command 4-66

dhcp command 4-67

diagnostics commands B-4



dial command 4-68  
dialchannels command 4-70  
dialing  
  command for allowing 4-16, 4-17  
  command for RS-366 4-233  
dialing order  
  command for primary choice 4-214  
  command for secondary choice 4-239  
  command for video calls 4-300  
  command for voice calls 4-301  
dialing prefix  
  command for PRI international 4-211  
  command for V.35 4-290  
dialing speed  
  command for IP 4-148  
  command for ISDN 4-155  
dialing tones, generating 4-117  
dialingdisplay command 4-71  
dialingentryfield command 4-72  
diffservaudio command 4-73  
diffservfec command 4-73  
diffservvideo command 4-73  
dir command 4-74  
directory  
  command for allowing changes 4-15  
  command for confirming additions 4-58  
  command for confirming deletions 4-59  
directory command 4-75  
directory commands B-5  
discussion mode, command for multipoint  
  display 4-177  
display command 4-76  
displayglobaladdresses command 4-77  
displaygraphics command 4-78  
displayipext command 4-79  
displayipisdninfo command 4-80  
displayparams command 4-81  
dns command 4-82  
do not disturb setting  
  for multipoint calls 4-176  
  for point-to-point calls 4-25  
dsr command 4-83  
dsranswer command 4-84  
DTMF dialing tones, generating 4-117  
dtr command 4-85  
dual stream setting, command for H.331 calls  
  4-134  
dualmonitor command 4-86  
dynamicbandwidth command 4-87

## E

e164ext command 4-88  
echo command 4-89  
echocanceller 4-90  
echocancellerred command 4-92  
echocancellerwhite command 4-93  
Edgewater NAT/firewall traversal 4-94  
ELMO cameras 1-18  
email contact, command for GMS 4-122  
enablefirewalltraversal command 4-94  
enablepvec command 4-95  
enablersvp command 4-96  
enablesnmp command 4-97  
encryption command 4-98  
event notification commands B-7  
exit command 4-99  
extension, command for gateway 4-110

## F

farcontrolnearcamera command 4-100  
farnametimedisplay command 4-101  
fax, command for GMS 4-123  
firewall traversal, NAT traversal 4-94  
flash command 4-102  
frame rate, command for H.331 calls 4-135  
fullscreen mode, command for multipoint  
  display 4-177

## G

gabk command 4-103  
gabpassword command 4-104  
gabserverip command 4-105  
gatekeeper, command for mode 4-283  
gatekeeperip command 4-106, 4-107  
gatekeeperpin command 4-107  
gateway, command for default 4-66  
gatewayareacode command 4-108  
gatewaycountrycode command 4-109  
gatewayext command 4-110  
gatewaynumber command 4-111  
gatewaynumbertype command 4-112  
gatewayprefix command 4-113  
gatewaysetup command 4-114  
gatewaysuffix command 4-115

## GDS

- command for display 4-77
- command for server 4-105
- password 4-104

gential command 4-116

gentialtonepots command 4-117

generatetone command 4-118

get screen command 4-119

getcallstate command 4-120

global directory

- displaying address in 4-7
- maximum call speed 4-165, 4-166, 4-167
- returning entries 4-103

global services commands B-4

## GMS

- command for email 4-122
- command for support number 4-128

gmscity command 4-121

gmscontactemail command 4-122

gmscontactfax command 4-123

gmscontactnumber command 4-124

gmscontactperson command 4-125

gmscountry command 4-126

gmsstate command 4-127

gmstechsupport command 4-128

gmsurl command 4-129

graphicsmonitor command 4-130

## H

H.323 commands B-5

H.460 firewall traversal 4-94

h239enable command 4-131

h323name command 4-132

h331audiomode command 4-133

h331dualstream command 4-134

h331framerate command 4-135

h331videoformat command 4-136

h331videoprotocol command 4-137

hangup command 4-138

help command 4-139

history command 4-140

history list 4-3

home screen IP and ISDN information display 4-149

home screen setting commands B-4

homequality command 4-141

homemultipoint command 4-142

homerecentcalls command 4-143

homesystem command 4-144

homesystemname command 4-145

hostname command 4-146

## I

icons, command for displaying 4-78

ImageShare II cable 2-37

InstantDesigner, recommendation 1-18

inverted signal

command for CTS 4-62

command for DCD 4-64

command for DSR 4-83

command for DTR 4-85

command for RT 4-234

command for RTS 4-235

command for ST 4-257

IP command for line state changes 4-161

IP commands B-5

IP dialing speed 4-148

IP information display on home screen 4-149

ipaddress command 4-147

ipdialspeed command 4-148

ipisdninfo command 4-149

ipprecaudio command 4-150

ipprecfecc command 4-150

ipprecvideo command 4-150

ipstat command 4-151

IR codes F-1

IR receiver connector 2-38

ISDN cable 2-2

ISDN command for line state changes 4-161

ISDN commands B-6

ISDN dialing speed 4-155

ISDN information display on home screen 4-149

isdnareacode command 4-152

isdncountrycode command 4-153

isdndialingprefix command 4-154

isdndialspeed command 4-155

isdnum command 4-156

isdnswitch command 4-157

## K

keypadaudioconf command 4-158

## L

LAN cable 2-1

language command 4-159

lanport command 4-160

- linestate command 4-161
- listen command 4-162
- localdatetime command 4-163
- M**
- marqueedisplaytext command 4-164
- maxgabinternationalcallspeed command 4-165
- maxgabinternetcallspeed command 4-166
- maxgabisdncallspeed command 4-167
- maxtimeincall command 4-168
- mcupassword command 4-169
- meetingpassword command 4-170
- midrangespeaker command 4-171
- monitor
  - command for graphics 4-130
  - command for split-screen 4-86
  - content presentation 4-56
- monitor commands B-3
- monitor1 command 4-172
- monitor1screensaveroutput command 4-173, 4-175
- monitor2 command 4-174
- mpautoanswer command 4-176
- mpmode command 4-177
- mtumode command 4-178
- mtusize command 4-179
- multicast IP address, command for stream 4-262
- multipoint button, command for access 4-142
- multipoint display mode, command for setting 4-177
- mute command 4-180
- muteautoanswer command 4-181
- N**
- name, video overlay 4-196
- natconfig command 4-182
- nath323compatible command 4-183
- nearloop command 4-184
- netstats command 4-185
- network commands B-5
- nonotify command 4-186
- notification commands B-7
- notifications, line state changes 4-161
- notify command 4-187
- ntpmode command 4-190
- ntpserver command 4-191
- null modem
  - cable 2-34
- null modem adapter 2-35
- numberofmonitors command 4-192
- numberofrouterhops command 4-193
- numdigitsdid command 4-194
- numdigitsext command 4-195
- O**
- overlayname command 4-196
- overlaytheme command 4-197
- P**
- parameters, configuring 4-52
- parameters, setting multiple 4-52
- password
  - command for administrator 4-8
  - command for chair control 4-46
  - command for GDS 4-104
  - command for meeting 4-170
  - remote access 4-285
  - room 4-285
- PathNavigator, command for multipoint calls 4-284
- pause command 4-198
- People+Content, H.239 command 4-131
- permissions commands B-7
- phone call, command to answer 4-21
- phone command 4-199
- phone flash command 4-102
- phone number
  - command for GMS contact 4-124
  - command for GMS technical support 4-273
  - command for room 4-229
  - command for system 4-275
- ping command 4-200
- pip command 4-201
- popupinfo command 4-203
- port settings
  - command for fixed 4-282
  - command for LAN 4-160
  - command for stream audio 4-260
  - command for stream video 4-266
  - command for TCP 4-272
  - command for UDP 4-280
  - command for VSX Web 4-308
- POTS cable 2-3
- POTS line, generating DTMF dialing tones 4-117

**PowerCam**

- break-out cable 2-17
- connecting as main camera 1-6–1-8
- connecting as secondary camera 1-8
- control cable 2-18, 2-21
- primary cable 2-16

**PowerCam Plus**

- connecting as main camera 1-13
- primary cable 2-15

presentation mode, command for multipoint display 4-177

preset command 4-204

PRI cable 2-2

PRI channel information 4-208

PRI port assignments 2-2

priareacode command 4-205

pricallbycall command 4-206

prichannel command 4-207

pricsu command 4-209

pridialchannels command 4-210

priintlprefix command 4-211

prilinebuildout command 4-212

prilinesignal command 4-213

primarycallchoice command 4-214

primarycamera command 4-215

prinumber command 4-216

prinumberingplan command 4-217

prioutsideline command 4-218

priswitch command 4-219

PTZ cameras, connecting 1-15

PVEC, command to enable 4-95

**Q**

quality preference 4-299

**R**

RCA adapter 2-22

reboot command 4-220

recent calls button, command for access 4-143

recentcalls command 4-221

registerall command 4-222

registerthissystem command 4-223

remote control IR codes F-1

remotecontrol command 4-224

remotemonenable command 4-226

repeat command 4-227

requireacctnumtodial command 4-228

restarting, commands that require C-1

room design A-1

room layout examples 1-1–1-4

roomphonenumber command 4-229

router hops, command for stream 4-264

router hops, number of 4-193

RS-232

- adapter 2-20

- cable 2-30

- interface

- configuring 3-1

- starting an API session 3-2

rs232 baud command 4-230

rs232 mode command 4-231

RS-232 serial port commands B-7

rs232monitor command 4-232

rs232port1 baud command 4-230

rs232port1 mode command 4-231

RS-366 cable 2-6, 2-7, 2-8

rs366dialing command 4-233

RS-449 cable 2-7

RS-449 commands B-6

RS-530 cable 2-8

RS-530 commands B-6

RSVP, command to enable 4-96

rt command 4-234

rts command 4-235

run command 4-236

**S**

screen command 4-237

screen saver setting 4-173, 4-175

screencontrol command 4-238

script file, command for running 4-236

secondarycallchoice command 4-239

security commands B-7

serial

- cable 2-32

serial port commands B-7

serialnum command 4-240

server

- command for DNS 4-82

- command for GDS 4-105

- command for NTP 4-191

- command for WINS 4-311

setaccountnumber command 4-241

showgatekeeper command 4-242

showpopup command 4-243

sleep command 4-244

- sleeptext command 4-245
  - sleeptime command 4-246
  - snapshottimeout command 4-247
  - SNMP, command for enabling 4-97
  - snmpadmin command 4-248
  - snmpcommunity command 4-249
  - snmpconsoleip command 4-250
  - snmplocation command 4-251
  - snmpsystemdescription command 4-252
  - snmptrapversion command 4-253
  - Sony cameras, connecting 1-18
  - soundeffectsvolume command 4-254
  - SoundStation VTX 1000
    - cable 2-27, 2-28
    - command for state 4-304
    - configuration with VSX system 1-20
    - connecting 1-19
  - speaker test, command for 4-118
  - speed, command for video stream 4-265
  - spidnum command 4-255
  - st command 4-257
  - statistics
    - command for advanced network 4-9
    - command for advanced network in XML 4-312
    - command for IP 4-151
    - command for network 4-185
    - command for network in XML 4-313
  - statistics commands B-4
  - status messages, B channel E-1
  - status notifications, command for registering 4-270
  - STD code, command for ISDN 4-152
  - stream command 4-258
  - streamannounce command 4-259
  - streamaudioport command 4-260
  - streamenable command 4-261
  - streaming
    - number of router hops 4-193
  - streaming commands B-7
  - streammulticastip command 4-262
  - streamrestoredefaults command 4-263
  - streamrouterhops command 4-264
  - streamspeed command 4-265
  - streamvideoport command 4-266
  - subnetmask command 4-267
  - subwoofer command 4-268
  - subwoofer volume attenuator 2-29
  - subwooferoffset command 4-269
- S-Video
    - adapter 2-11, 2-22
    - cable 2-9, 2-10
  - syntax
    - command for help 4-139
    - conventions 4-2
  - sysinfo command 4-270
  - system button, command for access 4-144
  - system settings commands B-8
  - systemname command 4-271
- ## T
- tcpports command 4-272
  - technical support, command for GMS 4-128
  - techsupport command 4-273
  - teleareacode command 4-274
  - telenumber command 4-275
  - telephony commands B-6
  - Telnet session 3-3
  - telnetmonitor command 4-276
  - theme, video overlay 4-197
  - time in call, command 4-168
  - timediffgmt command 4-277
  - tones, command for testing 4-118
  - traceroute command 4-278
  - typeofservice command 4-279
- ## U
- udpports command 4-280
  - unregisterall command 4-281
  - URL, command for GMS 4-129
  - usefixedports command 4-282
  - usegatekeeper command 4-283
  - usepathnavigator command 4-284
  - user settings, command for access 4-20
  - useroompassword command 4-285
- ## V
- V.35 cable 2-5, 2-6
  - V.35 commands B-6
  - V.35/RS-449/RS-530 adapter 2-4
  - v35broadcastmode command 4-286
  - v35dialingprotocol command 4-287
  - v35num command 4-288
  - v35portsused command 4-289
  - v35prefix command 4-290
  - v35profile command 4-291

v35suffix command 4-292  
validateacctnum command 4-293  
vcbUTTON command 4-294  
VCR audio out, command for controlling 4-295  
VCR/DVD composite cable 2-12  
vcraudioout command 4-295  
vcrrecordsource command 4-296  
vcstream command 4-297  
version command 4-298  
VGA cable 2-13  
vgaqualitypreference  
    command for video calls 4-299  
vgaqualitypreference command 4-299  
video call, command to answer 4-21  
video integration 1-5  
video overlay name, setting 4-196  
video overlay theme, setting 4-197  
video protocol, command for H.331 calls 4-137  
video quality 4-299  
videocallorder command 4-300  
VISCA cable 2-18  
Visual Concert  
    cable 2-28, 2-36  
    command for controlling 4-294  
    command for stream 4-297  
voicecallorder command 4-301  
volume  
    command for subwoofer 4-269  
volume command 4-302  
Vortex  
    cable 2-24, 2-26  
    configuration with VSX system 1-20  
    connecting 1-19  
vortex command 4-303  
VSX cable 2-27  
VTX cable 2-27, 2-28  
vtxstate command 4-304

## W

waitfor command 4-305  
wanipaddress command 4-307  
webport command 4-308  
whoami command 4-309  
winsresolution command 4-310  
winsserver command 4-311

## X

Xantech IR models 2-38  
xmladvnetstats command 4-312  
xmlnetstats command 4-313