

This box contains:

- The C40 codec
- Rack ears
- Remote control
- HDMI cable (3 m / 10 ft)
- Ethernet cable (5 m / 16 ft)
- Power cable (1.8 m / 6 ft)
- Batteries LR03 AAA 1.5 V for the remote control


User guides

The user documentation for this product, including compliance and safety information, is available on the Cisco web site. Go to: <http://www.cisco.com/go/telepresence/docs>.

Assembling the rack ear profiles


Mount the rack ear profiles to the codec.

1. Remove the two M3 screws on the left and right side of the codec.
Tool: Screwdriver, 2 mm Allen Key
2. Use the same two M3 screws to fasten the rack ear profiles to the codec.



IMPORTANT

There should always be a distance of minimum 10 cm / 4 in. free space in front of the codec.



SAFETY REQUIREMENT

Make sure the codec is not mounted with the front side up or down.



Connecting cables

For a basic setup, you should go through these steps:

1. Connect the main camera to the HDMI 1 input using a HDMI to HDMI cable
 - For camera control you should also connect the camera to the Camera Control input using the dedicated cable that came with your camera (RJ45 to DSUB)
2. Connect the monitor display to the HDMI 1 output using a HDMI to HDMI cable
3. If you want to send images from a PC, connect the PC to the DVI-I 3 input, using a DVI to DVI or a HDMI to DVI cable (for digital signals) or VGA to DVI cable (for analog signals) depending on your PC's capabilities
 - Audio from the PC could be connected to Line 1 and 2 inputs for stereo signals
4. Connect the microphone to the Mic/Line in 1 (XLR input)
5. The loudspeakers (optional) should be connected to Line 1 and 2 outputs
6. Connect the codec to the IP network using the Ethernet 1 interface
7. Connect the power and use the power switch to turn the codec on

NOTE: If using the DVI-I out 2 for the main monitor a shortcut is required to move the on screen display (OSD) to this output. On the remote control key in the following sequence:

- Disconnect - * - # - * - # - 0 - 2 - #

Basic setup - The main connectors are highlighted in orange color.

